Ref: C0.03.0 (1)


Section: C0 - ENGINE ACCESSORIES

FUEL COOLER PIPES Fig.

```
P/n
              ΟΤΥ
                   Name
```

Notes:

1	0.019.1931.3	1	channel
2	2.1310.002.2	2	flat washer 6.4x12.5
3	2.1011.103.2	2	nut m 6 p.1
9	2.6839.073.2	1	clamp 45
14	2.6851.001.0	2	clamp Ø 16/25
15	0.015.8420.0	1	pipe fitting
17	0.012.6449.0	1.32	tube
18	0.012.6450.0	1.2	tube Ø mm 13/20
20	2.6851.019.0	2	clamp Ø 13/20




Ref: C0.03.1 (1)

Section: C0 - ENGINE ACCESSORIES FUEL COOLER

Fig.	P/n	QTY	Name

Notes:

1.4	0.018.9384.3	1	radiator
1.4.8	2.1560.053.0	2	gasket 17 x 21
1.4.9	2.3249.373.0	1	pipe fitting 3/8"
1.4.10	2.3249.085.2/10	1	pipe fitting 3/8" gas



Ref: C0.03.3 (1)


Section: C0 - ENGINE ACCESSORIES FUEL PRELIMINARY FILTER

Fig. P/n QTY Name

Notes:

[XM.K 110 T4i -> ZKDY430200TH10001] 10001 <-

1	2.6851.019.0	6	clamp Ø 13/20
2	2.4319.316.0/10	1	precleaner
			@ 2.4319.316.0/10
3	0.020.7099.3	1	tube
4	2.3332.005.2	1	pipe fitting m 16 p.1.5
5	2.3110.404.2	3	plug m 16 p.1.5
6	2.1560.012.0	6	gasket 16.2 x 22
7	2.1310.004.2	5	flat washer 8.4x17
8	2.1310.001.2	4	flat washer 5.3 x 10
9	2.1071.004.2	2	special nut m 8
10	2.1011.102.2	4	nut m 5 p.0.7
11	2.0112.211.2	4	screw m 8 p.1.25 x 30
12	0.019.1475.3/10	1	tube
13	0.020.7098.3	1	tube
14	0.020.6903.3	1	tube
15	0.019.0960.3/10	1	bracket
16	0.012.6450.0	0.07	tube Ø mm 13/20
17	2.0112.207.2	1	screw m 8 p 1.25 x 20
18	0.012.6450.0	0.08	tube Ø mm 13/20
19	0.012.6449.0	0.06	tube
20	2.3261.007.2	1	pipe fitting m 16 p.1.5-9/16"
21	2.3264.011.2	2	pipe fitting



Section: C0 - ENGINE ACCESSORIES FUEL PRELIMINARY FILTER

Ref: C0.03.3 (2)




Fig.	P/n	QTY	Name

Notes:

1 2

2.6851.019.0	6	clamp Ø 13/20
2.4319.316.0/10	1	precleaner
		2.4319.316.0/10
0.020.7099.3	1	tube
2.3332.005.2	1	pipe fitting m 16 p.1.5
2.3110.404.2	3	plug m 16 p.1.5
2.1560.012.0	6	gasket 16.2 x 22
2.1310.004.2	5	flat washer 8.4x17
2.1310.001.2	4	flat washer 5.3 x 10
2.1071.004.2	2	special nut m 8
2.1011.102.2	4	nut m 5 p.0.7
2.0112.211.2	4	screw m 8 p.1.25 x 30
0.019.1475.3/10	1	tube
0.021.2676.3	1	tube
0.020.6903.3	1	tube
0.019.0960.3/10	1	bracket
0.012.6450.0	0.07	tube Ø mm 13/20
2.0112.207.2	1	screw m 8 p 1.25 x 20
0.012.6450.0	0.08	tube Ø mm 13/20
0.012.6449.0	0.06	tube
2.3261.007.2	1	pipe fitting m 16 p.1.5-9/16"
2.3264.011.2	2	pipe fitting
0.021.3780.0	1	connection

Name

ΟΤΥ

Section: C0 - ENGINE ACCESSORIES

FUEL TANK


P/n

Notes:

Fig.

[XM.K 110 T4i -> ZKDY430200TH10001]

	1.1	0.020.6477.3	1	fuel tank
	1.1.6	0.010.0749.0	2	breather
	1.1.7	0.020.7023.3	1	tube
	1.1.8	0.016.3795.3	1	tube
0-A-001	1.2	0.019.9407.4	1	plug
	1.3.1	0.016.9607.0	1	plug m10
	1.3.2	2.1560.006.0	1	gasket 10.2 x 16
	1.3.3	0.016.9605.0	1	plug m14
	1.3.4	2.1539.040.0	1	special oil seal 21.82 x 3.53
	1.4	2.7059.014.0	1	level indicator
	1.5	2.6839.066.0/10	1	clamp 16
	1.6	2.0112.006.2	1	screw m 6 p.1 x 18
	1.7	2.1470.002.2	1	lock washer 6
- 1.1	1.8	2.1011.101.2	6	nut
	1.9	2.1310.028.2	6	flat washer
	1.10	0.012.6451.0	1.14	tube Ø mm 8/15
	1.11	2.6851.018.0	2	clamp Ø11/17
	2	0.010.6927.0/10	1	shim
	3	0.014.3176.2/10	1	pin
	4	2.1549.334.2	1	spacer 26x30x8
	9	2.6851.019.0	4	clamp Ø 13/20
	10	0.012.6450.0	1.08	tube Ø mm 13/20
\sim				- DELIVERY
(@)	11	0.014.8587.2	1	pin
\cup	12	2.1470.002.2	1	lock washer 6
	13	2.0112.007.2	1	screw m 6 p.1 x 20
7	14	2.1549.328.2	1	spacer 10.5x20x45
	15	2.1569.161.0	2	gasket 20x50x6
	16	2.1599.354.2	1	washer 12.5x50x3
	17	2.0112.324.2	1	screw m 10 p.1.5x75
	18	2.1310.006.2	1	flat washer 10.5x21
	19	2.1011.106.2	1	nut m 10 p.1.5
	20	0.012.6450.0	1.55	tube Ø mm 13/20
				- RETURN



Ref: C0.03.4 (1)


Ref: C0.03.5 (1)

Section: C0 - ENGINE ACCESSORIES FUEL TANK SUPPORT

Fig.	P/n	QTY	Name

Notes:

4	2.1475.004.2	16	spring washer 12
22	2.0113.415.2	2	screw m 12 p.1.75 x 40
24	0.020.6919.0	1	bracket



Section: C0 - ENGINE ACCESSORIES FUEL TANK FIXING PARTS

Ref: C0.03.8 (1)

Fig. P/n QTY Name


Notes:

1 2 3	0.019.2969.2/10 0.019.2974.0 2.0312.412.2	1 1 1	tank support shim screw m 12 p.1.75x35
4	2.1480.016.2	1	washer 12
5	2.0112.424.2	1	screw m 12 p.1.75x75
6	2.1470.007.2	1	lock washer 12
7	2.1310.007.2	1	flat washer 13 x 24

Ref: 2.4319.316.0/10

Section: C0 - ENGINE ACCESSORIES **PREFILTER**

rkefilier				
QTY	Name			
1	precleaner			
1	filter			
1	clogging warning ind.			
1	screw			
1	ring			
	QTY 1 1 1 1 1 1 1 1 1			



2.4319.316.0_10

Section: C0 - ENGINE ACCESSORIES EXHAUST SYSTEM


Ref: C0.06.0 (1)

EXHAUST SYSTEM Fig. P/n QTY

P/n QTY Name

Notes:

1	01980210	1	silencer
2	04603276	2	fascia
3	04600004	2	gasket
4	04603585	2	clamp
5	04602018	1	gasket



Name

Ref: C0.06.1 (2)

Section: C0 - ENGINE ACCESSORIES

EXHAUST SYSTEM

P/n


Notes:

Fig.

[XM.K 110 T4i -> ZKDY430200TH10001]

1	0 010 01 49 2/10	1	
1	0.019.9148.3/10	1	plate
2	0.018.9834.3/10	1	tube
3	0.019.9155.3/10	1	bracket
4	0.019.9179.3/20	1	bracket
5	0.019.9149.3/10	1	bracket
6	0.021.1192.0	4	spacer
7	2.1475.003.2	2	washer 10
8	2.0112.308.2	2	screw m 10 p.1.5x22
9	2.1475.002.2	8	conical washer 8
10	2.0112.205.2	16	screw m 8 p.1.25 x 16
11	2.1310.004.2	12	flat washer 8.4x17
12	2.1470.004.2	12	lock washer 8
14	2.0112.207.2	4	screw m 8 p 1.25 x 20
15	0.019.7817.0	1	gasket

ΟΤΥ



Name

Ref: C0.06.3 (1)

Section: C0 - ENGINE ACCESSORIES

EXHAUST PIPE

QTY


Notes:

Fig.

[XM.K 110 T4i -> ZKDY430200TH10001]

P/n

1	0.020.5482.4	1	exhaust pipe
2	2.0112.207.2	2	screw m 8 p 1.25 x 20
3	2.1470.004.2	2	lock washer 8
4	2.1310.004.2	2	flat washer 8.4x17
5	2.0112.205.2	1	screw m 8 p.1.25 x 16
6	2.1475.002.2	2	conical washer 8
7	2.1312.004.2	2	washer 8x24x2
8	0.010.1054.2/10	1	support
10	2.1549.169.0	2	spacer 14.5x22x2
11	2.1579.994.2	1	spacer 8.5x14x7
12	0.020.6701.0	1	bracket
14	2.1011.105.2	1	nut m 8 p.1.25
20	0.019.9300.3	1	bracket
21	2.1310.006.2	2	flat washer 10.5x21
22	2.1470.006.2	2	lock washer 10
23	2.0112.310.2	2	screw m 10 p.1.5x28



Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com