JOHN DEERE AG & TURF DIVISION

Sprayer - 60 Gallon LP33813, LP33814, LP33815, LP33816, LP33817, LP33818

OMLVU24593 J1

OPERATOR'S MANUAL



JOHN DEERE

Original Instruction
All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 2011

Deere & Co.

John Deere Ag & Turf Division
All rights reserved

Previous Editions

COPYRIGHT©

North American Version Printed in U.S.A.

Introduction

Table of Contents

Introduction	
Product Identification	1
Safety Labels	2
Safety	3
Assembly	4
Installing	6
Removing and Storing	6
Operating	8
Service	10
Troubleshooting	10
Specifications	11
Getting Quality Service	11

Introduction

Using Your Operator's Manual

Read this entire operator's manual, especially the safety information, before operating.

This manual is an important part of your machine. Keep all manuals in a convenient location so they can be accessed easily.

Use the safety and operating information in the attachment operator's manual, along with the machine operator's manual, to operate and service the attachment safely and correctly.

If your attachment manual has a section called Preparing the Machine, it means that you will have to do something to your tractor or vehicle before you can install the attachment. The Assembly and Installation sections of this manual provide information to assemble and install the attachment to your tractor or vehicle. Use the Service section to make any needed adjustments and routine service to your attachment.

If you have any questions or concerns with the assembly, installation, or operation of this attachment, see your local John Deere dealer or call the John Deere Customer Contact Center at 1-800-537-8233 for assistance.

Warranty information on this John Deere attachment can be found in the warranty that came with your John Deere tractor or vehicle.

Product Identification

Product Compatibility


This Sprayer is compatible with Compact Utility Tractors:

2305, 2320, 2520, 2720, 3032E, 3038E, 3203, 3120, 3320, 3520, 3720, 4005, 4105, 4120, 4320, 4520, 4720

Safety Labels

Safety Labels

Safety Label Location



A- WARNING - MT3980



Understanding The Machine Safety Labels

The machine safety labels shown in this section are placed in important areas on your machine to draw attention to potential safety hazards.

On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards.

The operator's manual also explains any potential safety hazards whenever necessary in special safety messages that are identified with the word, CAUTION, and the safety-alert symbol.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

WARNING MT3980



MT3980

• To avoid injury from chemical hazards, wear protective clothing. Read and follow chemical manufacturer's labels and instructions.



Our support email: ebooklibonline@outlook.com