

**Series 300
3029, 4039, 4045,
6059, and 6068
OEM Diesel Engines**

**Deere Power Systems Group
OMRG18293 Issue H4
(This manual replaces OMRG18293 C3)**

LITHO IN U.S.A.
ENGLISH

Introduction

READ THIS MANUAL CAREFULLY to learn how to operate and service your engine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your engine and should remain with the engine when you sell it.

MEASUREMENTS IN THIS MANUAL are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by standing at the drive or flywheel end (rear) of the engine and facing toward the front of the engine.

WRITE ENGINE SERIAL NUMBERS and the option codes in the spaces indicated in the Specifications section. Accurately record all the numbers. Your dealer also needs these numbers when parts are ordered. File the identification numbers in a secure place off the engine.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

CERTAIN ENGINE ACCESSORIES such as radiator, air cleaner, and instruments are optional equipment on John Deere OEM Engines. These accessories may be provided by the equipment manufacturer instead of John Deere. This operator's manual applies only to the engine and those options available through the John Deere distribution network.

Engine Owner

JOHN DEERE ENGINE OWNER:

Don't wait until you need warranty or other service to meet your local John Deere Engine Distributor or Service Dealer.

Learn who he is and where he is. At your first convenience, go meet him. He'll want to get to know you and to learn what your needs might be.

UTILISATEURS DE MOTEURS JOHN DEERE:

N'attendez pas d'être obligé d'avoir recours à votre Concessionnaire ou Point de Service le plus proche pour vous adresser à lui.

Renseignez-vous dès que possible pour l'identifier et le localiser. À la première occasion, prenez contact avec lui et faites-vous connaître. Il sera lui aussi heureux de faire votre connaissance et de savoir que vous pourrez compter sur lui le moment venu.

AN DEN BESITZER DES JOHN DEERE MOTORS:

Warten Sie nicht auf einen evt. Reparaturfall um den nächstgelegenen John Deere Händler kennen zu lernen.

Machen Sie sich bei ihm bekannt und nutzen Sie sein "Service Angebot".

PROPRIETARIO DEL MOTORE JOHN DEERE:

Non aspetti fino a quando ha bisogno della garanzia o di un altro tipo di assistenza per incontrarsi con il Suo Concessionario che fornisce l'assistenza tecnica.

Impari a conoscere chi è e dove si trova. Alla Sua prima occasione cerchi d'incontrarlo. Egli desidera farsi conoscere e conoscere le Sue necessità.

PROPIETARIO DE EQUIPO JOHN DEERE:

No espere hasta necesitar servicio de garantía o de otro tipo para conocer a su Distribuidor de Motores John Deere o al Concesionario de Servicio.


Entérese de quién es, y dónde está situado. Cuando tenga un momento, vaya a visitarlo. A él le gustará conocerlo, y saber cuáles podrían ser sus necesidades.

JOHN DEERE MOTORÄGARE:

Vänta inte med att besöka Din John Deere återförsäljare till dess att Du behöver service eller garanti reparation.

Bekanta Dig med var han är och vem han är. Tag första tillfälle att besöka honom. Han vill också träffa Dig för att få veta vad Du behöver och hur han kan hjälpa Dig.

Identification Views




3029D Engine

S11,CONT,L3 -19-17FEB93

CDS0356 -JUN-03FEB93

Identification Views




4039T Engine

S11,CONT,L4 -19-17FEB93

RG6613 -JUN-03FEB93

Identification Views




4045T Engine

RG5603 -JUN-30NOV89

S11.CONT.L1 -19-08FEB91

Identification Views



6068T Engine

RG5604 -JN-30NOV89

S11,CONT,L2 -19-08FEB91

Contents

Page	Page
Record Keeping	
Engine Serial Number Plate	1
Record Engine Serial Number	2
Engine Option Codes	3
Record PTO Serial Number	5
Record Fuel Injection Pump Model Number	5
Safety	6
Fuels, Lubricants, and Coolant	
Diesel Fuel	13
Diesel Fuel Storage	14
Filling Fuel Tank	14
Minimizing the Effect of Cold Weather on Diesel Engines	15
Engine Break-in Oil	16
Engine Oil	17
OILSCAN™ and COOLSCAN™	18
Alternative and Synthetic Lubricants	18
Grease	19
Lubricant Storage	19
Engine Coolant Requirements	20
Recommended Engine Coolant	22
Engine Coolant Specifications	23
Replenishing Supplemental Coolant Additives Between Coolant Changes	25
Disposing Of Coolant	26
Engine Operating Guidelines	
Instrument (Gauge) Panel	27
Break-In Service	28
Daily Prestarting Checks	30
Auxiliary Gear Drive Limitations	32
Standby Power Units	33
Starting the Engine	33
Cold Weather Operation	35
Warming Engine	36
Changing Engine Speed—Standard (Mechanical) Governor	36
Idling Engine	37
Stopping the Engine	38
Using A Booster Battery or Charger	39
Lubrication and Maintenance	
Observe Service Intervals	40
Use Correct Fuels, Lubricants, and Coolant	40
Lubrication and Maintenance Service Interval Chart	41
Lubrication and Maintenance/100 Hour	
Lubricate PTO Clutch Shaft Bearings	42
Service Fire Extinguisher	42
Lubrication and Maintenance/250 Hour	
Service Battery	43
Change Engine Oil and Filter	45
Fan and Alternator Belts Tension or Replacement	47
Check PTO Clutch Adjustment	48
Lubrication and Maintenance/400 Hour	
Check and Adjust Engine Valve Clearance	49
Lubrication and Maintenance/600 Hr/1-Yr	
Lubricate PTO Clutch Internal Levers and Linkage	52
Clean Crankcase Vent Tube	52
Check Air Intake Hoses	53
Replace Fuel Filter Element	53
Check Effectiveness of Coolant Solution	55
Replace Air Cleaner Elements	55
Check Air Intake System	56
Check Cooling System	57
Lubrication and Maintenance/1200 Hr/2-Yr	
Check and Adjust Engine Speeds	58

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMRG18293 H4-19-11AUG94

COPYRIGHT© 1994
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual

Buy Now



Our support email:

ebooklibonline@outlook.com