

**Setting Up Instructions
Parts List**


**McCormick
No. 200 Tractor
Manure Spreader**

Owner's Manual

1005571R8

Reprinted

CASE III




 *THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.*

M171B

If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

Owner's Manual



SETTING UP INSTRUCTIONS

McCORMICK

No. 200

Tractor

Manure Spreader

INTERNATIONAL HARVESTER COMPANY

180 North Michigan Ave.

Chicago 1, Illinois, U.S.A.

Owner's Manual



PARTS LIST

McCORMICK

No. 200

Tractor

Manure Spreader

INTERNATIONAL HARVESTER COMPANY

180 North Michigan Ave.

Chicago 1, Illinois, U.S.A.



Farm Accidents can be prevented with your help

No accident-prevention program can be successful without the wholehearted co-operation of the person who is directly responsible for the operation of equipment.

To read accident reports from all over the country is to be convinced that a large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the harvest field or in the industrial plant, can be safer than the man who is at the controls. If farm accidents are to be prevented—and they can be prevented—it will be done by the operators who accept a full measure of their responsibility.

It is true that the designer, the manufacturer, the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that "*the best kind of a safety device is a careful operator.*" We ask you to be that kind of an operator.

NATIONAL SAFETY COUNCIL


All illustrations and descriptive matter in this publication apply to International Harvester products sold under the McCormick, McCormick-International, McCormick-Deering, or McCormick-Deering International trade name.

INSTRUCTIONS FOR OPERATING

Do not throw the spreader in gear while the machine is in motion.

CHAINS

Run all chains with hooks forward and slot side out, except the apron chains, which should be run as shown in *Illust. 23*.



Illust. 1

To detach chain, bend to bend to coupling position, and strike light blows.

HOW TO LOAD

CAUTION! In freezing weather, make sure that the apron is not frozen to the bed. Before loading, always be sure that the feed lever on the right side of the spreader is in neutral.

In order to get the best results, both as to spreading manure evenly on the ground and to avoid heavy draft, the machine should be loaded at the forward end of the box first, and continue loading toward the rear end until the cylinder is reached, being careful not to force the manure against the cylinder. This will allow the cylinder to start easy and the machine will draw much easier when loaded in this manner, as the manure is more easily separated.

When ready to spread, stop the tractor, and put the drive chain in gear by moving the left lever to the lower notch in the sector. Then set the feed lever (on right side) in Notch 1, 2, 3, 4, or 5 for the desired amount to spread.

When the load is almost all spread, a little manure will remain in the bed. To clean this out, disengage the drive and shift the lever into high feed. When the machine is empty, disengage the feed. Make this a regular practice so the feed will always be disengaged when the machine is empty.

GOOD CARE - LUBRICATION

Good care of a machine will save a great deal of expense and time. The manure spreader, above all other machines used on the farm, is subject to the worst conditions. Spreaders are often left in the field or yard, exposed to all conditions of weather, without attempting to clean or lubricate them properly. A machine should be stored in the shed or barn, and before storing away should be well cleaned and lubricated. A little kerosene is good occasionally on the apron links and the main bearings of the machine, afterwards using a little heavy lubricant, as the lye and acids which come from the manure are very severe on the metal parts, causing the steel to rust. Always use plenty of lubricant. It will increase the life of your machine. Before using, lubricate all parts well, such as the main axle bearings, cylinder bearings, apron drive shaft and widespread spiral boxes, and also see that all joints on the chain are well lubricated. This will make the apron run easier and prevent the links from rusting.

Buy Now



Our support email:

ebooklibonline@outlook.com