

Page Title	Page Number
ENGINE ASSEMBLY-A4.236 ENGINE	1
SHORT ENGINE-A4.236 ENGINE	2
CYLINDER BLOCK-A4.236 ENGINE	3
CRANKSHAFT, PISTONS AND CONNECTING RODS-A4.236 ENGINE	4
CYLINDER HEAD-A4.236 ENGINE	5
ROCKER SHAFT-A4.236 ENGINE	6
TIMING GEAR AND CAMSHAFT-A4.236 ENGINE	7
BALANCER UNIT-A4.236 ENGINE	8
FUEL INJECTION EQUIPMENT-A4.236 ENGINE	9
LUBRICATING OIL SUMP-A4.236 ENGINE	10
LUBRICATING OIL FILTER AND INTEGRAL COOLER-A4.236 ENGINE	11
WATER PUMP, THERMOSTAT AND HEAT EXCHANGER-A4.236 ENGINE	12
FUEL SYSTEM AND FILTER-A4.236 ENGINE	13
AIR INDUCTION AND EXHAUST SYSTEM-A4.236 ENGINE	14
ALTERNATOR POSITIONER-A4.236 ENGINE	15
JOINTS AND GASKETS-A4.236 ENGINE	16
STAND OIL FILTER-WITH SPACER	17
HEATER KIT-COLD CLIMATE	18
ALTERNATOR-VALEO TYPE	19
ALTERNATOR	20
ALTERNATOR-ISKRA TYPE	21
STARTER MOTOR-MARELLI TYPE	22
STARTER MOTOR-ISKRA TYPE	23
STARTER MOTOR-BOSCH	24
COOLING SYSTEM-FAN AND HOSES	25
COOLING SYSTEM-RADIATOR AND BRACKET	26
FUEL SYSTEM	27
FUEL TANK-TRACTOR 374 GE	28
FUEL TANK-TRACTOR 374 H	29
FUEL TANK-TRACTOR 374 SP	30
FUEL TANK-TRACTOR 374 FP	31
FUEL TANK-TRACTOR 374 AP	32
DRY AIR FILTER	33
EXHAUST SYSTEM-TRACTOR 374 SP	34
EXHAUST SYSTEM-TRACTOR 374 FP	35
EXHAUST SYSTEM-TRACTOR 374 AP	36
EXHAUST SYSTEM-TRACTOR 374 GE	37
EXHAUST SYSTEM-TRACTOR 374 SP - 374 FP - 374 AP - 374 H	38
THROTTLE CONTROLS-TRACTOR 374 SP - 374 FP - 374 GE	39
THROTTLE CONTROLS-TRATTRICE H	40
THROTTLE CONTROLS-TRACTOR 374 AP	41
INSTRUMENT PANEL-TRACTOR SP - FP - AP - GE	42
INSTRUMENT PANEL-TRATTRICE H	43
INSTRUMENT PANEL	44
INSTRUMENT PANEL-WITH ELECTRONIC LIFT - NOT INCLUDED TRACTOR	45
ELECTRICAL WIRING-REAR - TRACTOR SP - FP - AP - GE	46
ELECTRICAL WIRING-REAR - TRACTOR H	47
ELECTRICAL WIRING-FRONT - TRACTOR SP - FP - AP	48
ELECTRICAL WIRING-FRONT - TRACTOR H	49
ELECTRICAL WIRING-FRONT - TRACTOR GE	50
ELECTRICAL WIRING-TRACTOR SP - FP - AP	51
ELECTRICAL WIRING-TRATTRICE H	52
ELECTRICAL WIRING-TRACTOR SP - FP - AP	53
ELECTRICAL WIRING-REAR - TRACTOR H	54
ELECTRICAL WIRING-TRACTOR SP - FP - AP	55
BATTERY	56
LIGHTING EQUIPMENT-TRACTOR SP - FP - AP - GE	57
LIGHTING EQUIPMENT	58
LIGHTING EQUIPMENT-TRATTRICE H	59
CLUTCH PEDAL AND LINKAGE-TRACTOR SP - FP - GE - H	60
CLUTCH PEDAL AND LINKAGE-TRACTORT AP	61
CLUTCH-O.M.G. - 11	62
CLUTCH-LUK - 11	63
CLUTCH-O.M.G. - 12	64
CLUTCH-LUK - 12	65
LOWER CLUTCH P.T.O.-TRACTOR SP - FP - GE - H	66

TABLE OF CONTENT

LOWER CLUTCH P.T.O.-TRACTOR AP	67
CENTRE AXLE HOUSING AND TRANSMISSION HOUSING-WITHOUT OPTIONS (EXPORT ONLY)	68
CENTRE AXLE HOUSING AND TRANSMISSION HOUSING-FOR OPTIONS VERSION ONLY	69
CENTRE AXLE HOUSING AND TRANSMISSION HOUSING	70
CENTRE AXLE HOUSING AND TRANSMISSION HOUSING-TRACTORT AP	71
TRANSMISSION	72
TRANSMISSION-TRACTORT AP	73
TRANSMISSION	74
SHIFT LEVERS-TRACTOR SP - FP - AP - H	75
SHIFT LEVERS-TRACTOR GE	76
GEAR BOX	77
REDUCER OPTION-FOR SHUTTLE VERSION ONLY: TRACTOR SP - FP - GE	78
REDUCER OPTION-FOR SHUTTLE VERSION ONLY : TRACTOR AP	79
GEAR BOX-FOR SHUTTLE VERSION ONLY.	80
GEAR BOX-FOR SPECIAL OPTIONS VERSION ONLY	81
REDUCER OPTION-OVERDRIVE AND SHUTTLE VERSION	82
REDUCER OPTION-OVERDRIVE AND SHUTTLE VERSION	83
REDUCER OPTION-OVERDRIVE AND CREEPER VERSION	84
REDUCER OPTION-OVERDRIVE AND CREEPER VERSION	85
REDUCER OPTION-OVERDRIVE AND UNDERDRIVE VERSION	86
REDUCER OPTION-OVERDRIVE AND UNDERDRIVE VERSION	87
REDUCER OPTION-UNDERDRIVE AND SHUTTLE VERSION	88
REDUCER OPTION-UNDERDRIVE AND SHUTTLE VERSION	89
REDUCER OPTION-UNDERDRIVE E CREEPER VERSION	90
REDUCER OPTION-UNDERDRIVE E CREEPER VERSION	91
REDUCER OPTION-SHUTTLE AND CREEPER VERSION	92
REDUCER OPTION-SHUTTLE AND CREEPER VERSION	93
PTO SHAFT-STANDARD - TRACTOR SP - GE	94
PTO SHAFT-STANDARD - TRACTOR FP - H	95
PTO SHAFT-STANDARD - TRACTOR AP	96
PTO SHAFT-540/750/1000 R.P.M.- TRACTOR SP - GE	97
PTO SHAFT-540/750/1000 R.P.M.- TRACTOR FP - H	98
PTO SHAFT-540/750/1000 R.P.M.- TRACTOR AP	99
PTO-CONTROL-TRACTOR SP - GE	100
PTO-CONTROL-TRACTOR FP - AP - H	101
PTO-CONTROL-540/750/1000 R.P.M.- TRACTOR SP - GE	102
PTO-CONTROL-540/750/1000 R.P.M.- TRACTOR FP - AP - H	103
TRANSFER GEAR BOX AND DRIVE SHAFT:-TRACTOR 374 SP - FP - GE - H	104
TRANSFER GEAR BOX AND DRIVE SHAFT:-TRACTOR 374 AP	105
4 WHEEL DRIVE CONTROLS	106
REAR AXLE	107
REAR AXLE-TRACTOR 374 SP	108
REAR AXLE-TRACTOR 374 FP - 374 AP	109
REAR AXLE-TRACTOR 374 GE	110
REAR AXLE-TRACTOR 374 H	111
DIFFERENTIAL LOCK CONTROLS-MECHANICAL CONTROL	112
DIFFERENTIAL LOCK CONTROLS-HYDRAULIC CONTROL	113
DIFFERENTIAL LOCK CONTROLS-HYDRAULIC CONTROL	114
BRAKE AND CONTROLS-PEDALS	115
BRAKE AND CONTROLS-PIPINGS	116
BRAKE AND CONTROLS-DEVICE CONTROL	117
BRAKES	118
MASTER CYLINDER-BRAKE PUMP	119
BRAKE CYLINDER	120
TRAILER BRAKES-TRACTOR 374 SP - 374 FP - 374 AP - 374 H	121
TRAILER BRAKES-TRACTOR 374 SP - 374 FP - 374 AP - 374 H	122
REAR WHEELS-TRACTOR 374 SP	123
REAR WHEELS-TRACTOR 374 FP - 374 AP	124
REAR WHEELS-TRACTOR GE	125
REAR WHEELS-TRACTOR H	126
FRONT WHEELS-TRACTOR 374 SP	127
FRONT WHEELS-TRACTOR 374 FP - 374 AP	128
FRONT WHEELS-TRACTOR GE	129
FRONT WHEELS	130
FRONT AXLE 2 WHEEL DRIVE-TRACTOR FP - AP	131
FRONT AXLE 2 WHEEL DRIVE-TRACTOR SP - GE	132
FRONT AXLE 2 WHEEL DRIVE-TRACTOR H	133
FRONT AXLE 4 WHEEL DRIVE	134

TABLE OF CONTENT

FRONT AXLE 4 WHEEL DRIVE	135
FRONT AXLE 4 WHEEL DRIVE-TRACTOR SP	136
FRONT AXLE 4 WHEEL DRIVE-TRACTOR FP - AP	137
FRONT AXLE 4 WHEEL DRIVE-TRACTOR GE	138
FRONT AXLE 4 WHEEL DRIVE-TRATTRICE H	139
FRONT AXLE 4 WHEEL DRIVE-TRACTOR SP	140
FRONT AXLE 4 WHEEL DRIVE-TRACTOR FP - AP	141
FRONT AXLE 4 WHEEL DRIVE-TRACTOR GE	142
FRONT AXLE 4 WHEEL DRIVE-TRATTRICE H	143
FRONT AXLE 4 WHEEL DRIVE-TYPE NO-SPIN	144
FRONT AXLE 4 WHEEL DRIVE-TYPE STANDARD	145
FRONT AXLE 4 WHEEL DRIVE-TYPE HYDROLOCK	146
FRONT AXLE 4 WHEEL DRIVE-PINION SET AND SIDE SHAFT	147
FRONT AXLE 4 WHEEL DRIVE-PINION SET AND SIDE SHAFT	148
FRONT AXLE 4 WHEEL DRIVE-PINION SET AND SIDE SHAFT	149
FRONT AXLE 4 WHEEL DRIVE-PINION SET AND SIDE SHAFT	150
FRONT AXLE 4 WHEEL DRIVE-HOUSINGS AND STEERING CYLINDER	151
FRONT AXLE 4 WHEEL DRIVE-FINAL REDUCER AND WHELL HUB	152
FRONT AXLE 4 WHEEL DRIVE-WITH DIFFERENTIAL NO-SPIN AND STANDARD	153
FRONT AXLE 4 WHEEL DRIVE-WITH DIFFERENTIAL HYDROLOCK	154
STEERING HYDRAULIC LINES	155
STEERING HYDRAULIC LINES-TRACTOR SP - FP - GE	156
STEERING HYDRAULIC LINES-TRACTORT AP	157
STEERING HYDRAULIC LINES-TRATTRICE H	158
STEERING ORBITROL UNIT-2 WHEE DRIVE	159
STEERING ORBITROL UNIT-4 WHEELS DRIVE	160
STEERING-PUMP-TUROLLA	161
STEERING-PUMP-BOSCH	162
STEERING CYLINDER-TRACTOR SP - GE	163
STEERING CYLINDER-TRACTOR FP - AP - H	164
STEERING CYLINDER	165
HYDRAULIC EQUIPMENT-TRACTOR SP - FP - GE - H	166
HYDRAULIC EQUIPMENT-TRACTORT AP	167
HYDRAULIC EQUIPMENT-TRACTOR SP - FP - GE - H	168
HYDRAULIC EQUIPMENT-TRACTORT AP	169
HYDRAULIC EQUIPMENT-TRACTOR SP - FP - GE	170
HYDRAULIC EQUIPMENT-TRACTORT AP	171
AUXILIARY HYDRAULIC VALVE LINES-WITH AUXILIARY HYDRAULIC VALVE CLEARANCE	172
HYDRAULIC PUMP-TUROLLA	173
HYDRAULIC PUMP-BOSCH	174
HYDRAULIC PUMP-BOSCH	175
HYDRAULIC PUMP-TUROLLA	176
HYDRAULIC PUMP-TUROLLA	177
HYDRAULIC PUMP-BOSCH	178
HYDRAULIC LIFT VALVE-WITH MECANICS RISER	179
HYDRAULIC LIFT	180
HYDRAULIC LIFT-TRACTOR SP - GE	181
HYDRAULIC LIFT-TRACTOR FP - AP	182
HYDRAULIC LIFT-TRATTRICE H	183
HYDRAULIC LIFT-TRACTOR SP	184
HYDRAULIC LIFT-TRACTOR FP - AP	185
HYDRAULIC LIFT-TRATTRICE H	186
ELECTRICAL WIRING-FOR ELECTRONIC LIFT	187
ELECTRICAL WIRING-FOR ELECTRONIC LIFT	188
HYDRAULIC LIFT VALVE-FOR ELECTRONIC LIFT	189
ELECTRICAL WIRING-CONTROL PANEL ELECTRONIC LIFT	190
ELECTRICAL WIRING-CONTROL PANEL ELECTRONIC LIFT	191
ELECTRICAL WIRING-CONTROL PANEL ELECTRONIC LIFT	192
MECHANICAL CONTROL LIFT-TRACTOR SP	193
MECHANICAL CONTROL LIFT-TRACTOR GE	194
MECHANICAL CONTROL LIFT-TRACTOR FP - AP	195
MECHANICAL CONTROL LIFT-TRATTRICE H	196
MECHANICAL CONTROL LIFT-TRACTOR FP - AP	197
MECHANICAL CONTROL LIFT-TRACTOR SP	198
MECHANICAL CONTROL LIFT-TRACTOR SP - FP - AP	199
MECHANICAL CONTROL LIFT-TRACTOR GE	200
MECHANICAL CONTROL LIFT-TRATTRICE H	201
HYDRAULIC LIFT CYLINDER-HYDRAULIC LIFT CYLINDER,WITH 1'AND 2'AUXIL.HYD	202

TABLE OF CONTENT

HYDRAULIC LIFT CYLINDER-HYDRAULIC LIFT CYLINDER,WITH 1'AND 2'AUXIL.HYD	203
HYDRAULIC LIFT CYLINDER-HYDRAULIC LIFT CYLINDER,WITH 3AND 4 AUXIL.HYDR	204
HYDRAULIC LIFT CYLINDER-HYDRAULIC LIFT CYLINDER,WITH 3AND 4 AUXIL.HYDR	205
AUXILIARY HYDRAULIC VALVE LINES-WITH 1.O DISTRIBUTOR	206
AUXILIARY HYDRAULIC VALVE LINES-WITH 2.O DISTRIBUTORES	207
AUXILIARY HYDRAULIC VALVE LINES-WITH 3.O DISTRIBUTORES	208
AUXILIARY HYDRAULIC VALVE LINES-TRACTOR FP-AP-H ,WITH N.4 HYDRA. VALVE	209
CONTROLS ,AUXILIARY HYDRAULICS-WITH 1.O DISTRIBUTOR	210
CONTROLS ,AUXILIARY HYDRAULICS-WITH 2.O DISTRIBUTORES	211
CONTROLS ,AUXILIARY HYDRAULICS-WITH 3.O DISTRIBUTORES	212
CONTROLS ,AUXILIARY HYDRAULICS-TRACTOR FP - AP - H	213
PLATE FOR AUXILIARY HYDRAULIC VALVE-HIDROIRMA TYPE.	214
AUXILIARY HYDRAULICS VALVE STANDARD-HYDROIRMA TYPE STANDARD	215
AUXILIARY HYDRAULICS VALVE STANDARD-HYDROIRMA TYPE STANDARD	216
AUXILIARY HYDRAULICS FLOATING-HYDROIRMA TYPE FLOATING	217
AUXILIARY HYDRAULICS FLOATING-HYDROIRMA TYPE FLOATING	218
AUXILIARY HYDRAULIC VALVE LINES-WITH 1.O DISTRIBUTOR	219
AUXILIARY HYDRAULIC VALVE LINES-WITH 2.O DISTRIBUTORES	220
AUXILIARY HYDRAULIC VALVE LINES-TRACTOR FP-AP-H ,WITH N.3 HYDRA. VALVE	221
CONTROLS ,AUXILIARY HYDRAULICS-WITH 1.O DISTRIBUTOR	222
CONTROLS ,AUXILIARY HYDRAULICS-WITH 2.O DISTRIBUTORES	223
CONTROLS ,AUXILIARY HYDRAULICS-TRACTOR FP-AP-H ,WITH N.3 HYDRA. VALVE	224
AUXILIARY HYDRAULICS VALVE-TILL TYPE STANDARD	225
AUXILIARY HYDRAULICS VALVE-TILL TYPE FLOATING	226
ACCESSORIES HYDRAULIC-ADDITIONAL POWER OUTLET UNIT	227
LINKAGE-STANDARD VERSION	228
LINKAGE-STANDARD VERSION	229
LINKAGE-TRACTOR SP	230
LINKAGE-NOT INCLUDED GE TRACTOR	231
LINKAGE-TRACTOR GE	232
LINKAGE-NOT INCLUDED GE TRACTOR	233
LINKAGE-TRACTOR GE	234
LINKAGE	235
LINKAGE-MECANICS LIFT CYLINDER RIGTH	236
LINKAGE-TRACTOR FP - AP	237
LINKAGE-TRATTRICE H	238
LINKAGE-TRACTOR FP - AP	239
LINKAGE-TRATTRICE H	240
SHEET METAL	241
SHEET METAL-TRACTOR SP - FP - GE	242
SHEET METAL-TRACTORT AP	243
SHEET METAL-TRATTRICE H	244
COOLING SYSTEM-SHIELD FAN	245
SHEET METAL-TRACTOR SP - FP - GE	246
SHEET METAL-TRACTORT AP	247
SHEET METAL-TRACTOR 374 SP - 374 FP - 374 GE - 374 H	248
DECALS	249
DECALS	250
DECALS	251
DECALS	252
DECALS	253
FENDERS - FRONT-4 WHEELS DRIVE	254
FENDERS AND PLATFORM-TRACTOR SP	255
FENDERS AND PLATFORM-TRACTOR FP - AP	256
FENDERS AND PLATFORM-TRACTOR GE	257
FENDERS AND PLATFORM-TRATTRICE H	258
FENDERS AND PLATFORM-TRATTRICE H	259
SEAT	260
SEAT-CHASSIS AND SUSPENSION	261
SEAT-TRATTRICE H	262
SAFETY FRAME-TRACTOR SP - FP - GE	263
SAFETY FRAME-TRACTORT AP	264
SAFETY FRAME-TRATTRICE H	265
ROTATING LIGHT	266
WEIGHT FRAME AND WEIGHTS W	267
HITCH CONNECTIONS-WITHOUT HITCH	268
REAR HOOK	269
DRAWBAR-HEAVY DUTY	270

TABLE OF CONTENT

REAR HOOK-STANDARD TYPE	271
REAR HOOK-TRACTOR FP - AP - H	272
REAR HOOK-TRACTOR FP - AP - H	273
TOOL KIT	274
SEALERS AND LIQUID GASKETS ADHESIES	275
HEATER KIT-COLD CLIMATE	276
REDUCER OPTION-SHUTTLE AND CREEPER VERSION KIT	277
REDUCER OPTION-UNDERDRIVE AND SHUTTLE VERSION KIT	278
REDUCER OPTION-OVERDRIVE AND SHUTTLE VERSION KIT	279
REDUCER OPTION-OVERDRIVE AND SHUTTLE VERSION KIT	280
REDUCER OPTION-OVERDRIVE AND CREEPER VERSION KIT	281
REDUCER OPTION-SHUTTLE AND CREEPER VERSION KIT	282
KIT TRAILOR BRAKE LINES-TRACTOR SP - FP - AP	283
KIT TRAILOR BRAKE LINES-TRACTOR SP - FP - AP	284
HYDRAULIC PUMP DOUBLE BODY AND PIPINGS-SINGLE HYDRAULIC LINES	285
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 2.0 DISTRIBUTOR - HIDROIRMA	286
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 2.0 DISTRIBUTOR - HIDROIRMA	287
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 3.0 DISTRIBUTOR - HIDROIRMA	288
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 3.0 DISTRIBUTOR - HIDROIRMA	289
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 2.0 DISTRIBUTOR - HIDROIRMA	290
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 2.0 DISTRIBUTOR - TILL	291
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 2.0 DISTRIBUTOR - TILL	292
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 2.0 DISTRIBUTOR - TILL	293
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 3.0 DISTRIBUTOR - TILL	294
AUXILIARY HYDRAULIC VALVE LINES KIT-KIT FOR 3.0 DISTRIBUTOR - TILL	295
AUXILIARY HYDRAULIC VALVE LINES KIT-WITH AUXILIARY HYDRAULIC VALVE CLEARANCE	296
KIT FRONT FENDERS-4 WHEELS DRIVE	297
KIT HOOK PULL	298
KIT HOOK PULL-TRACTOR FP - AP	299

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)