BMX154 54" Blade for Tractors DX18E, DX24E

Operator's Manual

87300429 10/03 (OM 0325B54-A) © **2003 CNH Global N.V.**



TABLE OF CONTENT

INTRODUCTION – To the Purchaser	2	
SAFETY PRECAUTIONS	3	
Before Operation	3	
Notice	4	
Subframe & Blade	4	
Before Operation	4	
Blade & Subframe Operation	5	
The Tractor		
General Information	6	
Operating the Tractor		
During Operation	7	
Roll-Over Protective Structure "ROPS" (If Equipped)	7	
Additional Safety Equipment		
Maintenance	8	
Transporting	9	
Storage		
DECALS	10	
ASSEMBLY	11	
Blade Assembly	11	
Blade Installation & Removal	12	
Installation		
Removal	12	
OPERATION	13	
Blade Operation	13	
Up & Down Control		
Blade Angle Adjustment		
Shock Spring Adjustment		
Rigid Blade Operation		
Skid Shoe Adjustment		
Tractor Speed Recommendation		
Increasing Traction and Stability		
MAINTENANCE	11	
MAINTENANCE		
Lubrication		
PARTS		
Introduction		
Blade Assembly	16	
AVAILABLE EQUIPMENT	18	
ORQUE SPECIFICATION TABLE		

INTRODUCTION

TO THE PURCHASER

All products are designed to give safe, dependable service if they are operated and maintained according to instructions. <u>Read</u> and understand this manual before operation.

This manual has been prepared to assist the owner and operators in the safe operation and suitable maintenance of the equipment. The information is applicable to products at the time of manufacture and does not include modifications made afterwards.

Read and understand this operator's manual before attempting to put equipment into service. Familiarize yourself with the operating instructions and all the safetv recommendations contained in this manual and those labeled on the equipment and on Follow the tractor. the safetv recommendations and make sure that those with whom you work follow them.

<u>Illustrations</u>

The illustrations may not necessarily reproduce the full detail and the exact shape of the parts or depict the actual models, but are intended for reference only.

Direction Reference

All references to right and left, forward or rearward, are from the operator's seat, facing the steering wheel.

To assist your dealer in handling your needs, please record hereafter the model number and serial number of your equipment and tractor. It is also advisable to supply them to your insurance company. It will be helpful in the event that equipment or tractor is lost or stolen.

TRACTOR

BLADE

MODEL:

SERIAL NUMBER:

DATE OF PURCHASE:

DEALER NAME:

SAFETY PRECAUTIONS



This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.

A DANGER :	Indicates an immediate hazardous situation which, if not avoided, will result in death or serious injury.
WARNING :	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION :	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
IMPORTANT :	Indicates that equipment or property damage could result if instructions are not followed.
NOTE :	Gives helpful information.

All products are designed to give safe, dependable service if they are operated and maintained according to instructions. **Read and understand this manual before operation**. It is the owner's responsibility to be certain anyone operating this product reads this manual, and all other applicable manuals, to become familiar with this equipment and all safety precautions. Failure to do so could result in serious personal injury or equipment damage. If you have any questions, consult your dealer.

BEFORE OPERATION

<u>Children</u>

Tragic accidents can occur if the operator is not alert to the presence of children. Children are generally attracted to machines and the work being done. Never assume children will remain where you last saw them.

- 1. Keep children out of the operating area and under the watchful eye of another responsible adult.
- **2.** Be alert and turn machine off if children enter the work area.
- **3.** Before and when backing, look behind for small children.

- **4.** Never carry children while operating the machine. They may fall off and be seriously injured or interfere with the safe operation of the machine.
- 5. Never allow children to play on the machine or attachment even when they are turned off.
- 6. Never allow children to operate the machine even under adult supervision.
- **7.** Use extra care when approaching blind corners, shrubs, trees, or other obstructions that might hide children from sight.

SAFETY PRECAUTIONS - continued

NOTICE

A safe operator is the best assurance against accidents. All operators, no matter how experienced they may be, should read this operator's manual and all other related manuals before attempting to operate the equipment. Please read the following section and pay particular attention to all safety recommendations contained in this manual and those labeled on the equipment and on the tractor.

SUBFRAME & BLADE

Before Operation

- 1. Read and understand this operator's manual and tractor operator's manual. Know how to operate all controls and how to stop the unit and disengage the controls quickly.
- 2. Never wear loose, torn, or bulky clothing around the tractor, the subframe and the blade. It may catch on moving parts or controls, causing injury.
- **3.** Before and during seasons, thoroughly inspect the area where the equipment is to be used and remove all objects that may be thrown or cause damage to the equipment.
- **4.** Set transmission to neutral and disengage clutch, if equipped, before starting the engine.
- 5. Do not operate equipment in wintertime without wearing adequate winter garments. Always wear protective clothing.

- 6. Never attempt to make any adjustments while engine is running. Read this manual carefully to acquaint yourself with the equipment as well as the tractor operator's manual. Working with unfamiliar equipment can lead to accidents. Be thoroughly familiar with the controls and proper use of the equipment.
- **7.** Keep all safety guards in place and verify hardware for proper tightening.
- 8. Check for moving parts excessive wear regularly. Replace worn parts with genuine parts.
- **9.** Replace all missing, illegible, or damaged safety and warning decals. See list of decals in operator's manual.
- **10.** Keep safety decals clean of dirt and grime.
- **11.** Do not modify or alter this equipment or any of its components, or any equipment function without first consulting your dealer.
- **12.** Make sure the tractor is counterweighted as recommended by your dealer. Weights provide the necessary balance to improve stability, traction and steering.



Our support email: ebooklibonline@outlook.com