

Maxxum 5100 series tractors


Operator's manual

Print No. 9-78990

English 11/2007

9-78990

CASE *III*



GENERAL TABLE OF CONTENTS

MAINTENANCE AND TRANSFER INSTRUCTIONS 1

OUR COMMITMENT TO QUALITY 1

TRACTOR DATA 2

PRE-DELIVERY INSPECTION 3

TRACTOR TRANSFER TO CUSTOMER 8

MAINTENANCE AND INSPECTION SCHEDULES 11

250 HOURS INSPECTION 12

SERVICING SCHEDULE 14

INSPECTION AND MAINTENANCE RECORDS 17

EXPIRY OF THE WARRANTY 28

TRIM THIS EDGE

MAXXUM 5100 SERIES TRACTORS

MAINTENANCE AND TRANSFER INSTRUCTIONS

Our Commitment to Quality

Your CASE IH tractor is a product of the highest quality and reliability. Your CASE IH dealer is at your disposal for advice and information.

Your CASE IH dealer guarantees that your tractor is delivered in top condition. A comprehensive introduction into your newly acquired tractor ensures maximum benefits from the machine.

This booklet contains and explains all maintenance measures prescribed by CASE IH to ensure your tractor's long term serviceability. Please read with care the booklet as well as the operator's manual. Your CASE IH dealer will help you with any questions.

The purchase of this CASE IH tractor gives you the certainty of possessing a state-of-the-art machine of the highest quality. Its continued value, operation and reliability depend to a large extent on the regular maintenance and care of your CASE IH tractor.

TRIM THIS EDGE

Buy Now



Our support email:

ebooklibonline@outlook.com