# CASE Eagle Hitch Tractor Mounted Corn Planter

No. 45E Check and Drill

### **Operator's Manual**

D-1684



Reprinted



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

M171E

If Safety Decals on this machine use the words **Danger**, **Warning or Caution**, which are defined as follows:

- DANGER: Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- WARNING: Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- CAUTION: Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as





and s

if used, are RED.



IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

© 2001 Case Corporation

Bur 0-00000

March, 1995 (Revised October, 1997)

CASE and IH are registered trade marks of Case Corporation

### Operator's Instruction Manual

## CASE

# EAGLE HITCH TRACTOR MOUNTED CORN PLANTER

No. 45E Check and Drill

Airst Edition

J. I. Case Co. RACINE, WISCONSIN - U.S.A.



#### TO PURCHASERS OF CASE CORN PLANTERS

Congratulations on your purchase of a Case Corn Planter and welcome to the ever-increasing number of satisfied Case Owners.

The dependability and economical performance of your new Case Planter will prove that you were wise in making this choice.

The organization back of your planter has been building quality farm equipment for more than a century. Your Case Planter was built in one of the largest and best equipped plants in the world. In this factory, quality materials, precision machinery, high grade workmanship, thorough inspection and complete testing equipment are combined to give you the best in performance and economical operation.

The care which you give your planter will have a great deal to do with the service and satisfaction you get from it. By observing the precautions and suggestions in this manual, your Case Planter will serve you well for many years. Make this manual your guide. Should you need information not covered herein, or should your planter require special servicing, contact your Case Dealer. He has trained men who are kept informed on the best methods of servicing Case Farming Equipment in the field or in his shop.

When it becomes necessary, after long use, to replace certain parts on your planter, be sure to use only genuine Case Parts, thus insuring proper fit and continued good service. These may be obtained from your Case Dealer. It is always helpful to provide him with the Model of your planter in addition to a description and part number, if available, of the parts required.



Our support email: ebooklibonline@outlook.com