

S150

S160

TURBO



Bobcat®


Parts Manual

S/N 5269 11001 & ABOVE

S/N 5268 11001 & ABOVE

S/N 5267 11001 & ABOVE

S/N 5266 11001 & ABOVE



**EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)**



B-22380

S150/S160 CONTENTS

MAIN FRAME	11-42
MAINTENANCE ITEMS	11-12
MAINTENANCE SCHEDULE ITEMS	13-20
MAIN FRAME	21-22
OPERATOR CAB	23-26
SEAT & SEAT BAR	27-28
SEAT	29-30
PANELS	31-32
REAR DOOR	33-34
LIFT ARMS & BOBTACH	35-36
BOB-TACH	37-38
FUEL SYSTEM	39-42
DRIVE TRAIN	43-52
DRIVE TRAIN	43-44
AXLE	45-46
MOTOR CARRIER	47-48
DISC BRAKE	49-52
HYDRAULIC SYSTEM	53-100
HYDRAULIC CIRCUITRY	53-66
MANUAL LIFT RELEASE SYSTEM	67-70
AUXILIARY HYDRAULICS	71-74
TILT CYLINDER	75-76
LIFT CYLINDER	77-78
CONTROL PEDALS	79-80
HYDRAULIC CONTROL VALVE	81-96
BICS CONTROL VALVE	97-98
MANUAL LIFT RELEASE VALVE	99-100
HIGH FLOW HYDRAULICS	101-106
HIGH FLOW HYDRAULICS	101-106
HYDROSTATIC SYSTEM	107-138
HYDROSTATIC CIRCUITRY	107-118
HAND CONTROLS	119-122
HYDROSTATIC MOTOR	123-124
HYDROSTATIC PUMP	125-132
GEAR PUMP	133-134
HYDROSTATIC OIL FILTER	135-138
ELECTRICAL SYSTEM	139-158
CAB ELECTRICAL CIRCUITRY	139-140
ENGINE ELECTRICAL CIRCUITRY	141-144
CONTROLS ELECTRICAL	145-154
ALTERNATOR	155-156
STARTER	157-158
POWER UNIT	159-266
COOLING SYSTEM	159-162
ENGINE & ATTACHING PARTS	163-172
THROTTLE	173-174
COOLING FAN DRIVE ASSY.	175-176
ENGINE & GASKET KITS (KUBOTA V2203MDI)	177-178
GEARCASE (KUBOTA V2203MDI)	179-180
CRANKCASE (KUBOTA V2203MDI)	181-182
ROCKER ARM COVER (KUBOTA V2203MDI)	183-184
VALVE ROCKER ARM (KUBOTA V2203MDI)	185-186
CYLINDER HEAD (KUBOTA V2203MDI)	187-188

S150/S160 CONTENTS (Cont'd)

POWER UNIT (CONT'D)	159-266
OIL PAN (KUBOTA V2203MDI)	189-190
PISTON & CRANKSHAFT (KUBOTA V2203MDI)	191-192
FUEL CAMSHAFT (KUBOTA V2203MDI)	193-194
CAMSHAFT (KUBOTA V2203MDI)	195-196
WATER PUMP (KUBOTA V2203MDI)	197-198
WATER FLANGE & THERMOSTAT (KUBOTA V2203MDI)	199-200
MANIFOLDS (KUBOTA V2203MDI)	201-202
ENGINE STOP LEVER (KUBOTA V2203MDI)	203-204
GOVERNOR (KUBOTA V2203MDI)	205-206
SPEED CONTROL PLATE (KUBOTA V2203MDI)	207-208
INJECTION PUMP (KUBOTA V2203MDI)	209-212
INJECTOR NOZZLES (KUBOTA V2203MDI)	213-214
INJECTOR HOLDER (KUBOTA V2203MDI)	215-216
ENGINE & GASKET KITS (KUBOTA V2003MDIT)	217-218
GEARCASE (KUBOTA V2003TMDI)	219-220
OIL COOLER (KUBOTA V2003TMDI)	221-222
CRANKCASE (KUBOTA V2003TMDI)	223-224
ROCKER ARM COVER (KUBOTA V2003TMDI)	225-226
VALVE ROCKER ARM (KUBOTA V2003TMDI)	227-228
CYLINDER HEAD (KUBOTA V2003TMDI)	229-230
OIL PAN (KUBOTA V2003TMDI)	231-232
PISTON & CRANKSHAFT (KUBOTA V2003TMDI)	233-234
FUEL CAMSHAFT (KUBOTA V2003TMDI)	235-236
CAMSHAFT (KUBOTA V2003MDI)	237-238
WATER PUMP (KUBOTA V2003TMDI)	239-240
WATER FLANGE & THERMOSTAT (KUBOTA V2003TMDI)	241-242
MANIFOLDS (KUBOTA V2003TMDI)	243-244
TURBO CHARGER (KUBOTA V2003TMDI)	245-246
OIL PIPE (KUBOTA V2003TMDI)	247-248
ENGINE STOP LEVER (KUBOTA V2003TMDI)	249-250
GOVERNOR (KUBOTA V2003TMDI)	251-252
SPEED CONTROL PLATE (KUBOTA V2003TMDI)	253-254
BOOST COMPENSATOR (KUBOTA V2003TMDI)	255-256
INJECTION PUMP (KUBOTA V2003TMDI)	257-260
INJECTOR NOZZLES (KUBOTA V2003TMDI)	261-262
INJECTOR HOLDER (KUBOTA V2003TMDI)	263-264
AIR CLEANER	265-266
ACCESSORIES & OPTIONS	270-431
ACS CONVERSION KIT	270-271
ACCESS COVER	272-273
ACCESSORIES HARNESS	274-275
AXLE SEAL KIT	276-277
BACK-UP ALARM	278-279
BEACON	280-281
BLOCK HEATER	282-283
BOB-TACH LEVERS	284-285
BUCKET POSITIONING VALVE KIT	286-289
BUCKET POSITIONING VALVE	290-291
CAB DOOR	292-301
CAB ENCLOSURE	302-305
CAB WINDOWS	306-309
COUNTERWEIGHT KIT	310-313
DECALS	314-317
DELUXE CAB	318-319

S150/S160 CONTENTS (Cont'd)

ACCESSORIES & OPTIONS (Cont'd)	270-431
DUAL BATTERY KIT	320-321
ELECTRICAL CONTROLS KIT	322-327
ENGINE MOUNT KIT	328-329
EUROPEAN ACCESSORIES	330-341
FIRE EXTINGUISHER	342-343
F.O.P.S. KIT	344-345
FLASHER LIGHTS	346-347
FRONT AUXILIARY	348-349
GAS SPRING KIT	350-351
HAND CONTROL KIT	352-355
HEATER & A/C	356-375
HORN KIT	376-377
LIFT LIT	378-383
LIGHT KIT	384-385
MUFFLER/PURIFIER KIT	386-387
POWER BOB-TACH KIT	388-391
POWER BOB-TACH	392-395
RADIATOR SCREEN KIT	396-397
REAR AUXILIARY	398-401
REAR AUXILIARY VALVE	402-403
REAR DOOR LOCK	404-405
REAR WIPER	406-407
SEAL ENCLOSURE KIT	408-409
SEAT	410-413
SEAT BELT	414-417
SOUND KIT	418-419
SOUND OPTION	420-421
SOUND REDUCTION HARDHAT	422-423
STROBE LIGHT	424-425
TIRES & RIMS	426-429
BULK ITEMS	430-431
NUMERICAL INDEX	432-479
NUMERICAL INDEX	432-479

S150/S160 CONTENTS

MAIN FRAME	11-42
MAINTENANCE ITEMS	11-12
MAINTENANCE SCHEDULE ITEMS	13-20
MAIN FRAME	21-22
OPERATOR CAB	23-26
SEAT & SEAT BAR	27-28
SEAT	29-30
PANELS	31-32
REAR DOOR	33-34
LIFT ARMS & BOBTACH	35-36
BOB-TACH	37-38
FUEL SYSTEM	39-42
DRIVE TRAIN	43-52
DRIVE TRAIN	43-44
AXLE	45-46
MOTOR CARRIER	47-48
DISC BRAKE	49-52
HYDRAULIC SYSTEM	53-100
HYDRAULIC CIRCUITRY	53-66
MANUAL LIFT RELEASE SYSTEM	67-70
AUXILIARY HYDRAULICS	71-74
TILT CYLINDER	75-76
LIFT CYLINDER	77-78
CONTROL PEDALS	79-80
HYDRAULIC CONTROL VALVE	81-96
BICS CONTROL VALVE	97-98
MANUAL LIFT RELEASE VALVE	99-100
HIGH FLOW HYDRAULICS	101-106
HIGH FLOW HYDRAULICS	101-106
HYDROSTATIC SYSTEM	107-138
HYDROSTATIC CIRCUITRY	107-118
HAND CONTROLS	119-122
HYDROSTATIC MOTOR	123-124
HYDROSTATIC PUMP	125-132
GEAR PUMP	133-134
HYDROSTATIC OIL FILTER	135-138
ELECTRICAL SYSTEM	139-158
CAB ELECTRICAL CIRCUITRY	139-140
ENGINE ELECTRICAL CIRCUITRY	141-144
CONTROLS ELECTRICAL	145-154
ALTERNATOR	155-156
STARTER	157-158
POWER UNIT	159-266
COOLING SYSTEM	159-162
ENGINE & ATTACHING PARTS	163-172
THROTTLE	173-174
COOLING FAN DRIVE ASSY.	175-176
ENGINE & GASKET KITS (KUBOTA V2203MDI)	177-178
GEARCASE (KUBOTA V2203MDI)	179-180
CRANKCASE (KUBOTA V2203MDI)	181-182
ROCKER ARM COVER (KUBOTA V2203MDI)	183-184
VALVE ROCKER ARM (KUBOTA V2203MDI)	185-186
CYLINDER HEAD (KUBOTA V2203MDI)	187-188

S150/S160 CONTENTS (Cont'd)

POWER UNIT (CONT'D)	159-266
OIL PAN (KUBOTA V2203MDI)	189-190
PISTON & CRANKSHAFT (KUBOTA V2203MDI)	191-192
FUEL CAMSHAFT (KUBOTA V2203MDI)	193-194
CAMSHAFT (KUBOTA V2203MDI)	195-196
WATER PUMP (KUBOTA V2203MDI)	197-198
WATER FLANGE & THERMOSTAT (KUBOTA V2203MDI)	199-200
MANIFOLDS (KUBOTA V2203MDI)	201-202
ENGINE STOP LEVER (KUBOTA V2203MDI)	203-204
GOVERNOR (KUBOTA V2203MDI)	205-206
SPEED CONTROL PLATE (KUBOTA V2203MDI)	207-208
INJECTION PUMP (KUBOTA V2203MDI)	209-212
INJECTOR NOZZLES (KUBOTA V2203MDI)	213-214
INJECTOR HOLDER (KUBOTA V2203MDI)	215-216
ENGINE & GASKET KITS (KUBOTA V2003MDIT)	217-218
GEARCASE (KUBOTA V2003TMDI)	219-220
OIL COOLER (KUBOTA V2003TMDI)	221-222
CRANKCASE (KUBOTA V2003TMDI)	223-224
ROCKER ARM COVER (KUBOTA V2003TMDI)	225-226
VALVE ROCKER ARM (KUBOTA V2003TMDI)	227-228
CYLINDER HEAD (KUBOTA V2003TMDI)	229-230
OIL PAN (KUBOTA V2003TMDI)	231-232
PISTON & CRANKSHAFT (KUBOTA V2003TMDI)	233-234
FUEL CAMSHAFT (KUBOTA V2003TMDI)	235-236
CAMSHAFT (KUBOTA V2003MDI)	237-238
WATER PUMP (KUBOTA V2003TMDI)	239-240
WATER FLANGE & THERMOSTAT (KUBOTA V2003TMDI)	241-242
MANIFOLDS (KUBOTA V2003TMDI)	243-244
TURBO CHARGER (KUBOTA V2003TMDI)	245-246
OIL PIPE (KUBOTA V2003TMDI)	247-248
ENGINE STOP LEVER (KUBOTA V2003TMDI)	249-250
GOVERNOR (KUBOTA V2003TMDI)	251-252
SPEED CONTROL PLATE (KUBOTA V2003TMDI)	253-254
BOOST COMPENSATOR (KUBOTA V2003TMDI)	255-256
INJECTION PUMP (KUBOTA V2003TMDI)	257-260
INJECTOR NOZZLES (KUBOTA V2003TMDI)	261-262
INJECTOR HOLDER (KUBOTA V2003TMDI)	263-264
AIR CLEANER	265-266
ACCESSORIES & OPTIONS	270-431
ACS CONVERSION KIT	270-271
ACCESS COVER	272-273
ACCESSORIES HARNESS	274-275
AXLE SEAL KIT	276-277
BACK-UP ALARM	278-279
BEACON	280-281
BLOCK HEATER	282-283
BOB-TACH LEVERS	284-285
BUCKET POSITIONING VALVE KIT	286-289
BUCKET POSITIONING VALVE	290-291
CAB DOOR	292-301
CAB ENCLOSURE	302-305
CAB WINDOWS	306-309
COUNTERWEIGHT KIT	310-313
DECALS	314-317
DELUXE CAB	318-319

S150/S160 CONTENTS (Cont'd)

ACCESSORIES & OPTIONS (Cont'd)	270-431
DUAL BATTERY KIT	320-321
ELECTRICAL CONTROLS KIT	322-327
ENGINE MOUNT KIT	328-329
EUROPEAN ACCESSORIES	330-341
FIRE EXTINGUISHER	342-343
F.O.P.S. KIT	344-345
FLASHER LIGHTS	346-347
FRONT AUXILIARY	348-349
GAS SPRING KIT	350-351
HAND CONTROL KIT	352-355
HEATER & A/C	356-375
HORN KIT	376-377
LIFT LIT	378-383
LIGHT KIT	384-385
MUFFLER/PURIFIER KIT	386-387
POWER BOB-TACH KIT	388-391
POWER BOB-TACH	392-395
RADIATOR SCREEN KIT	396-397
REAR AUXILIARY	398-401
REAR AUXILIARY VALVE	402-403
REAR DOOR LOCK	404-405
REAR WIPER	406-407
SEAL ENCLOSURE KIT	408-409
SEAT	410-413
SEAT BELT	414-417
SOUND KIT	418-419
SOUND OPTION	420-421
SOUND REDUCTION HARDHAT	422-423
STROBE LIGHT	424-425
TIRES & RIMS	426-429
BULK ITEMS	430-431
NUMERICAL INDEX	432-479
NUMERICAL INDEX	432-479

Buy Now



Our support email:

ebooklibonline@outlook.com