

365 HYDRAULIC GANG MOWER

(Serial No. 010001 –)

OPERATOR'S MANUAL

**John Deere
Lawn & Grounds Care Division
OMMT1758 D4**

North American Version
Litho in U.S.A
English

TABLE OF CONTENTS

	Page
Safety	
Safety-Alert Symbol.....	1
Machine Safety Labels	1
Operational Decals (Electro-hydraulic Option)	3
Operational Decals (Electro-hydraulic Option)	4
Controls	
Function of Remote Controls (Optional Electro-Hydraulic (EH)).....	5
Troubleshooting Controls.....	6
Installing Mower	
Park Tractor Safely	7
Avoid High Pressure Fluids	7
Tractor Specifications	8
Install Hydraulic Lines (5 or 7-Gang).....	9
Electrical	10
Detaching Mower.....	11
Operating Mower	
Operator Training Required.....	12
Check Ground Conditions.....	12
Avoid Injury From Contacting Blades	13
Keep Riders Off	13
Wear Appropriate Clothing	13
Stay Clear of Rotating Drivelines.....	14
Park Safely	14
Help Prevent Serious Or Fatal Accidents	14
Avoid Tipping.....	15
Check Wheel Bolts	15
Starting Tractor Engine.....	16
Cutting Units	17
Adjusting Height-of-cut	18
Adjusting Reel-to-bed Knife Clearance.....	23
Backlapping Cutting Units.....	25
Backlap Valve (Optional)	27
Readjust Reel-to-bed Knife Clearance	29

TABLE OF CONTENTS

	Page
Operating Mower (Continued)	
Cutting Taller Grass	29
Grinding The Bed Knife.....	29
Replacing Bed Knife.....	30
Mercury Switches.....	31
Basics of Mowing Operation	32
Lifting Cutting Units	34
Parts	
WE RECOMMEND JOHN DEERE quality parts and lubricants, available at your John Deere dealer.	35
Optional Equipment	
The following attachments are available from your John Deere dealer.....	36
Service Safely	
Practice Safe Maintenance	37
Wear Appropriate Clothing.....	38
Stay Clear of Rotating Drivelines	38
Handling Waste Product and Chemicals.....	38
Avoid High Pressure Fluids.....	39
Service Mower	
Daily Service Required.....	40
Periodic Service Required.....	40
Service Record.....	42
Avoid Injury From Contacting Blades.....	43
Keep Service Area Clean.....	44
Grease	45
Perform Lubrication And Maintenance.....	46
Mower Hydraulic Oil	46
Cutting Unit Gear Case Grease	46
Cutting Unit Gear Case	46
Before Each Use	47
Hood.....	47
Changing Hydraulic Oil	48
Gear Case Oil Change.....	48

TABLE OF CONTENTS

	Page
Service Mower (Continued)	
Daily.....	49
Every 8 hours.....	50
Every 25 hours.....	52
After First 50 Hours of Use.....	53
Every 500 Hours.....	53
Yearly or Every 500 Hours.....	53
Removing Suction Element.....	54
Replacing Oil Filter.....	55
Replacing Return Filter.....	55
Lubricate Weekly.....	56
Hydraulic Routings.....	56
Hydraulic Routing—Rear Center Cutting Unit.....	57
Hydraulic Routing—Rear Right-hand Cutting Unit.....	58
Hydraulic Routing—Rear Left Hand Cutting Unit.....	59
Hydraulic Routing—Right Center Cutting Unit.....	60
Hydraulic Routing—Front Right-Hand Cutting Unit.....	61
Hydraulic Routing—Front Left-Hand Side.....	62
Hydraulic Routing—Left Center Cutting Unit (Optional 7-Gang).....	63
Hydraulic Routing—Valve Block (Optional 7-Gang Electro-Hydraulic(EH).....	64
Hydraulic Routing—Flow Divider (Optional 7-Gang Electro-Hydraulic (EH).....	65
Hydraulic Routing—Electro Hydraulic Valve.....	66
Hydraulic Routing—Electro-Hydraulic Valve Continued.....	67
Hydraulic Routing—Tee Union (Optional 7-Gang).....	68
Service Miscellaneous	
Checking Tire Pressure.....	69
Adapter Piece For Jackstand (optional).....	70
Electrical.....	71
Electrical Plug Sockets.....	71
Electrical Routing.....	72

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com