

# 35 Series 1 Farm Loader 1010 Utility, Single Row-Crop, and Row-crop Utility Tractors



JOHN DEERE


## OPERATORS MANUAL


35 Series 1 Farm Loader 1010 Utility, Single  
Row-Crop, and Row-crop Utility Tractors

OMC14081C (01FEB62) English

OMC14081C (01FEB62)

LITHO IN U.S.A.  
ENGLISH





# to the purchaser


This manual covers the operation, service, and lubrication instructions for the John Deere 35 Farm Loader, "Series 1," for 1010 Utility, Single Row-Crop, and Row-Crop Utility Tractors.

This loader has been designed to give many years of satisfactory service. The successful operation and long life of the loader depends of course on proper operation and the care given it. The first recommendation is that you read this manual carefully and follow the instructions. By so doing you may save much time and expense in the field. If additional information is needed, see your John Deere dealer.

Lubrication is very important. Refer to the Lubrication Chart.

When in need of parts see your John Deere dealer. He is equipped to provide genuine John Deere parts and service.

Right-hand and left-hand reference is determined by standing at



the rear of the tractor-loader combination and facing the forward direction of travel.


Before you forget, fill in the information below.

<b>JOHN DEERE 35 FARM LOADER "Series 1"</b>	
Date Purchased . . . . .	19 . . . . .
<i>(To be filled in by purchaser)</i>	




# contents

	Page
IDENTIFICATION VIEWS . . . . .	2-3
SPECIFICATIONS . . . . .	4
OPERATION . . . . .	5-20
Controls . . . . .	5-6
Tractor Operation . . . . .	6
Loader Operation . . . . .	7
Attaching Loader . . . . .	8-13
Detaching Loader . . . . .	13-18
Checking Couplers . . . . .	18
Safety Suggestions . . . . .	19
EXTRA EQUIPMENT . . . . .	19-22
LUBRICATION . . . . .	23
SERVICE . . . . .	24-27
Installing Remote-Controlled Hydraulic Attachment . . . . .	24-25
Cylinders . . . . .	26
Adding Oil to Tractor Hydraulic System . . . . .	27
TROUBLE SHOOTING . . . . .	28-29



John Deere 35 Farm Loader with Hydraulically-controlled 6-Tine Bucket on John Deere 1010 Utility Tractor

C-1682



C 1698

John Deere 35 Farm Loader on John Deere 1070 Utility Tractor

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)