

No. 3 Forage Harvester



OPERATORS MANUAL

No. 3 Forage Harvester

OME19682 Issue D4 English


OME19682 Issue D4

LITHO IN U.S.A. ENGLISH





introduction




Your new John Deere No. 6 Forage Harvester is a dependable machine. With proper care and operation, you can expect it to deliver the service and long life designed and built into it. Like any precision machine, your harvester will require a certain amount of attention at regular intervals. When any questions arise regarding lubrication, operation, or maintenance, use this manual as a guide to care for and service your machine the RIGHT WAY.

If you find yourself in need of additional information or special servicing not covered in this manual, see your John Deere dealer. He is in a position to answer your questions for you, or to secure the correct information.

When in need of parts, either to replace worn parts or to make emergency repairs, see your local John Deere dealer.

When ordering parts, provide your dealer with the serial number of your harvester or attachment, depending on the parts you need. This information will help him to give you prompt and efficient service.

The serial number of your machine is located on the lower rear right-hand portion of the main frame. (Record it in the space below.)




Record the serial number of the attachments in the spaces provided below:

Pickup Unit	
Row-Crop Unit	
Mower Bar Unit	




contents


IDENTIFICATION VIEWS	2-3	Cutternead Knives	26
		Knife Guide	2 6
SPECIFICATIONS	4	Cutterhead Brace	27
		Conveyor Idler	27
OPERATION	5-19	Gear Case	27
Controls	5-8	Wheel Bearings	28
Discharge Spout	5	Sealed Bearing Locking	
Feed Roll Clutch Lever	6	Collars	28
Wagon Hitch	6	Chains	28
Cutterhead Door Latch	6	Feed Roll Drive Chain	28
Lift Control	7	Main Drive Chain	28
Jack Stand	8	Mower-Bar Units	29-32
Safety Lock	9	Chain Tighteners	29
Lift Spring	9	V-Belt	30
Tongue Locating Pins	9	Cutter Bar	30-32
Hookup Instructions	10	Pitman and Stabilizer and	
Breaking-in	11	Bearings	32
Transporting	11	Stabilizer Arm	32
Starting the Harvester	12	Row-Crop Units	33-36
Tire Inflation	12	Conveyor for No. 6 or	
Shear Bolts	12	12	33
Safety	13	Conveyor for No. 6	33
Operating Adjustments	14-18	Gatherer Chains	33
Length of Cut	14	Main Drive Chain Idler .	34
Length of Cut Chart	15	Sickle Drive Chain for	
Adjustments for Length		2-Row Unit	34
of Cut	15	Island Drive Chain for	
Mower-Bar Unit	16	2-Row Unit	34
Row-Crop Unit	16-17	Lower Gatherer Drive	
Pickup Unit	18	Chains for 2-Row Unit	34
Storage	19	Sickle Idler for No. 6 or	
		12	35
LUBRICATION	20-23	Sickle	35-36
		Pitman adjustment	37
SERVICE	24 - 37	Pickup Unit	37
Belt and Pulleys	24	Drive Chain Tightener.	37
Cutterhead	25-27	Pickup Chain Idler	37
Shaft	25	-	
Bearings	25	ATTACHMENTS	38-43
Paddles	25		
Stationary Knife	26	ASSEMBLY	44-52




No. 6 Forage Harvester with 2-row row-crop unit



No. 6 Forage Harvester with 1-row row-crop unit



No. 6 Forage Harvester with mower bar unit



No. 6 Forage Harvester with pickup unit

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com