# Utility Backhoe PRO850, PRO900, PRO911 for 240, 250, 260, 270 and 4475, 5575, 6675, 7775, 8875 Skid Steers

(Serial No. 100100 – )



# OPERATOR'S MANUAL

John Deere Commercial Worksite Products

**OMKV16796 C0** 

North American Version Litho in U.S.A English

### INTRODUCTION

### THANK YOU for purchasing a John Deere product.

Read this manual and your vehicle manual thoroughly. Failure to do so could result in personal injury or equipment damage.

This manual should be considered a permanent part of your attachment and should remain with the attachment when you sell it.

Measurements in this manual are metric units and their U.S. customary equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (----->), it indicates the part it is pointing to is hidden.

Product warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The product warranty is explained on the warranty certificate you received from your dealer.

Record identification numbers below. Be sure to record all the numbers to help in tracing the attachment if it is stolen. You also need to give these numbers to your authorized John Deere skid steer dealer when you order parts.

SERIAL NUMBER (A):	M97929 —————
DEALER PHONE:	
DEALER NAME:	
DATE OF PURCHASE:	

### **TABLE OF CONTENTS**

	Page
Safety Signs	1
Preparing the Vehicle	4
Controls	5
Installing	6
Removing	14
Operating	19
Service Machine Safely	33
Service	35
Troubleshooting	40
Storing Machine	42
Assembly	43
Specifications	78
Warranty	85
Index	87
John Deere Service Literature	93

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1999

John Deere Commercial Worksite Products
All rights reserved
Previous Editions

COPYRIGHT© 1996 and 1994

### **SAFETY SIGNS**

### Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.



On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards. In this manual, the word CAUTION and this symbol call attention to safety messages.

### Machine Safety Labels (PRO850 Backhoe)

### WARNING (A)

- Seat mounting must be checked at regular intervals.
- Tighten if necessary.
- If cracks or rust occur replace this seat immediately.

### DANGER (B)

### AVOID CRUSH INJURY OR DEATH

- Operate backhoe controls from backhoe seat only.
- Secure backhoe to skid steer with tie rods or tie down yoke assembly and tool bar coupling levers before operating.

# B A DANGER A CAUTION C M97925

### CAUTION (C)

### HELP AVOID INJURY

- Read Operator's Manual.
- Avoid overhead and underground powerlines.
- Keep bystanders away from maximum swing reach area and stabilizers.
- Do not operate skid steer and backhoe using two operators.
- Lock backhoe swing and boom with lockpins when not in use or when transporting.
- Lower stabilizers and bucket before leaving seat.
- Keep all shields in place.

### **SAFETY SIGNS**

# Machine Safety Labels (PRO900 and PRO911 Backhoes)

### WARNING (A)

- Seat mounting must be checked at regular intervals.
- Tighten if necessary.
- If cracks or rust occur replace this seat immediately.

### DANGER (B)

## AVOID CRUSH INJURY OR DEATH

- Operate backhoe controls from backhoe seat only.
- Secure backhoe to skid steer with tie rods or tie down yoke assembly and tool bar coupling levers before operating.



### **CAUTION (C)**

#### HELP AVOID INJURY

- Read Operator's Manual.
- Avoid overhead and underground powerlines.
- Keep bystanders away from maximum swing reach area and stabilizers.
- Do not operate skid steer and backhoe using two operators.
- Lock backhoe swing and boom with lockpins when not in use or when transporting.
- Lock swing lever, lower stabilizers and bucket before leaving seat.
- Keep all shields in place.

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com