
47 and 59-Inch Snowblowers for 55 Series Tractors, 670 and 770 Tractors

(Serial No. 010001 –) (55 Series Tractors) (Serial No. 100001 –) (670 and 770 Tractors)



OPERATOR'S MANUAL

John Deere Lawn & Grounds Care Division OMM123336 C6

North American Version Litho in U.S.A English

INTRODUCTION

THANK YOU for purchasing a John Deere product.

The 47-Inch Snowblower can be used on the 55 Series Tractors. It will also fit the 670 and 770 Tractors but it will not cover the entire wheel track.



The 59-Inch Snowblower can be used on the 55 Series Tractors, and the 670, and 770 Tractors.

All information in this manual can be used for both snowblowers, and tractor models mentioned above. When information is for a specific application, it will be spelled out as such.

Read this manual and your vehicle manual thoroughly. Failure to do so could result in personal injury or equipment damage.

This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.

Measurements in this manual are U.S. customary units and their metric equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (- - - ►) it indicates the part it is pointing to is hidden.

Product warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The product warranty is explained on the warranty certificate you received from your dealer.

INTRODUCTION

Record identification numbers below. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also need to give these numbers to your dealer when you order parts.

Date of Purchase:	Dealer Name:	Phone:




TABLE OF CONTENTS

Page
Safety Signs
Safety-Alert Symbol
Preparing the Tractor
Preparing the Tractor3
Installing
Park Vehicle Safely
Removing
Park Vehicle Safely
Operating
SAFETY:
Operate Safely
Adjusting Spout

TABLE OF CONTENTS

TABLE OF CONTENTS

	Page
Assembly	J
Install Driveshaft	34
Install Lift Arms	34
Install Chute	
Route Chute Cables	
Install Cable Shield	
Install Drift Blade	37
Install Wear Plate (Optional)	38
Specifications	
Snowblower Specifications	39
Recommended Lubricants	
John Deere Service Literature	
Order Form	43

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1996
John Deere Horicon Works
All rights reserved
Previous Editions
COPYRIGHT© 1995, 1994, 1990,
1988 and 1986


SAFETY SIGNS

Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.

On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards. In this manual, the word CAUTION and this symbol call attention to safety messages.







Our support email: ebooklibonline@outlook.com