

**38, 48, and 54-Inch  
Commercial  
Walk-Behind Mowers**  
(Serial No. 010001 – )

**OPERATOR'S  
MANUAL**

**John Deere  
Lawn & Grounds Care Division  
OMM114548 B3**

**This manual replaces OMM114548 J2**

North American Version  
Litho in U.S.A  
English

# INTRODUCTION

**THANK YOU** for purchasing a John Deere product.

Read this manual thoroughly. Failure to do so could result in personal injury or equipment damage.



This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.

Measurements in this manual are U.S. customary units and their metric equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward.

Product warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The product warranty is explained on the warranty certificate you received from your dealer.

Record identification numbers below. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also need to give these numbers to your dealer when you order parts.

<b>Date of Purchase:</b> _____
-----------------------------------

<b>Dealer Name:</b> _____	<b>Phone:</b> _____
------------------------------	------------------------

<b>Power Unit Serial Number:</b> □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □
---



M73333

# INTRODUCTION

---

---

Engine Serial Number:  
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □



Mower Serial Number:  
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □



## TABLE OF CONTENTS

	Page		Page
<b>Safety</b>		Daily Operating Checklist ..	22
Safety-Alert Symbol .....	1	Starting To Mow .....	22
Machine Safety Labels .....	1	Travel Speeds .....	23
<b>Controls</b>		Traction Drive .....	24
Console Controls .....	3	PTO Switch .....	25
Handle Levers and Engine		Turn And Service Brakes ..	26
Controls .....	3	Grass Catcher .....	27
<b>Operating the Machine</b>		Transporting .....	28
Safety .....	4	<b>Lawn Care</b>	
Using Controls .....	8	Mowing Tips .....	29
Starting Engine .....	12	Bagging Tips .....	31
Stopping Engine .....	13	Mulching Tips .....	32
Daily Operating Checklist ..	14	<b>Replacement Parts</b>	
Testing Safety System .....	14	John Deere Quality Parts	
Avoid Damage To Plastic And		Available At Your John	
Painted Surfaces .....	15	Deere Dealer .....	34
<b>Operating the Mower</b>		<b>Service Machine Safely</b>	
Safety .....	16	Practice Safe	
Leveling Mower		Maintenance .....	36
Side-to-side .....	17	<b>Service Interval Chart</b>	
Leveling Mower (Front-to-		Services Required .....	38
rear) .....	18	<b>Service - Engine</b>	
Adjusting Level		Engine Oil .....	40
(Early Units) .....	19	Changing Engine Oil .....	41
Adjusting Level		Changing Engine	
(Late Units) .....	19	Oil Filter .....	42
Adjusting Cutting Height And		Cleaning Air Intake	
Gauge Wheels		Screen .....	43
(Early Units) .....	20	Cleaning Foam Element ....	43
Adjusting Cutting Height And		Replacing Paper	
Gauge Wheels		Element .....	44
(Late Units) .....	21	Carburetor Adjustments ....	45
Checking Blade		Changing Fuel Filter .....	48
Stop Time .....	21		

## TABLE OF CONTENTS

	Page		Page
<b>Service - Transmission</b>		<b>Service - Miscellaneous</b>	
Transmission Oil .....	49	Checking Tire Pressure .....	69
Checking Oil Level .....	49	Adjusting Tire Pressure .....	70
Changing Oil .....	50	John Deere Tire	
Replacing Belt .....	51	Warranty .....	70
<b>Service - Brakes</b>		Refueling Machine .....	71
Gear Selector Neutral		<b>Troubleshooting</b>	
Adjustment .....	52	Using Troubleshooting	
<b>Service - Mower</b>		Chart .....	73
Grease .....	53	<b>Storing Machine</b>	
Lubricating Mower .....	54	Storing Safety .....	77
Lubricating Idler		Storing Power Unit .....	77
Arm Bushing .....	55	Storing Mower .....	78
Inspecting Blades .....	55	Removing Mower From	
Checking Mower Blades .....	56	Storage .....	79
Adjusting PTO Clutch .....	57	<b>Assembly</b>	
Sharpening Blades .....	57	Assembly For Early Model	
Balancing Blades .....	58	Mowers .....	80
Belt Shields .....	58	Early Model Mowers—Install	
Replacing Mower Belt .....	59	Caster Wheel Assemblies &	
<b>Service - Electrical</b>		Left Mower Arm .....	81
Cleaning or Replacing		Early Model Mowers—Install	
Battery .....	61	Chute .....	82
Checking Battery Electrolyte			
Level .....	62		
Charging the Battery .....	63		
Charging Rates .....	65		
Using Booster Battery .....	66		
Limited Battery Warranty ...	67		
Replacing Fuse .....	68		
Cleaning And Gapping Spark			
Plug .....	68		

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1993  
John Deere Horicon Works  
All rights reserved  
Previous Editions  
Copyright© 1992, 1991, and 1990

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)