
PTO TILLER for 4300-4600 Compact Utility Tractors Models 660, 670 and 680

Serial No. (010001 -)



OPERATOR'S MANUAL

John Deere Worldwide Commercial And Consumer Equipment Division OMM137899 G8

INTRODUCTION

THANK YOU for purchasing a John Deere product.


Read this manual and your vehicle manual thoroughly. Failure to do so could result in personal injury or equipment damage.

This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.

Measurements in this manual are metric units and their U.S. customary equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (----->) it indicates the part it is pointing to is hidden.

Product warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The product warranty is explained on the warranty certificate you received from your dealer.

Record identification numbers. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also need to give these numbers to your dealer when you order parts.



DATE OF PURCHASE:
DEALER NAME:
DEALER PHONE:
SERIAL NUMBER (A):




TABLE OF CONTENTS

Safety Signs	1
Preparing Vehicle	3
Installing	
Removing	9
Operating Machine	
Replacement Parts	26
Service Machine Safely	27
Service	28
Troubleshooting	45
Storing Machine	46
Assembly	47
Specifications	57
Index	59
John Deere Service Literature	61

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1998
Deere & Co.
John Deere Worldwide Commercial and
Consumer Equipment Division
Horicon, WI
All rights reserved


OMM137899 G8

SAFETY SIGNS

Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.


On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards. In this manual, the word CAUTION and this symbol call attention to safety messages.



Machine Safety Labels


WARNING: AVOID INJURY FROM ROTATING KNIVES:

· Keep hands, feet and clothing away.



WARNING: AVOID INJURY FROM PTO:

- · Keep all shields in place.
- Keep hands, feet and clothing away.
- Operate only with 540 RPM.



SAFETY SIGNS

CAUTION: AVOID INJURY


- · Read Operator's Manual
- · Ballast power unit per operator's manual
- · Know location and function of controls
- Keep all shields in place
- Stay clear of power driven parts
- Never carry riders
- Keep people and pets a safe distance away from machine


BEFORE DISMOUNTING OR SERVICING

- Shut off engine and remove key
- · Lock brake for park
- Lower or block up machine




- · All driveline, tractor and equipment shields in place
- · Drivelines securely attached at both ends
- · Driveline shields that turn freely on driveline





DANGER: SHIELD MISSING DO NOT OPERATE

Picture Note: Separate telescoping driveshaft members to locate safety label. Label attached to outer profile tube.



Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com