

TRACTOR MODEL "MC"



JOHN DEERE

OPERATORS MANUAL TRACTOR MODEL "MC"

OMTMC2551 E1 English

JOHN DEERE WATERLOO WORKS
OMTMC2551 E1

LITHO IN THE U.S.A.
ENGLISH



TO THE PURCHASER

We welcome you to our ever-growing family of John Deere tractor owners. We are confident that the dependable and economical performance of the John Deere Model "MC" Tractor will prove that you made a wise choice.

The purpose of this manual is to acquaint you with the John Deere Model "MC" Tractor. The manual explains how to operate and service your tractor, and how to maintain its high operating efficiency. Instructions are given clearly, with the intention of making these operations as easy as possible.


Keep this manual in a convenient place for quick and easy reference. Use it as a guide whenever questions arise. You have purchased a dependable, sturdy tractor, but only by operating and caring for it properly can you expect to receive the service and long life for which it was designed.

If in the future you need new parts to replace those that may be worn, insist on genuine John Deere parts. They are exact duplicates of the originals, made from the same patterns and of the same high-quality materials.

When ordering parts, be sure to give the serial number of your tractor. The illustration below shows where to find this serial number, which should be written NOW in the space provided in the illustration. Also write in date purchased and owner's name.

Serial number of hydraulic attachment should also be recorded as indicated.

TRACTOR



JOHN DEERE MODEL "MC"
SERIES TRACTOR

Serial No.

Date Purchased

Owner

Serial No. of Hydraulic Attachment

• TABLE OF CONTENTS •

1

	Page
SPECIFICATIONS AND DATA.....	4
CONTROLS AND INSTRUMENTS.....	6
OPERATION OF TRACTOR.....	13
LUBRICATION.....	30
SERVICE INSTRUCTIONS.....	43
SERVICE REMINDERS.....	66
STORING THE TRACTOR.....	67
SAFETY SUGGESTIONS.....	68
TRACTOR DIFFICULTIES.....	69
INDEX.....	74

Even though your dealer has carefully inspected this tractor before delivering it to you, it is always good business to re-check the items which are circled on the reproduction below of the envelope which contains this manual.

TO THE NEW JOHN DEERE TRACTOR OWNER

Each John Deere Tractor is carefully designed, assembled, and given a complete test and final inspection at the factory before it is shipped. Our main ambition is to deliver tractors to new owners in the same mechanical condition as when shipped from the factory.

To enable us to fulfill this one ambition, this tractor was carefully inspected for irregularities that may have occurred in shipment. This inspection included a complete checking of the following:

- Track tension and alignment.
- Radiator; Fill with water or anti-freeze.
- Air cleaner oil level.
- Crankcase oil level.
- Transmission oil level.
- Steering clutches and brakes.
- Power clutch operation.
- Spark plug gaps.
- Carburetor setting (May require adjusting later, see Instructions in Manual).
- Engine speed and oil pressure.
- Inspect Rubber Hose connections.

Starter and Lighting Equipment

- Install new battery; Check water level; Grease terminal posts.
- Check charging rate.
- Check starting motor for operation.
- Serial number entered in owner's register.

The above inspection made by *John Doe*
Date *1/27/50* Dealer *Good Business Supply Co.*



**HANG THIS BOOK IN A
HANDY PLACE**

We suggest this rechecking especially during freezing weather or when a period of time has elapsed between delivery and when you are ready to operate it. For complete starting information, see page 15.



13969

We, your John Deere dealer, are mighty proud to add your name to our list of John Deere Tractor owners. Because we are interested in having you obtain from this new tractor all the comfort and long life that are built into it, we are pleased to discuss the following important maintenance operations:

- Controls and Instruments—Operation and Care.
- Breaking-in Period—Part Load, Open Throttle, Changing Oil.
- Method of Starting and Stopping Engine.
- Lubrication—Engine, Transmission, Air Cleaner, Track, Hydraulic System and Oil Gauge.
- Cooling System—Adding Water, Cleaning.
- Fuel System—Gasoline, Sediment Bowl and Trap, Carburetor Adjustment.
- Crankcase Breather Cap—Servicing.
- Track Tension and Alignment.
- Drawbar—Adjustment; pull from no other place.
- Distributor Care—Keeping Terminals Tight, Cleaning, Adjusting Points, Timing.
- Steering Clutches and Brakes.
- Power Clutch—Adjustment.
- Starter and Lights—Starting, Charging Rate Adjustment, Changing Fuse, Battery Care.
- Tightening Bolts and Nuts.
- Safety in Operation—Selecting Proper Speed, Keeping Guards on Power Shaft.
- Keeping the Tractor Clean.
- Operating the Tractor.
- Appointment for After-Sales Service—not later than two weeks after delivery.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com