

# 207 GYRAMOR ROTARY CUTTER



JOHN DEERE

## OPERATORS MANUAL 207 GYRAMOR ROTARY CUTTER

OMW11089 (01JAN62) English

OMW11089 (01JAN62)

LITHO IN THE U.S.A.  
ENGLISH



## TO THE PURCHASER

Your new John Deere Gyramor Rotary Cutter is sturdy and dependable. Proper care and operation will insure the service and long life built into it.

The many illustrations in this manual will assist you in making the necessary adjustments to adapt your Gyramor Rotary Cutter for all types of jobs.

Occasionally your new machine may require new parts. If so, we suggest that you take advantage of the facilities offered by your John Deere dealer, which assures you of genuine John Deere parts and prompt efficient service in the field or shop. Be sure and give him the correct part number of the part required.

Study this manual carefully and keep it handy, in a safe place, for future reference.



### JOHN DEERE GYRAMOR ROTARY CUTTER


The Gyramor Rotary Cutter has a Series Number plate attached to upper deck, directly behind the gear box. Become familiar with this Series Number and use it when ordering new parts.

DATE PURCHASED.....19.....  
SERIES NUMBER.....


*(To be filled in by Purchaser)*

## CONTENTS


	<i>Page</i>
SPECIFICATIONS.....	4
OPERATION.....	5-19
INTEGRAL GYRAMOR.....	6-11
Attaching to Tractor.....	7-9
Backing Machine.....	11
Cutting Height.....	10
Gauge Shoes.....	10
Gauge Wheel.....	10
Setting Depth Stop.....	11
Detaching from Tractor.....	11
Location of Mast Pin.....	11
Preparing Tractor.....	5-7
PULL-TYPE GYRAMOR.....	12-14
Attaching to Tractor.....	12
Cutting Height.....	14
Detaching from Tractor.....	13
Hydraulic Remote Cylinder.....	13
Leveling.....	14
Locating Pins in Lift Mechanism.....	13
Making Sharp Turns.....	14
Preparing Tractor.....	12
Tire Shield.....	14
INTEGRAL AND PULL-TYPE GYRAMOR.....	15-19
Blades.....	17
Converting Gear Housing.....	22
Double Blades.....	18
Front Shields.....	19
Gatherer Attachment.....	18
Rear Shield.....	18
Safety Suggestions.....	19
Shear Pin.....	16
Shredding Attachment.....	15
Slip Clutch.....	18
Transporting.....	15
SERVICE.....	20-23
Gear Housing.....	20-21
Converting Gear Housing.....	22
Shear Pin.....	23
Slip Clutch.....	23
Powershafts.....	24
LUBRICATION.....	25




*John Deere 207 Integral Gyramor Rotary Cutter*



*John Deere 207 Integral Gyramor Rotary Cutter  
Equipped with Rear Gauge Wheel*



*Front View of  
John Deere 207 Pull-Type Gyramor Rotary Cutter  
with Wheels in Front Position*



*Rear View of  
John Deere 207 Pull-Type Gyramor Rotary Cutter  
with Wheels in Front Position*

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)