

700, 720 AND 740 FARM WAGONS



JOHN DEERE


OPERATORS MANUAL

700, 720 AND 740
FARM WAGONS

OMW38905 I7 English

JOHN DEERE WELLAND WORKS
OMW38905 I7

LITHO IN THE U.S.A.
ENGLISH



Introduction

Read this manual carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.




Measurements in this manual are U.S. customary units and their metric equivalents.

Right-hand and left-hand sides are determined by facing in the direction of forward travel.

Warranty is on the warranty certificate which you should have received from your dealer.

The tire manufacturer's warranty supplied with your machine may not apply outside the U.S.

Write identification numbers in the Specifications section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. If this manual is kept on the machine, also file the identification numbers in a secure place off the machine.



All information, illustrations and specifications in this manual are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

Checklists

PREDELIVERY CHECKLIST

Check off each item as it is found satisfactory or after correction is made.

- Wagon gear has been correctly assembled.
- Tires are inflated to proper pressure.
- Wheel bolts are tightened to 176 N·m (130 lb-ft).
- Wagon gear has been lubricated.
- Scratches are painted.
- All decals are in place and readable.
- This wagon gear has been checked and to the best of my knowledge is ready for delivery to the customer.

Date Predelivered: _____

Signature: _____

W02;10PD -A 260387

DELIVERY CHECKLIST

Review the operator's manual with the customer explaining the following:

- John Deere warranty.
 - Safe operation and service.
 - Daily and periodic inspections.
 - Proper drawbar setting for 540 or 1000 rpm operation if PTO driven equipment is mounted on wagon gear.
 - Safety chain hookup.
 - Correct lubricants, lubrication and maintenance.
 - John Deere parts and service.
- Prior to final delivery to the customer do the following:
- Record serial number in the Specifications section.
 - Sign and remove this page for dealer's record.
 - Give the customer the operator's manual. Encourage the customer to read the manual.

Date Delivered: _____

Signature: _____

W02;10PD -B 260387

W58;1FC 7 260687

Checklists

AFTER-SALE CHECKLIST

It is suggested that the following items be checked sometime during the first six months operation of the machine.

- Check the entire machine for loose or missing hardware.
- Check for broken or damaged parts. Make necessary repairs.
- Acquaint the customer with any special attachments that will help do a better job.

- Check with the customer as to the performance of the machine.
- If possible, run the machine to see if it is functioning properly.
- Review the entire operator's manual with the customer and stress the importance of proper and regular lubrication and safety precautions.

Date Visited: _____

Signature: _____

W02;;10PD -C 260387

Contents


	Page		Page
Safety	05-1	740 Wagons	35-4
Preparing The Tractor		720 Wagons	35-5
Position Drawbar	10-1	Lubricating Wheel Bearings	35-5
Removing Quick-Coupler	10-1	Clean And Repack Wheel Bearings	35-6
Ballasting The Tractor	10-1	Adjusting Wheel Bearings	35-6
Attaching The Wagon		Replacing Spindles	35-6
Position The Tractor	15-1	Replacing Bushings	35-7
Attaching Standard Hitch Pole	15-1	Adjusting Wheel Toe-In	35-8
Attaching Adjustable Hitch Pole	15-2	Inspecting Tires And Wheels	35-9
Transporting		Assembly	
Transport Safely	20-1	Assemble Front Gear	40-1
Beware Of Low Wires	20-2	Assemble Rear Gear	40-1
Using Safety Lights And Devices	20-3	Install Reach	40-2
Using Seat Belt	20-3	Attach Hitch Pole	40-2
Multiple Hitching	20-3	Install Safety Chain Regular Hitch	40-3
Operating		Install Safety Chain Adjustable Hitch	40-3
Load Capacities And Towing Speeds		Crime Prevention	45-1
700 Wagon	25-1	Specifications	
720 Wagon	25-2	Specifications	
740 Wagon	25-3	700 Wagon	50-1
Load Wagon Safely	25-4	720 Wagon	50-2
Working On Inclines	25-4	740 Wagon	50-3
Checking Wheel Bolts	25-4		
Inflating Tires	25-4		
Checking Trailing	25-5		
Checking Chassis	25-5		
Adjusting Wheel Base	25-5		
Adjusting Hitch For Towing	25-6		
Adjusting Hitch Pole	25-6		
Attachments			
Installing Bolster Stakes	30-1		
Install Solid Front And Rear Bolsters, 740 Wagons	30-1		
Install Safety Chain Regular Hitch	30-2		
Install Safety Chain Adjustable Hitch	30-2		
Service			
Service Wagon Safely	35-1		
Keep Service Area Clean	35-1		
Service Tires Safely	35-1		
Checking Bolt Torque	35-2		
Selecting Grease	35-3		
Observing Intervals	35-3		
Lubricating Spindles And Steering Arms			
700 Wagons	35-4		

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



AB6;TB1389 053;ALERT 160687

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



AB6;TS187 053;SIGNAL 071085

FOLLOW SAFETY INSTRUCTIONS


Carefully read all safety messages in this manual and on your machine safety signs. Follow recommended precautions and safe operating practices.

Keep safety signs in good condition. Replace missing or damaged safety signs.



AB6;TS188 053;SIGNS 071085

SAFETY DECAL LOCATION



CAUTION

- To avoid possible loss of control during transport:
1. Do not exceed 10 mph (16 km/h) if total towed gross weight of wagons is greater than towing vehicle weight.
 2. Do not tow loads that exceed twice towing vehicle weight.
 3. Do not tow multiple wagons where combined gross weight of wagons exceeds rated capacity of leading wagon.

LEARN MACHINE SAFETY

Carefully read this manual. Learn how to operate the machine and how to use the controls properly.

Do not let anyone operate this machine without proper instruction.

Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.




AB6;TS183 053;READ2 080785

INSPECT WAGON GEAR

Check for loose or missing hardware.

Check condition of tires and wheel rims.


Keep wheel bolts tightened to 176 N·m (130 lb-ft) torque on 700 and 720 Wagons and 230 N·m (170 lb-ft) on 740 Wagons.



8DA;W9786 W02;;10SA -B 220687

MOUNT ATTACHMENTS SAFELY

When attaching other equipment to the wagon gear, refer to the operator's manual supplied with that equipment for complete attaching instructions.



1EA;W12772 W02;;10SA -C 290487

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com