

**AXIAL-FLOW® 7230**  
**AXIAL-FLOW® 8230**  
**AXIAL-FLOW® 9230**

**Combine**

*PIN YDG222001 and above*

**SERVICE MANUAL**

Part number 47636947

English

November 2013

Copyright © 2013 CNH America LLC. All Rights Reserved.





## **SERVICE MANUAL**

**AXIAL-FLOW 7230 [YDG222001 - ]**  
**AXIAL-FLOW 8230 [YDG222001 - ]**  
**AXIAL-FLOW 9230 [YDG222001 - ]**

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.202] Air cleaners and lines .....	10.2
[10.210] Lift pump and lines .....	10.3
[10.216] Fuel tanks .....	10.4
[10.218] Fuel injection system .....	10.5
[10.310] Aftercooler.....	10.6
[10.400] Engine cooling system .....	10.7
[10.414] Fan and drive .....	10.8
[10.418] Rotary screen .....	10.9
[10.450] Engine air compressor .....	10.10
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment .....	10.11
Main gearbox and drive .....	14
[14.100] Main gearbox and drive .....	14.1
Transmission.....	21
[21.100] Mechanical transmission lubrication system .....	21.1
[21.114] Mechanical transmission .....	21.2
[21.130] Mechanical transmission external controls.....	21.3
[21.145] Gearbox internal components.....	21.4
[21.182] Differential.....	21.5
Front axle system .....	25
[25.100] Powered front axle .....	25.1
[25.108] Final drive hub, steering knuckles, and shafts .....	25.2
[25.310] Final drives .....	25.3
Rear axle system.....	27

[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts .....	27.2
<b>Hydrostatic drive.....</b>	<b>29</b>
[29.100] Transmission and steering hydrostatic control .....	29.1
[29.202] Hydrostatic transmission .....	29.2
[29.218] Pump and motor components.....	29.3
[29.300] Rear hydrostatic transmission.....	29.4
<b>Power Take-Off (PTO).....</b>	<b>31</b>
[31.146] Front Power Take-Off (PTO) .....	31.1
<b>Brakes and controls .....</b>	<b>33</b>
[33.110] Parking brake or parking lock .....	33.1
[33.202] Hydraulic service brakes .....	33.2
<b>Hydraulic systems.....</b>	<b>35</b>
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump .....	35.3
[35.220] Auxiliary hydraulic pump and lines .....	35.4
[35.300] Reservoir, cooler, and filters.....	35.5
[35.350] Safety and main relief valves .....	35.6
[35.359] Main control valve.....	35.7
[35.410] Header or attachment height system .....	35.8
[35.415] Header or attachment tilting system .....	35.9
[35.440] Grain tank unload system.....	35.10
[35.536] Crop processor system .....	35.11
<b>Steering.....</b>	<b>41</b>
[41.101] Steering control .....	41.1
[41.200] Hydraulic control components.....	41.2
[41.216] Cylinders .....	41.3

[41.432] Autoguidance steering .....	41.4
<b>Wheels .....</b>	<b>44</b>
[44.511] Front wheels.....	44.1
[44.520] Rear wheels.....	44.2
<b>Tracks and track suspension .....</b>	<b>48</b>
[48.100] Tracks .....	48.1
[48.130] Track frame and driving wheels .....	48.2
[48.134] Track tension units .....	48.3
[48.138] Track rollers .....	48.4
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating.....	50.1
[50.200] Air conditioning .....	50.2
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.010] Fuel injection system.....	55.2
[55.011] Fuel tank system .....	55.3
[55.012] Engine cooling system .....	55.4
[55.013] Engine oil system .....	55.5
[55.014] Engine intake and exhaust system.....	55.6
[55.015] Engine control system.....	55.7
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.8
[55.100] Harnesses and connectors.....	55.9
[55.201] Engine starting system .....	55.10
[55.202] Cold start aid .....	55.11
[55.301] Alternator.....	55.12
[55.302] Battery.....	55.13
[55.408] Warning indicators, alarms, and instruments .....	55.14
[55.421] Feeding control system .....	55.15
[55.426] Harvest material flow control system.....	55.16

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)