

Patriot® 3240
Patriot® 3340
Tier 4B (final)
Sprayer

PIN YGT044001 and above

SERVICE MANUAL

Part number 48068911

1st edition English

October 2016



Link Product / Engine

Product	Market Product	Engine
Patriot® 3240 TIER 4B (FINAL) sprayer [YGT044001 -]	North America	F4HFE613F*B004
Patriot® 3340 TIER 4B (FINAL) sprayer [YGT044001 -]	North America	F4HFE613U*B002

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.310] Aftercooler.....	10.3
[10.400] Engine cooling system	10.4
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.5
Power coupling	19
[19.121] Pump-drive assembly	19.1
Front axle system	25
[25.100] Powered front axle	25.1
[25.108] Final drive hub, steering knuckles, and shafts	25.2
[25.122] Axle suspension control.....	25.3
Rear axle system	27
[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts	27.2
Hydrostatic drive	29
[29.218] Pump and motor components.....	29.1
Power Take-Off (PTO)	31
[31.220] Gearbox.....	31.1
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems	35
[35.000] Hydraulic systems.....	35.1
[35.104] Fixed displacement pump.....	35.2

[35.106] Variable displacement pump	35.3
[35.300] Reservoir, cooler, and filters.....	35.4
[35.703] Stabilizer hydraulic system.....	35.5
[35.735] Track frame widening system	35.6
[35.911] Sprayer boom hydraulic system.....	35.7
Frames and ballasting	39
[39.130] Sprayer boom	39.1
Steering.....	41
[41.101] Steering control	41.1
[41.206] Pump	41.2
[41.216] Cylinders	41.3
Wheels	44
[44.511] Front wheels.....	44.1
[44.520] Rear wheels.....	44.2
Cab climate control	50
[50.100] Heating.....	50.1
[50.200] Air conditioning.....	50.2
[50.300] Cab pressurizing system.....	50.3
Electrical systems	55
[55.000] Electrical system	55.1
[55.019] Hydrostatic drive control system	55.2
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.3
[55.100] Harnesses and connectors.....	55.4
[55.201] Engine starting system.....	55.5
[55.301] Alternator.....	55.6
[55.302] Battery.....	55.7
[55.512] Cab controls.....	55.8
[55.515] Wing/Boom control system.....	55.9

[55.988] Selective Catalytic Reduction (SCR) electrical system	55.10
[55.DTC] FAULT CODES.....	55.11
Chemical applicators	63
[63.100] Liquid fertilizer system	63.1
Spraying	78
[78.110] Chemical spraying.....	78.1
[78.120] Foam marking system.....	78.2
Platform, cab, bodywork, and decals	90
[90.105] Machine shields and guards	90.1
[90.150] Cab.....	90.2

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com