

AXIAL-FLOW® 7250
AXIAL-FLOW® 8250
AXIAL-FLOW® 9250
Tier 4B (final)
Combine

PIN YJG238001 and above

SERVICE MANUAL

Part number 51586252

1st edition English

March 2019



Link Product / Engine

Product	Market Product	Engine
AXIAL-FLOW® 7250 Tier 4B (final) [YJG238001 -]	North America	F3GFE613A*B001
AXIAL-FLOW® 8250 Tier 4B (final) [YJG238001 -]	North America	F3HFE613A*B003
AXIAL-FLOW® 9250 Tier 4B (final) [YJG238001 -]	North America	F3JFE613A*B001

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.206] Fuel filters	10.3
[10.210] Lift pump and lines	10.4
[10.216] Fuel tanks	10.5
[10.250] Turbocharger and lines.....	10.6
[10.254] Intake and exhaust manifolds and muffler	10.7
[10.304] Engine lubrication system.....	10.8
[10.310] Aftercooler.....	10.9
[10.400] Engine cooling system	10.10
[10.414] Fan and drive	10.11
[10.419] Stationary air screen	10.12
[10.450] Engine air compressor	10.13
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.14
Main gearbox and drive	14
[14.100] Main gearbox and drive	14.1
Power coupling	19
[19.110] Flywheel damper	19.1
Transmission	21
[21.100] Mechanical transmission hydraulic components	21.1
[21.114] Mechanical transmission	21.2
[21.140] Mechanical transmission internal components.....	21.3
[21.182] Differential.....	21.4
Front axle system	25

[25.100] Powered front axle	25.1
[25.310] Final drives	25.2
Rear axle system.....	27
[27.450] Rear-powered steerable axle	27.1
[27.550] Non-powered rear axle.....	27.2
Hydrostatic drive.....	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.218] Pump and motor components.....	29.2
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump	35.3
[35.106] Variable displacement pump	35.4
[35.105] Charge pump.....	35.5
[35.359] Main control valve.....	35.6
[35.500] Radiator cleaning system	35.7
[35.820] Hydraulic driven cooling fans	35.8
[35.410] Header or attachment height system	35.9
[35.602] Header or attachment leveling system	35.10
[35.796] Chaff spreader control	35.11
[35.440] Grain tank unloading system.....	35.12
[35.904] Cleaning hydraulic system	35.13
[35.925] Counter knife hydraulic system	35.14
[35.415] Header or attachment tilting system	35.15
[35.998] Feeder drive system	35.16

[35.999] Rotor drive system	35.17
[35.963] Chopper or beater drive system.....	35.18
Steering.....	41
[41.101] Steering control	41.1
[41.106] Tie rods.....	41.2
[41.200] Hydraulic control components.....	41.3
[41.216] Cylinders	41.4
[41.432] Autoguidance steering	41.5
Wheels.....	44
[44.511] Front wheels.....	44.1
[44.520] Rear wheels	44.2
Tracks and track suspension.....	48
[48.100] Tracks	48.1
[48.130] Track frame and driving wheels.....	48.2
[48.134] Track tension units	48.3
[48.138] Track rollers	48.4
Cab climate control.....	50
[50.100] Heating.....	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning.....	50.3
Electrical systems.....	55
[55.000] Electrical system	55.1
[55.010] Fuel injection system.....	55.2
[55.011] Fuel tank system	55.3
[55.012] Engine cooling system	55.4
[55.013] Engine oil system	55.5
[55.014] Engine intake and exhaust system.....	55.6
[55.015] Engine control system.....	55.7

[55.019] Hydrostatic drive control system 55.8

[55.020] Transmission speed sensors..... 55.9

[55.023] Transmission position sensors and switches 55.10

[55.024] Transmission control system 55.11

[55.029] Gearbox electric system 55.12

[55.030] Service brake electrical system 55.13

[55.031] Parking brake electrical system 55.14

[55.036] Hydraulic system control 55.15

[55.046] Rear axle control system..... 55.16

[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system..... 55.17

[55.100] Harnesses and connectors..... 55.18

[55.201] Engine starting system 55.19

[55.202] Cold start aid 55.20

[55.301] Alternator..... 55.21

[55.302] Battery..... 55.22

[55.404] External lighting 55.23

[55.405] External lighting switches and relays 55.24

[55.408] Warning indicators, alarms, and instruments 55.25

[55.421] Feeding control system 55.26

[55.422] Ejection/Unloading control system 55.27

[55.423] Cleaning control system..... 55.28

[55.426] Harvest material flow control system..... 55.29

[55.512] Cab controls..... 55.30

[55.518] Wiper and washer system..... 55.31

[55.519] Cab brake controls 55.32

[55.520] Cab harvesting controls 55.33

[55.525] Cab engine controls 55.34

[55.610] Ground speed control 55.35

[55.624] Residue handling control..... 55.36

[55.628] Threshing electrical control	55.37
[55.640] Electronic modules	55.38
[55.661] Cab header controls.....	55.39
[55.662] Header height control	55.40
[55.675] Reel speed and position control.....	55.41
[55.680] Autopilot/Autoguidance	55.42
[55.780] Shaker shoe leveling system control.....	55.43
[55.834] Sieve electric control	55.44
[55.836] Rotary separator control	55.45
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.46
[55.996] Feeder positioning control system	55.47
[55.997] Chopper or beater drive system.....	55.48
[55.DTC] FAULT CODES	55.49
Product feeding	60
[60.105] Floating roll, feed chain, and drive	60.1
[60.110] Feeder housing.....	60.2
[60.112] Stone trapping system	60.3
[60.120] Header drive system	60.4
[60.150] Feeder drive system	60.5
Threshing	66
[66.000] Threshing	66.1
[66.101] Concave conveyor plate	66.2
[66.110] Concave control system.....	66.3
[66.260] Threshing mechanism drive system	66.4
[66.331] Rotor	66.5
[66.360] Drum/Rotor housing.....	66.6
Separation	72
[72.420] Rotary separator	72.1

Residue handling	73
[73.230] Straw chopper.....	73.1
[73.210] Straw chopper drive system.....	73.2
[73.215] Straw chopper electro-magnetic clutch support.....	73.3
[73.430] Straw spreader.....	73.4
Cleaning	74
[74.100] Self-leveling frame.....	74.1
[74.101] Cleaning drive systems.....	74.2
[74.110] Grain pan.....	74.3
[74.114] Upper shaker shoe.....	74.4
[74.118] Lower shaker shoe.....	74.5
[74.130] Fan housing.....	74.6
[74.140] Tailings return system.....	74.7
Crop storage / Unloading	80
[80.101] Clean grain elevator.....	80.1
[80.150] Grain tank.....	80.2
[80.175] Grain tank unload drive system.....	80.3
[80.180] Grain tank unload.....	80.4
Platform, cab, bodywork, and decals	90
[90.150] Cab.....	90.1
[90.151] Cab interior.....	90.2
[90.118] Protections and footboards.....	90.3
[90.124] Pneumatically-adjusted operator seat.....	90.4
[90.102] Engine shields, hood latches, and trims.....	90.5
[90.105] Machine shields and guards.....	90.6

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com