


**GLP/GDP70VX, GLP/GDP60VX  
(D878)**




**SECTIONS**

<b>1</b>	<b>GENERAL TRUCK</b>
<b>2</b>	<b>DIESEL ENGINE</b>
<b>3</b>	<b>LPG ENGINES</b>
<b>4</b>	<b>FUEL SYSTEM</b>
<b>5</b>	<b>ELECTRICAL SYSTEM</b>
<b>6</b>	<b>STEERING SYSTEM</b>
<b>7</b>	<b>BRAKE SYSTEM</b>
<b>8</b>	<b>TRANSMISSION</b>
<b>9</b>	<b>HYDRAULIC SYSTEM</b>
<b>10</b>	<b>MAST-TWO STAGE LIMITED FREE-LIFT</b>
<b>11</b>	<b>MAST-THREE STAGE FULL FREE-LIFT</b>
<b>12</b>	<b>FORKS, LOAD BACKREST, AND MAST INSTALLATION</b>
<b>13</b>	<b>ATTACHMENTS AND HEADER HOSE GROUP</b>
<b>14</b>	<b>OPTIONS</b>
<b>15</b>	<b>NUMERICAL INDEX</b>

**SECTION 1  
GENERAL TRUCK**

DESCRIPTION	PAGE
CAB	
ATTACHING PARTS - SHEET 1 OF 2 .....	1-16
ATTACHING PARTS - SHEET 2 OF 2 .....	1-18
LEFT HAND DOOR ASSEMBLY .....	1-24
MAIN ASSEMBLY .....	1-14
RIGHT HAND DOOR ASSEMBLY .....	1-22
WINDOW WIPER SYSTEM .....	1-26
WINDOWS .....	1-20
COMPARTMENT PLATFORM .....	1-10
CONTROL LEVER LABELS	
MANUAL HYDRAULICS .....	1-54
COUNTERWEIGHTS AND FENDERS .....	1-28
COWL MOUNT .....	1-34
ELECTRONIC MINI LEVER LABELS	
DUAL FUNCTION .....	1-48
SINGLE FUNCTION .....	1-46
FLOORPLATES AND COVERS .....	1-8
FULL SUSPENSION SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS .....	1-38
FULL SUSPENSION SWIVEL SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS .....	1-40
HEATER .....	1-36
HOOD ASSEMBLY .....	1-2
INTERIOR PANELS AND COVERS .....	1-4
JOYSTICK LABELS .....	1-50
WITH RETURN TO SET TILT .....	1-52
LABELS	
EXTERIOR .....	1-42
INTERIOR .....	1-44
OVERHEAD GUARD .....	1-12
SEAT PAN AND COVERS .....	1-6
SOUND ABATEMENT	
DIESEL .....	1-30
LPG .....	1-32

### HOOD ASSEMBLY (FIGURE 1-1)




BP120554

**HOOD ASSEMBLY**

ITEM	PART NO.	DESCRIPTION	QTY
1	580086801	Seal .....	2
2	524298575	Hood (LH) (With Overhead Guard) .....	1
2	524298574	Hood (LH) (With Cab) .....	1
3	504235245	Handle .....	2
4	449001121	Capscrew .....	4
5	580017101	Washer .....	4
6	580055650	Nut .....	4
7	580078722	Sound Liner (LH) .....	1
8	580083675	Sound Liner (LH) .....	1
9	580078724	Sound Liner (LH) .....	1
10	580067512	Seal .....	1
11	580060019	Nut .....	12
12	580049915	Ball Stud .....	4
13	580072744	Gas Spring .....	2
14	580049231	Capscrew .....	16
15	580082458	Hinge .....	2
16	580026621	Nut .....	8
17	580056624	Pin (Rod End) .....	4
18	580000868	Lockring .....	4
19	580044861	Insert .....	8
20	580084838	Hinge (Base) .....	2
21	580027572	Nut .....	4
22	080143400	Motor Mount .....	4
23	518796686	Washer .....	4
24	580049331	Capscrew .....	4
25	580083446	Hood Support .....	1
26	580030966	Capscrew .....	3
27	580044860	Insert .....	3
28	524275588	Crossmember (With Overhead Guard) .....	1
28	524275589	Crossmember (With Cab) .....	1
29	580065933	Seal .....	1
30	580078725	Sound Liner (RH) .....	1
31	580083674	Sound Liner (RH) .....	1
32	580078720	Sound Liner (RH) .....	1
33	580058383	Bumper (Hood) .....	4
34	580067529	Seal .....	1
35	524298546	Hood (RH) (With Overhead Guard) .....	1
35	524298545	Hood (RH) (With Cab) .....	1
36	580088048	Hinge (Base) .....	2
37	580088049	Hinge .....	2

INTERIOR PANELS AND COVERS (FIGURE 1-2)



BP120386

**INTERIOR PANELS AND COVERS**


**KEY:**

**A: Manual Hydraulics**

**B: Electronic Hydraulics**

ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
1	580083020	Cover (Steering Column Upper) .....	1	1
2	580046138	Cover (Steering Column Lower) .....	1	1
3	932728908	Capscrew .....	5	5
4	580046139	Clip .....	8	8
5	580044859	Insert .....	5	5
6	580052292	Panel (Single Pedal) .....	1	1
6	580059919	Panel (Dual Pedal) .....	1	1
7	580077564	Cover Plate .....	1	..
7	580077566	Cover Plate .....	..	1
8	580077585	Seal .....	1	1
9	580077584	Seal .....	1	1
10	580058909	Dash Panel .....	1	..
10	580058910	Dash Panel .....	..	1
11	580052409	Cup Holder .....	1	1
12	909904403	Screw .....	2	2

### SEAT PAN AND COVERS (FIGURE 1-3)



BP120318



**SEAT PAN AND COVERS**

**KEY:**

**A: With Cab**

**B: Without Cab**

ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
1	580083001	Insert .....	4	..
2	<b>a</b> 580077811	Cover (Seat Surround) .....	1	..
2	<b>b</b> 580077812	Cover (Seat Surround) .....	..	1
2	524260440	Plug .....	1	1
3	922365300	Cap .....	1	1
4	580058269	Capscrew .....	2	2
5	580056526	Handle (Grab) .....	1	1
6	580078134	Spacer .....	2	2
7	580044860	Insert .....	2	2
8	580064483	Capscrew .....	4	4
9	580058191	Nut .....	4	4
10	580067605	Seal (LH) .....	1	1
11	580044861	Insert .....	9	9
12	580078131	Seal .....	2	2
13	580065022	Capscrew .....	3	5
14	580077522	Cover .....	1	..
14	580077523	Cover .....	..	1
15	580064981	Striker Bolt .....	1	1
16	580039438	Capscrew .....	2	2
17	580064982	Latch .....	1	1
18	580008580	Nut .....	1	1
19	580082436	Seat Pan .....	1	1
20	580067606	Seal (RH) .....	1	1
21	580051832	Grommet .....	2	2
22	<b>c</b> 580058137	Plug .....	2	2
22	<b>d</b> 580058137	Plug .....	1	1
23	580056815	Capscrew .....	20	20

**FOOTNOTES:**


**a** With Cab

**b** With Overhead Guard

**c** With Swivel Seat

**d** Without Swivel Seat

### FLOORPLATES AND COVERS (FIGURE 1-4)



BP120321

**FLOORPLATES AND COVERS**

**KEY:**

**A: Without Cab**

**B: With Cab**


ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
1	580077409	Floormat (Rear) .....	1	1
2	580077408	Floormat (Front) .....	1	1
3	580037206	Tail Light Base (RH) .....	1	1
4	580058212	Capscrew .....	4	4
5	580048573	Cover .....	1	1
6	580041711	Capscrew .....	3	3
7	580037205	Tail Light Base (LH) .....	1	1
8	580041704	Insert .....	4	4
9	580044859	Insert .....	3	3
10	580082371	Floorplate (Rear) .....	1	1
11	580041704	Insert .....	2	2
12	<b>a</b> 524274772	Cover (RH) (Rear) .....	1	..
12	<b>b</b> 524274773	Cover (RH) (Rear) .....	1	..
12	<b>a</b> 524274778	Cover (RH) (Rear) .....	..	1
12	<b>b</b> 524274777	Cover (RH) (Rear) .....	..	1
13	580056530	Screw .....	12	12
14	524274771	Cover (LH) (Rear) .....	1	..
14	524274776	Cover (LH) (Rear) .....	..	1
15	580083190	Plate (LH) .....	1	1
16	580058192	Nut .....	4	4
17	932731910	Capscrew .....	4	4
18	580065022	Capscrew .....	10	10
19	580083194	Plate (Lower LH Tread) .....	1	1
20	580026621	Nut .....	23	33
21	524246345	Plate (Upper LH Tread) .....	1	1
22	580083195	Cover (Front LH) .....	..	1
23	504225257	Nut .....	10	10
24	580078132	Seal .....	2	2
25	580083196	Plate (RH) .....	1	1
26	580083198	Plate (Upper RH Tread) .....	1	1
27	580083197	Cover (RH) .....	..	1
28	580083193	Plate (RH) .....	1	1
29	580064839	Floorplate .....	1	1
30	580038033	Grommet .....	1	1
31	580076408	Seal (RH) .....	1	1
32	580064968	Floorplate .....	1	1
33	580012987	Nut .....	8	8
34	580076407	Seal (LH) .....	1	1

**FOOTNOTES:**

**a** Cummins QSB 3.3L Diesel

**b** GM 4.3L LPG

COMPARTMENT PLATFORM (FIGURE 1-5)





BP120335

**COMPARTMENT PLATFORM**

<b>ITEM</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>	<b>QTY</b>
1	524251262	Module .....	1
2	909882405	Nut .....	2
3	504233271	Washer .....	4
4	505966562	Washer .....	4
5	580082448	Isolator .....	4
6	504323759	Stud .....	2
7	931015915	Capscrew .....	2

### OVERHEAD GUARD (FIGURE 1-6)



BP120357

**OVERHEAD GUARD**


ITEM	PART NO.	DESCRIPTION	QTY
1	524294779	Overhead Guard .....	1
2	258979300	Plug .....	4
3	524240692	Plug .....	1
4	524208883	Grommet .....	1
5	<b>b</b> 580058212	Capscrew .....	2
6	<b>b</b> 580051747	Handle (Alternate Horn Button) .....	1
7	580050959	Handle .....	1
8	580058447	Push Button Switch .....	1
9	580022893	Connector .....	1
10	505968540	Connector .....	1
11	505968514	Terminal (Pin) .....	2
12	<b>b</b> 580026812	Clip .....	1
13	<b>b</b> 580056613	Fastener .....	1
14	580066681	Capscrew .....	10
15	580058194	Nut .....	2
16	580044861	Insert .....	2
17	524201323	Grommet .....	1
	<b>a</b> 580083174	Grommet .....	1

**FOOTNOTES:**

**a** Not Illustrated

**b** Optional

**CAB (FIGURE 1-7)  
MAIN ASSEMBLY**




BP120332



**CAB  
MAIN ASSEMBLY**

ITEM	PART NO.	DESCRIPTION	QTY
1	524305879	Cab (☞ Page 1-16, ☞ Page 1-18, ☞ Page 1-20).....	1
2	.....	Cab Glass (☞ Page 1-20).....	1
3	524291221	Door (LH) (☞ Page 1-24).....	1
4	524291223	Door (RH) (☞ Page 1-22).....	1

**CAB (FIGURE 1-8)**  
**ATTACHING PARTS — SHEET 1 OF 2**




BP120330

**CAB**  
**ATTACHING PARTS – SHEET 1 OF 2**

ITEM	PART NO.	DESCRIPTION	QTY
1	524305879	Cab (With Steel Doors) (☞ Page 1-14).....	1
2	524201323	Grommet .....	1
3	580026712	Fan .....	1
4	580056815	Capscrew .....	2
5	580066767	Bracket .....	1
6	580044861	Insert .....	2
7	449015012	Nut .....	1
8	449022019	Lockwasher .....	4
9	580051168	Screw .....	4
10	580059493	Plug .....	10
11	580049231	Capscrew .....	4
12	580077842	Striker .....	2
13	580077851	Capscrew .....	2
14	580077852	Hose Assy .....	2
15	580062128	Fitting .....	2
16	580027573	Nut (Flange) .....	4
17	580041704	Insert .....	4
18	580039438	Capscrew .....	4
19	580077853	Reservoir (Washer Bottle with Pump) .....	1
20	258979300	Plug .....	4
21	580039799	Clip .....	1
22	580066681	Capscrew .....	10
23	580059127	Seal .....	2
24	580078007	Seal .....	2
25	524240692	Plug .....	1

**CAB (FIGURE 1-9)**  
**ATTACHING PARTS — SHEET 2 OF 2**



BP120338

**CAB**  
**ATTACHING PARTS – SHEET 2 OF 2**

ITEM	PART NO.	DESCRIPTION	QTY
	524305879	Cab .....	1
1	.....	Cab Frame .....	1
2	580080814	Headliner .....	1
3	580015532	Insert .....	5
4	580077071	Coat Hook .....	1
5	580080815	Gas Spring .....	2
6	580014787	Grommet .....	2
7	580015761	Hinge (RH) .....	2
8	580080812	Bolt .....	2
9	580080811	Guard .....	2
10	580016586	Block .....	2
11	580077087	Seal (Front Cowl) .....	1
12	580077088	Wire Harness (Cab) .....	1
13	580080817	Seal .....	1
14	580021628	Screw .....	2
15	580014801	Dome Light .....	1
16	580014800	Bulb .....	1
17	580077643	Fastener .....	2
18	580015760	Hinge (LH) .....	2

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)