



# 4620 Tractor




JOHN DEERE

## TECHNICAL MANUAL 4620 Tractor

TM1030 (01Apr76) English

**TM1030 (01Apr76)**

LITHO IN U.S.A.  
ENGLISH



**4620 TRACTOR****TECHNICAL MANUAL  
TM-1030 (APR-76)****CONTENTS****SECTION 10 - GENERAL**

- Group 5 - Specifications
- Group 10 - Predelivery, Delivery, and After-Sale Services
- Group 15 - Tune-Up
- Group 20 - Lubrication
- Group 25 - Separation

**SECTION 20 - ENGINE**

- Group 5 - General Information, Diagnosis, and Tests
- Group 10 - Cylinder Head, Valve Train, and Camshaft
- Group 15 - Cylinder Block, Liners, Pistons, and Rods
- Group 20 - Crankshaft, Main Bearings, and Flywheel
- Group 25 - Lubrication System
- Group 30 - Cooling System

**SECTION 30 - FUEL SYSTEM**

- Group 5 - Diagnosing Malfunctions
- Group 10 - Air Intake System
- Group 15 - Fuel Injection System
- Group 20 - Speed Control Linkage

**SECTION 40 - ELECTRICAL SYSTEM**

- Group 5 - Information and Wiring Diagrams
- Group 10 - Motorola Charging Circuit
- Group 12 - Delcotron Charging Circuit
- Group 15 - Delco-Remy Starting Circuit
- Group 17 - John Deere Starting Circuit
- Group 20 - Lighting and Accessory Circuits

**SECTION 50 - POWER TRAIN**

- Group 5 - Syncro-Range Transmission and PTO Clutches
- Group 10 - Syncro-Range Transmission
- Group 15 - Engine Disconnect Clutch
- Group 20 - Power Shift Transmission
- Group 25 - Differential
- Group 30 - Final Drive
- Group 35 - Syncro-Range PTO
- Group 40 - Power Shift PTO
- Group 45 - Power Front-Wheel Drive

**SECTION 60 - STEERING AND BRAKES**

- Group 5 - General Information

**SECTION 70 - HYDRAULIC SYSTEM**

- Group 5 - General Information, Diagnosis, and Tests
- Group 10 - Main Reservoir, Filters, Valves, Oil Cooler, and Oil Reservoir
- Group 15 - Hydraulic Pumps
- Group 20 - Power Steering
- Group 25 - Power Brakes
- Group 30 - Rockshaft and Implement Hitches
- Group 35 - Selective Control Valve, Breakaway Couplers, and Remote Cylinders

**SECTION 80 - MISCELLANEOUS**

- Group 5 - Conventional Front Axle
- Group 10 - Power Front-Wheel Drive Axle

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)