# JOHN DEERE WORLDWIDE COMMERCIAL & CONSUMER EQUIPMENT DIVISION

Compact Utility Tractor 3320, 3520, 3720

**OMLVU23878 IO** 

**OPERATOR'S MANUAL** 



Australian Version Litho in U.S.A.

#### Introduction

# Thank You for Purchasing a John Deere Product

We appreciate having you as a customer and wish you many years of safe and satisfied use of your machine.

#### **Using Your Operator's Manual**

This manual is an important part of your machine and should remain with the machine when you sell it.

Reading your operator's manual will help you and others avoid personal injury or damage to the machine. Information given in this manual will provide the operator with the safest and most effective use of the machine. Knowing how to operate this machine safely and correctly will allow you to train others who may operate this machine.

If you have an attachment, use the safety and operating information in the attachment operator's manual along with the machine operator's manual to operate the attachment safely and correctly.

This manual and safety signs on your machine may also be available in other languages (see your authorized dealer to order).

Sections in your operator's manual are placed in a specific order to help you understand all the safety messages and learn the controls so you can operate this machine safely. You can also use this manual to answer any specific operating or servicing questions. A convenient index located at the end of this book will help you to find needed information quickly.

The machine shown in this manual may differ slightly from your machine, but will be similar enough to help you understand our instructions.

RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line (-----), the item referred to is hidden from view.

Before delivering this machine, your dealer performed a predelivery inspection to ensure best performance.

#### Special Messages

Your manual contains special messages to bring attention to potential safety concerns, machine damage as well as helpful operating and servicing information. Please read all the information carefully to avoid injury and machine damage.



CAUTION: Avoid injury! This symbol and text highlight potential hazards or death to the operator or bystanders that may occur if the hazards or procedures are ignored.

IMPORTANT: Avoid damage! This text is used to tell the operator of actions or conditions that might result in damage to the machine.

NOTE: General information is given throughout the manual that may help the operator in the operation or service of the machine.

#### **Attachments for Your Machine**

There's a John Deere attachment or kit to make your new machine perform more tasks or be more versatile, whether your machine is a lawn tractor or compact utility tractor or a utility vehicle.

You can check out the entire line of attachments for your machine at JohnDeere.com or ask your John Deere dealer. From aerators to electric lift kits to tillers, there's a John Deere attachment or kit to fill every need.

## **Product Identification**

#### **Record Identification Numbers**

#### **Compact Utility Tractor**

3320, 3520, 3720 Open Station Models- PIN (710001-) 3320, 3520, 3720 Cab Models- PIN (740001-)

If you need to contact an Authorized Service Center for information on servicing, always provide the product model and identification numbers.

You will need to locate the identifications numbers for the product. Record the information in the spaces provided below.

DATE OF PURCHASE:

**DEALER NAME:** 

\_\_\_\_\_


**DEALER PHONE:** 

\_\_\_\_\_



MX35836


PRODUCT IDENTIFICATION NUMBER (A):



MX35851

ENGINE SERIAL NUMBER (B):

\_\_\_\_\_\_



MX3585

CAB SERIAL NUMBER (C):

# **Table of Contents**

Safety Labels	1
Safety	
Operating - Controls	13
Operating - Machine	
Replacement Parts	54
Service Intervals	55
Service Lubrication	57
Service Engine	58
Service Transmission	71
Service Steering & Brakes	75
Service Electrical	77
Service Miscellaneous	87
Troubleshooting	95
Storage	
Specifications	105
Index	113

#### Original Instruction

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 2011

Deere & Co.

John Deere Worldwide Commercial and


Consumer Equipment Division

All rights reserved

Previous Editions

COPYRIGHT©


#### **Safety Label Location**



MX41877

Picture Note: Use label number listed in table below to locate complete text of safety label message following this illustration.

- **A WARNING R138426**
- **B WARNING M117557**
- C DANGER T146195
- D CAUTION HOT SURFACE (embossed on muffler)
- **E WARNING M159705**
- **F WARNING M117554**
- **G DANGER/POISION M88249**
- **H CAUTION LVU10708**
- I WARNING LVU10709
- J WARNING LVU22753
- **K WARNING R141735**



MX41878

Picture Note: Use label number listed in table below to locate complete text of safety label message following this illustration.

- **A WARNING M117557**
- **B WARNING R120124**
- **C DANGER T146195**
- D CAUTION HOT SURFACE (embossed on muffler)
- **E WARNING M159705**
- F DANGER/POISON M88249
- **G WARNING M117554**
- **H WARNING LVU10707**
- I CAUTION MIU10747

# **Understanding The Machine Safety Labels**

The machine safety labels shown in this section are placed in important areas on your

machine to draw attention to potential safety hazards.

On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards.

The operator's manual also explains any potential safety hazards whenever necessary in special safety messages that are identified with the word, CAUTION, and the safety-alert symbol.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

#### **WARNING ROPS R141735**



R141735

If a canopy or sunshade is attached to the ROPS structure. the weight MUST be limited to 100 lb (45 kg) or less.

#### **WARNING M117557**



M117557

#### AVOID INJURY FROM PTO.

- · Keep all shields in place.
- · Keep hands, feet and clothing away.
- Operate only with 540 RPM.

#### **DANGER T146195**




T146195

Start only from seat in park or neutral.

Starting in gear kills.

#### **CAUTION HOT SURFACE**



Picture Note: Located on muffler.

NOTE: No-text warning molded into muffler.

Do not touch engine muffler, it may be hot.

#### **DANGER / POISON**



M88249

#### Picture Note: Located on battery.

SHIELD EYES: EXPLOSIVE GASES CAN CAUSE BLINDNESS OR INJURY.

NO SPARKS, FLAMES, SMOKING.

SULFURIC ACID CAN CAUSE BLINDNESS OR SEVERE BURNS.

FLUSH EYES IMMEDIATELY WITH WATER. GET MEDICAL HELP FAST.

KEEP OUT OF THE REACH OF CHILDREN. DO NOT TIP. KEEP VENT CAPS TIGHT AND LEVEL.

# CAUTION READ OPERATORS MANUAL LVU10708



LVU10708

- 1. Read Operator's Manual before operating this machine.
- 2. Keep all shields in place.
- 3. Hitch towed loads only to drawbar to avoid rearward upset.
- 4. Make certain everyone is clear of machine before starting engine or operation.
- 5. Keep all riders off machine and equipment.
- 6. Keep hands, feet and clothing away from power-driven parts.
- 7. Reduce speed when turning or applying individual brakes or operating around hazards on rough ground or steep slopes.
- 8. Couple brake pedals together for road travel.
- 9. Use flashing warning lights on highway unless prohibited by law.
- 10. Stop engine, lower implement to ground and shift to "PARK" or set brake(s) securely before dismounting.
- 11. Wait for all movement to stop before servicing machinery.
- 12. Remove key if leaving machine unattended.

#### **WARNING AVOID CRUSHING LVU10709**



LVU10709

• Keep Rollover Protective Structure fully extended.

- Do not jump if machine tips.
- Use seat belt.

When structure must be down;

- DO NOT use seat belt.
- Drive with extra care.

#### **WARNING M117554**



M117554

Hot surface

#### **WARNING ROPS R120124**



R120124

To maintain unimpaired operator protection and manufacturer's ROPS certification:

- Damaged ROPS structures must be replaced, not repaired or revised.
- Any alteration to the ROPS must be approved by the manufacturer.

#### **WARNING LVU22753**

#### **AVOID AMPUTATION**



LVU22753

• Hands or fingers may be pinched between folded ROPS and rear implements. Do not place hands or fingers near foldable ROPS when implements are raised.

# CAUTION READ OPERATORS MANUAL MIU10747



MIU10747

- 1. Read the operator's manual before operating the tractor.
- 2. Keep all shields in place.
- 3. Hitch towed loads only to drawbar to avoid rearward upset.
- 4. Make sure everyone is clear of machine before starting engine or operation.
- 5. Keep all riders off tractor and equipment.

- 6. Keep hands, feet, and clothing away from power-driven components.
- 7. Reduce speed when turning or applying individual brakes or operating around hazards on rough ground or steep slopes.
- 8. Couple brake pedals together for road travel.
- 9. Use flashing warning lights on highway unless prohibited by law.
- 10. Stop engine lower implement to ground and shift to "PARK" or set brake(s) securely before dismounting.
- 11. Wait for all movement to stop before servicing machinery.
- 12. Remove key if leaving tractor unattended.

#### **WARNING LVU10707**



LVU10707a

#### AVOID CRUSHING. Do not jump if machine tips.

• USE SEAT BELT.



Our support email: ebooklibonline@outlook.com