

# **Solar 75-V**

Shop Manual

023-00066AE

Serial Number 1001 and Up

January 2004

Daewoo reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

# TABLE OF CONTENTS

## Safety

Track Excavator Safety.....	S0102035K
-----------------------------	-----------

## Specifications

Specifications for Solar 75-V .....	S0202025K
-------------------------------------	-----------

## General Maintenance

General Maintenance Procedures.....	S0302000
Standard Torques.....	S0309000

## Upper Structure

Counterweight.....	S0403005K
Fuel Tank.....	S0405015K
Swing Bearing.....	S0407000

## Lower Structure and Chassis

Track Assembly .....	S0505075K
----------------------	-----------

## Engine and Drive Train

Air Conditioner .....	S0605015
-----------------------	----------

## Hydraulics

Accumulator.....	S0703010K
Center Joint (Swivel).....	S0704015K
Cylinders.....	S0705000
Travel Motor (with Gearbox).....	S0707355K
Swing Motor.....	S0707380
Main Pump (Rexroth).....	S0708375K

Pilot Control Valve (Work Lever / Joystick).....	S0709453K
Main Control Valve (REXROTH) .....	S709466K
Travel Control Valve (With Damper).....	S0709820K
Hydraulic Schematic (Solar 75-V).....	S0792096K

## **Electrical System**

Electrical System .....	S0802095K
Electrical Schematic (Solar 75-V) .....	S0892096K

## **Attachments**

Boom and Arm.....	S0902025K
Bucket.....	S0904000

# **SAFETY**

# TABLE OF CONTENTS

To the Operator of a Daewoo Excavator .....	5
Learn the Signal Words Used with the Safety Alert Symbol .....	7
General Safety Essentials .....	8
Accessory Applications .....	8
Lifting Capacity Rating Configuration .....	8
Location of Safety Labels .....	8
Summary of Safety Precautions for Lifting in Digging Mode .....	9
Unauthorized Modifications .....	10
General Hazard Information .....	10
Safety Rules .....	10
Safety Features .....	10
Inside Operator's Compartment .....	11
Clothing and Personal Protective Items .....	11
Breathing Masks, Ear Protection May Be Required .....	12
Vibration Level Information .....	12
Mounting and Dismounting .....	13
Fuel, Oil and Hydraulic Fluid Fire Hazards .....	14
Precautions When Handling Fluids at High Temperature .....	14
Asbestos Dust Hazard Prevention .....	15
Injury from Work Equipment .....	15
Fire Extinguisher and First Aid Kit .....	16
Protection from Falling or Flying Objects .....	16
Attachment Precautions .....	17
Accumulator .....	17
Indoor Ventilation .....	18
Emergency Exit .....	18
Before Starting Engine .....	19
Work Site Precautions .....	19
Checks Before Starting Engine .....	20
Engine Starting .....	21

Before Operating Machine .....	21
Machine Operation .....	22
When Swinging or Changing Direction of Travel .....	22
Travel Precautions .....	23
Traveling on Slopes .....	24
Prohibited Operations .....	24
Precautions for Operation .....	25
Avoid High-voltage Cables .....	26
Operate Carefully on Snow, Ice and in Very Cold Temperatures .....	26
Operations on Slopes.....	27
Parking Machine .....	27
Never Let Anyone Ride on Attachment .....	27
Maintenance.....	28
Warning Tag .....	28
Clean Before Inspection or Maintenance .....	28
Proper Tools .....	29
Use of Lighting .....	29
Fire Prevention and Explosion Prevention .....	29
Burn Prevention .....	30
Welding Repairs.....	31
Warning for Counterweight and Front Attachment Removal .....	31
Precautions for Removal, Installation, and Storage of Attachments .....	32
Precautions when Working on Machine.....	32
Lock Inspection Covers .....	32
Crushing Prevention and Cutting Prevention .....	33
Track Tension Adjustments Require Caution.....	33
Supports and Blocking for Work Equipment .....	33
Action When Abnormally Is Found During Inspection.....	34
Precautions with High-pressure Line, Tubes and Hoses.....	34
Waste Materials .....	35
Battery .....	36
Battery Hazard Prevention .....	36
Starting Engine With a Booster Cable .....	37

Connecting the Booster Battery .....	38
Disconnecting the Booster Battery .....	38
Towing .....	39
Precautions When Towing.....	39
Shipping and Transportation .....	40
Obey State and Local Over-the-Road Regulations.....	40
Lifting With Sling.....	40

# TO THE OPERATOR OF A DAEWOO EXCAVATOR



**DANGER!**

**Unsafe use of the excavator could lead to serious injury or death. Operating procedures, maintenance and equipment practices or traveling or shipping methods that do not follow the safety guidelines on the following pages could cause serious, potentially fatal injuries or extensive damage to the machine or nearby property.**

Please respect the importance of taking responsibility for your own safety, and that of other people who may be affected by your actions.

The safety information on the following pages is organized into the following sections:

1. "General Safety Essentials" on page 8
2. "Location of Safety Labels" on page 8
3. "Summary of Safety Precautions for Lifting in Digging Mode" on page 9
4. "Unauthorized Modifications" on page 10
5. "General Hazard Information" on page 10
6. "Before Starting Engine" on page 19
7. "Machine Operation" on page 22
8. "Maintenance" on page 28
9. "Battery" on page 36
10. "Towing" on page 39
11. "Shipping and Transportation" on page 40
12. "Lifting With Sling" on page 40





## **WARNING!**

**Improper operation and maintenance of this machine can be hazardous and could result in serious injury or death.**

**Operator and maintenance personnel should read this manual thoroughly before beginning operation or maintenance.**

**Keep this manual in the storage compartment to the rear of the operator's seat, and have all personnel involved in working on the machine read the manual periodically.**

**Some actions involved in operation and maintenance of the machine can cause a serious accident, if they are not done in a manner described in this manual.**

**The procedures and precautions given in this manual apply only to intended uses of the machine.**

**If you use your machine for any unintended uses that are not specifically prohibited, you must be sure that it is safe for any others. In no event should you or others engage in prohibited uses or actions as described in this manual.**

**Daewoo delivers machines that comply with all applicable regulations and standards of the country to which it has been shipped. If this machine has been purchased in another country or purchased from someone in another country, it may lack certain safety devices and specifications that are necessary for use in your country. If there is any question about whether your product complies with the applicable standards and regulations of your country, consult Daewoo or your Daewoo distributor before operating the machine.**



## SAFETY ALERT SYMBOL



**Be Prepared - Get To Know All Operating and Safety Instructions.**

**This is the Safety Alert Symbol. Wherever it appears in this manual or on safety signs on the machine you should be alert to the potential for personal injury or accidents. Always observe safety precautions and follow recommended procedures.**

### LEARN THE SIGNAL WORDS USED WITH THE SAFETY ALERT SYMBOL

The words "**CAUTION**," "**WARNING**" and "**DANGER**" used throughout this manual and on decals on the machine indicate degree of risk of hazards or unsafe practices. All three degrees of risk indicate that safety is involved. Observe precautions indicated whenever you see the Safety Alert "Triangle," no matter which signal word appears next to the "Exclamation Point" symbol.



### CAUTION!

**Indicates potential of a hazardous situation that, if not avoided, could result in minor or moderate injury. It may also be used to alert against a generally unsafe practice.**



### WARNING!

**Indicates potential of a hazardous situation that, if not avoided, could result in serious injury or death. It may also be used to alert against a highly unsafe practice.**



### DANGER!

**Indicates imminent hazard of a situation that, if not avoided, is very likely to cause death or extremely serious injury. It may also be used to alert against equipment that may explode or detonate if handled or treated carelessly.**

Safety precautions are described in SAFETY from page -8 on.

Daewoo cannot predict every circumstance that might involve a potential hazard in operation and maintenance. Therefore the safety messages in this manual and on the machine may not include all possible safety precautions. If any procedures or actions not specifically recommended or allowed in this manual are used, you must be sure that you and others can do such procedures and actions safely and without damaging the machine. If you are unsure about the safety of some procedures, contact a DAEWOO distributor.

# GENERAL SAFETY ESSENTIALS

## ACCESSORY APPLICATIONS

The excavator has been primarily designed for moving earth with a bucket. For use as a grapple or for other object handling, contact Daewoo for proper installation and application. Lifting-work applications (unless restricted or prohibited by local regulations) are permitted in approved lift configuration, to rated capacity only, with no side-loading. Do not use the machine for activities for which it was not intended. Do not use the bucket for lifting work, unless lift slings are used in the approved configuration.

Use of an accessory hydraulic hammer (breaker), work in rough terrain, demolition applications or other hazardous operation may require installation of additional protective structures to safeguard the operator.

## LIFTING CAPACITY RATING CONFIGURATION

Lifting capacity ratings that are printed at the end of this safety section are based on the machine being level, on a firm supporting surface, with hooks and slings attached in approved configuration. Loads must be balanced and supported evenly. Use taglines to keep the load steady if wind conditions and large surface area are a problem. Work crew hand signals, individual tasks and safe procedures should all be universally understood before the lift is made.

## IMPORTANT

**Before using the excavator to make lifts check municipal and regional regulations or statutes that could apply. Governing ordinances may require that all heavy lifting be done with single purpose equipment specifically designed for making lifts, or other local restrictions may apply. Making heavy lifts with a general purpose excavator that can be used for digging, loading, grading or other work may be expressly forbidden by a regional injunction or other legal prohibition. Always follow all of the other instructions, guidelines and restrictions for Safe Lifting in the Operation and Maintenance Manuals.**

## LOCATION OF SAFETY LABELS

Location of safety labels (decals) can vary from unit to unit. Refer to appropriate Operation and Maintenance Manual, and parts manual for your unit.

Always replace damaged or faded decals.

# SUMMARY OF SAFETY PRECAUTIONS FOR LIFTING IN DIGGING MODE



## DANGER!

**Unsafe use of the excavator while making rated lifts could cause serious, potentially fatal injuries or extensive damage to the machine or nearby property. Do not let anyone operate the machine unless they've been properly trained and understand the information in the Operation and Maintenance Manual.**

To lift safely while in Digging Mode, the following items must be evaluated by the operator and the work site crew.

- Condition of ground support.
- Excavator configuration and attachments.
- Weight, lifting height and lifting radius.
- Safe rigging of the load.
- Proper handling of the suspended load.

Taglines on opposite sides of the load can be very helpful in keeping a suspended load secure, if they are anchored safely to control points on the ground.



## WARNING!

**NEVER wrap a tagline around your hands or body.**

**NEVER rely on taglines or make rated lifts when wind gusts are more than 48.3 km/h (30 MPH). Be prepared for any type of wind gust when working with loads that have a large surface area.**

Always engage the "Digging Mode" control on the Instrument Panel before using the excavator for lifting work.



## WARNING!

**If you need more information or have any questions or concerns about safe operating procedures or working the excavator correctly in a particular application or in the specific conditions of your individual operating environment, please consult your local Daewoo representative.**

# UNAUTHORIZED MODIFICATIONS

Any modification made without authorization or written approval from Daewoo can create a safety hazard, for which the machine owner must be held responsible.

For safety's sake, replace all OEM parts with the correct authorized or genuine Daewoo part. For example, not taking the time to replace fasteners, bolts or nuts with the correct replacement parts could lead to a condition in which the safety of critical assemblies is dangerously compromised.

## GENERAL HAZARD INFORMATION

### SAFETY RULES

Only trained and authorized personnel can operate and maintain the machine.

Follow all safety rules, precautions and instructions when operating or performing maintenance on the machine.

Do not operate the machine if you are not feeling well, if you are taking medication that makes you feel sleepy, if you have been drinking, or if you are suffering from emotional problems. These problems will interfere with your sense of judgement in emergencies and may cause accidents.

When working with another operator or with a person on work site traffic duty, be sure that all personnel know the nature of the work and understand all hand signals that are to be used.

Always observe strictly any other rules related to safety.

### SAFETY FEATURES

Be sure that all guards and covers are installed in their proper position. Have guards and covers repaired immediately if damaged.

Be sure that you understand the method of use of safety features such as safety lock lever and the seat belt, and use them properly.

Never remove any safety features. Always keep them in good operating condition.

Failure to use safety features according to the instructions in the Operation and Maintenance Manual could result in serious bodily injury.

**Buy Now**



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)