

# **234 & 234-Hydro Tractors**

## **Operators Manual**

**1258522C3**

Reprinted

**CASE III**



***This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.***

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
2. MAKE SURE THE OPERATOR READS AND UNDERSTANDS THE OPERATOR'S MANUAL FOR THIS MACHINE.



**IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH.**

BEFORE STARTING THE ENGINE, DO THE FOLLOWING:

1. READ THE OPERATOR'S MANUAL.
2. READ ALL SAFETY DECALS ON THE MACHINE.
3. CLEAR THE AREA OF OTHER PERSONS.

LEARN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, CLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

# To The Owner

Before you operate the tractor, study this manual carefully. It has been prepared to help you operate and maintain your tractor with utmost efficiency.

**BE SURE THIS OPERATORS MANUAL IS KEPT WITH THIS MACHINE AT ALL TIMES, REGARDLESS OF OWNERSHIP.**



This symbol is used to call your attention to instructions concerning your personal safety. Be sure to observe and follow these instructions.

Assembled in this manual are operation, lubrication and maintenance instructions for the International 234 and Hydro 234 tractors. This material has been prepared in detail in the hope that it will help you to better understand the correct care and efficient operation of your new tractor.

For prompt, efficient service, always specify the tractor model and serial numbers, including prefix and suffix letters. Write these serial numbers in the spaces provided under "Serial Numbers".

Your new International Harvester tractor is designed to meet today's exacting operating requirement. The ease and comfort of operation, the ability to match ground speeds to engine power and work requirement, and the effortless versatility of the hydraulic system are intended to lighten your work and shorten your hours on the job.

Your local International Harvester dealer is interested in the performance you receive from these tractors. He has factory-trained servicemen, informed in the latest method of servicing tractors, modern tools, and original-equipment IH service parts which assure proper fit and good performance.

To obtain top performance and assure economical operation, the tractor should be inspected, depending on its use, periodically, or at least once a year by your International Harvester Dealer.



Universal symbols are used to pictorially identify various tractor instruments and controls. Throughout this manual, an identifying symbol is placed by the instructions like this example for engine coolant temperature. The waves signify water or coolant and the thermometer indicates temperature. Regardless of the language used in a nation, and without translation, this symbol means water or coolant temperature.

**NOTE:** The nuts and bolts are "Metric" sizes. Be careful to use the correct sizes and thread pitch when replacing them. Be sure to use the proper size tools.

Optional equipment and accessories are available. Disregard the instructions for equipment not on your tractor.

## METRIC (SI) MEASUREMENTS

A standard of metric measurement known as International System of Units (SI) has been adopted for world-wide use. English Units followed by Metric Equivalents are used throughout this manual. (Metric Equivalents are given in parenthesis.)



MM-1001

# CONTENTS

TO THE OWNER .....	Inside Front Cover		
SERIAL NUMBERS .....	4		
TERMS OF LOCATION .....	5		
WORK SAFELY – FOLLOW THESE RULES .....	6-9		
Servicing and Before Starting .....	6		
Starting .....	7		
During Operation .....	7		
Transporting .....	7		
Tractors without ROPS .....	8		
Before Dismounting .....	8		
Dismounting .....	8		
After an Upset .....	8		
Product Graphics .....	9		
ENERGY CONSERVATION – FOLLOW THESE RECOMMENDATION .....	10-11		
INSTRUMENT AND CONTROLS .....	12-20		
Instrument Panel and Controls .....	12-13		
Brake Pedals .....	14		
Brake Latch .....	14		
Clutch Pedal .....	14		
Differential Lock Pedal .....	14		
Hydraulic Flow Control .....	15		
Engine Speed Control Lever (gear drive) ..	15		
Engine Speed Control Lever (Hydrostatic drive) ..	15		
Foot throttle Control (gear drive).....	15		
Combination Flash and Turn Signal Switch .....	16		
Tachometer and Hourmeter .....	16		
Fuse Block .....	16		
Fuel Gauge .....	16		
Tellites .....	17		
Charge Indicator Tellite .....	17		
Engine Oil Pressure Tellite .....	17		
Engine Coolant Temperature Tellite ....	17		
Engine Glow Plug Indicator .....	17,18		
Lighting Switch .....	18		
Starting Switch Key .....	18		
Gear Shift Lever (gear drive).....	19		
Power Take-off Lever .....	19		
Hydraulic Control Lever .....	19		
Transmission Range Lever .....	19		
Park Brake Lever .....	20		
Seat .....	20		
OPTIONAL INSTRUMENT AND CONTROLS.....	21		
Speed Ratio Control (Hydrostatic drive) .....	21		
Rear Work Lamp .....	21		
All-Wheel Drive .....	21		
BEFORE OPERATING YOUR TRACTOR .....	22		
OPERATING THE TRACTOR .....	22-26		
Neutral Starting Switch .....	22		
Starting the Engine .....	22,23		
Tractor Break-in Procedure .....	23		
With the Engine Running .....	24		
Stopping the Engine .....	24		
Steering the Tractor .....	24		
Driving the Tractor (gear drive) .....	24,25		
Selecting Ground Speeds(gear drive) .....	25		
Stopping the Tractor(gear drive) .....	25		
Driving the Tractor (Hydrostatic drive)..	25		
Selecting Ground Speeds (Hydrostatic drive) .....	25,26		
Stopping the Tractor (Hydrostatic drive) .....	26		
Towing the Tractor .....	26		
ENGINE AND FUEL SYSTEM .....	27-29		
Warranty Notice .....	28		
Fuel System .....	28,29		
Fuel Injection Pump and Nozzles.....	29		
COOLING SYSTEM .....	30,31		
Coolants and Cooling System Conditioner .....	30		
Checking the Coolant Level .....	30		
Draining the Cooling System .....	31		
Filling the Cooling System .....	31		
Hoses and Clamps .....	31		
Thermostat .....	31		
Cleaning the Radiator .....	31		
Water Pump, Alternator- Generator and Fan Belt Tension .....	31		

## CONTENTES

<b>AIR CLEANER SYSTEM</b> .....	<b>32</b>	<b>POWER TAKE-OFF</b> .....	<b>45</b>
General Precautions .....	32	Rear Power Take-off .....	45
Removing the Dust Pan and Air Filter Element .....	32	Front Power Take-off Drive .....	45
Inspection .....	32		
<b>ELECTRICAL SYSTEM</b> .....	<b>33-37</b>	<b>ALL-WHEEL DRIVE</b> .....	<b>46</b>
Charging System for Alternator- Generator .....	33	<b>DIFFERENTIAL LOCK</b> .....	<b>46</b>
Cranking System .....	33	<b>FRONT WHEELS</b> .....	<b>47</b>
Lighting System .....	33	<b>REAR WHEELS</b> .....	<b>48</b>
Lights .....	33,34	Reversing the Rear Wheels .....	48
Tellites .....	34	<b>TIRES</b> .....	<b>49,50</b>
Turn Signal Indicators .....	34	Inflation .....	49
Warning Lights .....	34	Front Tires .....	50
Fuse .....	34	Rear Tires .....	50
Batteries .....	35	<b>WEIGHTS</b> .....	<b>51-53</b>
Electrical Connector .....	36	Rear Wheel Weights .....	51
Wiring Schematic .....	37	Front End Weights .....	51
		All-Wheel Drive Tractors .....	52
<b>HYDRAULIC CONTROLS FOR THREE-POINT HITCH</b> .....	<b>38</b>	Weight Table .....	53
Hydraulic Control Lever .....	38	<b>COLD WEATHER PRECAUTIONS</b> .....	<b>54</b>
Hitch Drop Rate Adjustment and Lock .....	38	Fuel System .....	54
		Electrical .....	54
<b>THREE-POINT HITACH</b> .....	<b>39-41</b>	Lubrication .....	54
Lift Links and Turnbuckles .....	39	Cooling System .....	54
Hitch Upper Link .....	39	<b>STORING THE TRACTOR</b> .....	<b>54,55</b>
Stabilizer Chain .....	40	Storage .....	54
Coupling the Equipment .....	40,41	Removing From Storage .....	54,55
Uncoupling the Equipment .....	41		
<b>HITCHING TRAILING EQUIPMENT TO THE TRACTOR</b> ...	<b>42,43</b>		
Safety Chain .....	42,43		
<b>REMOTE CYLINDERS AND HYDRAULIC OUTLETS</b> .....	<b>44</b>		
Adding Fluid After Connecting Cylinders and Hoses .....	44		

## CONTENTS

<b>LUBRICATION .....</b>	<b>56-59</b>
Engine Oil .....	56
Transmission Lubricant .....	56,57
Lubrication Fitting Grease .....	57
Engine Oil Filter .....	57
Hydraulic Fluid Filter .....	57,58
Hydrostatic Drive Housing Hydraulic Fluid Filter .....	58
Lubricating the Front Wheels and Axle (Two Wheel Drive).....	58
Lubricating the Front Axle (Four Wheel Drive) .....	59
<b>LUBRICATION TABLE .....</b>	<b>60</b>
<b>LUBRICATION GUIDE .....</b>	<b>61-65</b>
<b>PREVENTIVE MAINTENANCE GUIDE .....</b>	<b>66,67</b>
<b>SPECIFICATIONS .....</b>	<b>68-72</b>
<b>OPTIONAL EQUIPMENT .....</b>	<b>73</b>
<b>METRIC (SI) MEASUREMENTS UNITS .....</b>	<b>Inside Back Cover</b>

**Buy Now**



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)