

ORIGINAL INSTRUCTIONS

OPERATOR'S MANUAL

T7030

T7040

T7050

T7060

T7070

Sidewinder II

Auto Command and Power Command

Transmission - Tractor

Part number 47789321

4th edition English

January 2015

Replaces part number 47623319



Contents

1 GENERAL INFORMATION

Metric and imperial units abbreviations.....	1-1
To the owner.....	1-3
Product identification.....	1-5
Engine identification.....	1-6
Drive line identification.....	1-7
Drive line identification.....	1-7
Cab identification.....	1-8
Product identification plate.....	1-8
Ecology and the environment.....	1-9
Programming tractor functions.....	1-10
Before operating the tractor.....	1-11
International symbols.....	1-12
Machine stability.....	1-13
Instructor's seat.....	1-17

2 SAFETY INFORMATION

Safety precautions.....	2-1
Safety decals.....	2-3
Safety rules.....	2-11
Fire extinguisher.....	2-18
Protection offered by the tractor.....	2-19
Intended use statement.....	2-22

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Cab access/exit.....	3-1
Cab - Localization overview.....	3-5
Cab air filters.....	3-7
In cab storage (where applicable).....	3-8
Cable routing.....	3-9
Mobile phone.....	3-9
Monitor installation.....	3-9
Cab air pressurisation control (where fitted).....	3-10

OPERATOR'S SEAT

Air suspension seat.....	3-12
Air suspension seat deluxe.....	3-14
Armrest control.....	3-19
Seat belt.....	3-20

INSTRUCTOR'S SEAT

Instructor's seat.....	3-21
------------------------	------

FORWARD CONTROLS

Key start switch.....	3-22
Hazard warning light operation.....	3-22
Light's and turn indicator lever.....	3-23
Follow me home light's.....	3-23
Windshield wiper and washer controls.....	3-24
Electronic parking brake.....	3-25
Foot brakes.....	3-29
Exhaust brake where fitted.....	3-30
Steering column.....	3-31
Adjustable air vents.....	3-31

LEFT-HAND SIDE CONTROLS

Handbrake.....	3-32
----------------	------

RIGHT-HAND SIDE CONTROLS

Integrated control panel.....	3-33
Integrated control panel.....	3-34
Hand throttle lever.....	3-35
Multi function handle.....	3-35

REARWARD CONTROLS

Switches.....	3-36
Hydraulic master switch.....	3-37
Heated screens (where fitted).....	3-38
Fast steering system (where fitted).....	3-39
Battery isolator switch (where fitted).....	3-41
Climate controls.....	3-42
Manual temperature control.....	3-44
Automatic temperature control.....	3-45

OVERHEAD CONTROLS

Switch panel work lights.....	3-47
Radio or audio system.....	3-48
Interior light.....	3-49

INSTRUMENT CLUSTER

Analogue digital instrument cluster.....	3-50
Gauges.....	3-50
Indicator and warning lights.....	3-51
Displays.....	3-53
Keypad enhanced.....	3-55
Display settings.....	3-57
Ground speed calibration.....	3-58
Performance monitor.....	3-61
Armrest display.....	3-68
Color display.....	3-70
Performance monitor.....	3-76

Display programming	3-79
Error code access	3-82
Warning and advisory symbols	3-83

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Refueling the tractor	4-1
-----------------------------	-----

STARTING THE UNIT

Starting the engine	4-2
Grid heater cold start aid (where fitted)	4-3
Fuel heater (where fitted)	4-4
Coolant immersion heater (where fitted)	4-4
Transmission oil heater (where fitted)	4-5
Transmission - Operating Cold weather	4-6
Booster battery procedure	4-7

STOPPING THE UNIT

Engine shutdown	4-8
Engine automatic shutdown	4-8

MOVING THE UNIT

Operating in cold temperatures	4-9
Engine fan reversal	4-11

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

Tractor transporting	5-1
Roof panel securing	5-1

RECOVERY TRANSPORT

Towing the tractor	5-2
--------------------------	-----

6 WORKING OPERATIONS

GENERAL INFORMATION

Engine power management	6-1
Engine constant speed	6-3
Differential lock	6-7
Four wheel drive	6-9
Front axle suspension (where fitted)	6-11
Automated headland functions	6-13
Headland turn sequence symbols HTS Quick reference	6-15
Record and replay	6-17
Universal symbols	6-21
Recording a sequence	6-22

Record and replay	6-24
Colour display screens	6-28
Colour display screens	6-31

TRANSMISSION

Full powershift transmission	6-32
Clutch pedal	6-32
Foot throttle pedal	6-32
Transmission operation	6-33
Powershift transmission controls	6-34
Transmission display	6-35
Driving the tractor	6-36
Auto shift function	6-38
Speed matching	6-42
Setting the forward and reverse gear ratios	6-43
Creeper gears	6-44
Viewing error codes	6-45
Ground speed Ground speeds	6-46
Continuously Variable Transmission (CVT) operation	6-51
Transmission operation	6-51
Anti jack knife	6-52
Stationary control	6-53
Engine speed control	6-54
CVT transmission controls	6-55
CVT transmission controls	6-57
Drive pedal	6-59
Speed setup	6-60
Transmission display	6-62
Manual mode	6-64
Automatic mode	6-65
Cruise mode	6-67
Two speed PTO systems	6-70
Speed matching	6-70
Viewing error codes	6-71

REAR POWER TAKE-OFF

PTO operation	6-72
PTO interchangeable shaft	6-72
Power Take-off (PTO) Connection	6-73
PTO operation	6-74
PTO 2 speed system	6-79
PTO shiftable multi speed	6-81
PTO electronic Electronic (where fitted)	6-84
PTO external controls	6-85
PTO automatic system	6-87

FRONT POWER TAKE OFF

PTO operation	6-90
PTO automatic system	6-92

REAR HITCH

Draft control electronic	6-94
Three-point hitch	6-98
Electronic Draft Control (EDC) operation	6-100
External hitch controls	6-105

FRONT HITCH

Front hitch	6-107
Front hitch operation	6-110
Auxiliary front couplers (where fitted)	6-116
External hitch controls	6-118

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

Remote control valves	6-119
Remote control valves	6-126
Remote control valve operation	6-131
Remote control valve operation	6-138
Remote control valve operation	6-140
Joystick operation	6-142
Mid mount control valve	6-148
Remote valve controls	6-149
Hydraulic oil level	6-150

HYDRAULIC POWER BEYOND PORT

HYDRAULIC POWER BEYOND PORT FOR EXTERNAL SERVICES	6-152
Power beyond circuit	6-152
Power beyond circuit	6-154

THREE POINT HITCH

Three-point hitch	6-155
Lift rods	6-157
Top link	6-160
Lower links	6-162
Quick hitch	6-163
Lower links	6-165

DRAWBARS AND TOWING ATTACHMENTS

Drawbars and towing attachments	6-169
Drawbars and towing attachments	6-171
Automatic pickup hitch	6-175
Automatic pickup hitch	6-181
Rear tow hitch	6-185

TRAILER BRAKING SYSTEMS

Trailer brakes air operated	6-191
Trailer brakes air operated (Italy only)	6-195
Trailer brake bias control	6-196
Trailer brakes air operated	6-196

Trailer brakes hydraulic operated	6-197
Trailer brakes hydraulic operated (Italy only).....	6-199

WHEEL TRACK ADJUSTMENT

Front wheel track adjustment.....	6-200
Front wheel alignment	6-204
Steering stops	6-205
Front axle	6-205
Front wheel fenders	6-206
Rear wheel track adjustment	6-208
Flange type axle (where fitted) Flange type	6-208
Bar type axle (where fitted) Bar type	6-212
Dual rear wheels (where fitted) Dual wheels	6-218

BALLASTING AND TIRES

Tires and wheels ballast.....	6-221
Tires and wheels ballast.....	6-224
Tires and wheels ballast.....	6-226
Front wheels.....	6-228
Front wheels.....	6-229

AUXILIARY POWER CONNECTIONS

Diagnostic socket.....	6-231
Trailer electrical socket	6-231
Internal power connectors.....	6-232
External power connectors	6-234

7 MAINTENANCE

GENERAL INFORMATION

Introduction	7-1
Diesel fuel	7-2
Biodiesel fuel	7-3
Engine oil	7-5
Protective devices	7-6
Fluids and lubricants	7-8
Tractor jacking points.....	7-10
Specifications.....	7-11
Capacities	7-12
Organic Acid Technology (OAT) coolant.....	7-13

MAINTENANCE CHART

Maintenance chart.....	7-14
------------------------	------

WHEN THE WARNING LAMP LIGHTS

Air cleaner	7-16
Fuel filter.....	7-17

EVERY 10 HOURS OR EACH DAY

Engine coolant.....	7-18
---------------------	------

Engine oil	7-19
Remote control valves.....	7-19
Windscreen wash wipe	7-20
Trailer brakes air operated	7-20

FIRST 50 HOURS

Service schedule	7-21
------------------------	------

EVERY 50 HOURS

Cab air filters	7-22
Engine and hydraulic coolers.....	7-24
Grease fittings	7-25
Wheel and axle torques	7-33
Tire pressure and condition.....	7-33

EVERY 100 HOURS

Drive belts	7-34
Drive belts	7-34

EVERY 300 HOURS

Battery check	7-35
Transmission and hydraulic oil	7-37
Handbrake.....	7-38
PTO Gearbox.....	7-38
Engine gearbox - Check.....	7-38
Front axle.....	7-39

EVERY 600 HOURS

Engine oil and filter	7-40
Fuel filters	7-42
Air cleaner elements.....	7-44
Transmission / hydraulic oil filters	7-45
Engine air intake hoses.....	7-46
Transmission	7-47

EVERY 1200 HOURS OR ANNUALLY

Cab air filters	7-48
Transmission / hydraulic oil filters	7-50
Transmission and hydraulic fluid-change	7-52
Differential oil	7-54
Differential oil	7-55
Front axle (4WD) - oil change	7-56
PTO gearbox (if equipped)	7-56
PTO gearbox (if equipped)	7-57
Rear axle	7-58

EVERY 1200 HOURS OR EVERY 2 YEARS

Battery	7-59
---------------	------

Engine air cleaner	7-61
Engine valve adjustment	7-62
Change the engine coolant fluid - Conventional type coolant	7-63
Trailer brakes air operated	7-68
Drive belts	7-69

EVERY 1800 HOURS OR EVERY 2 YEARS

Engine breather filter	7-70
------------------------------	------

EVERY 3600 HOURS OR EVERY 4 YEARS

Change the engine coolant fluid - OAT type coolant	7-71
--	------

EVERY 36 MONTHS

Air conditioning	7-76
------------------------	------

GENERAL MAINTENANCE

Cleaning the tractor.....	7-77
Battery	7-78
Fuel system.....	7-80
Fuel system.....	7-81
Brake pedals	7-82
Cab suspension, if equipped	7-83
Adjust the automatic pickup hitch	7-84
Adjust the automatic pickup hitch	7-85
Transmission clutch calibration.....	7-86
Transmission clutch calibration.....	7-87
Lighting system.....	7-92
Lighting system.....	7-93
Fuses and relays	7-97
Electrical / Electronic	7-102
Battery.....	7-103

STORAGE

Tractor storage	7-105
Storage up after	7-106

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Introduction	8-1
--------------------	-----

ALARM(S)

Electronic fault codes.....	8-2
-----------------------------	-----

SYMPTOM(S)

Engine	8-4
Transmission	8-5

Hydraulics	8-5
Three-point hitch	8-6
Brakes	8-6
Cab	8-6
Electrical system	8-7

9 SPECIFICATIONS

GENERAL DIMENSIONS	9-1
Specifications	9-1
Capacities	9-4
Transmission - Capacity	9-4
Front axle system - Capacity	9-4
Engine	9-5
Transmission	9-6
Two speed PTO systems	9-7
Front Power Take-Off (PTO)	9-7
Hydraulic system	9-8
Three-point hitch	9-12
Remote control valves	9-13
Three-point hitch front	9-13
Brakes	9-14
Steering	9-14
Electrical equipment	9-15
Tightening torques	9-16

10 ACCESSORIES

Rear view mirrors	10-1
Lighting system	10-3
Roof beacon	10-4
Front loader support	10-5

11 FORMS AND DECLARATIONS

Service record 1st 50 hour, Owner copy	11-3
Service record 1st 50 hour, Dealer copy	11-5

1 - GENERAL INFORMATION

Metric and imperial units abbreviations

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Area (Land area)				
	hectare	ha	acre	ac
	square meter	m ²	square foot	ft ²
			square inch	in ²
	square millimeter	mm ²	square inch	in ²
Electricity				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	μF	microfarad	μF
	ohm	Ω	ohm	Ω
Force				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
Force per length				
	newton per meter	N/m	pound per foot	lb/ft
			pound per inch	lb/in
Frequency				
	megahertz	MHz	megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
Frequency - Rotational				
	revolution per minute	r/min	revolution per minute	r/min ^a
		rpm		rpm
Length				
	kilometer	km	mile	mi
	meter	m	foot	ft
	centimeter	cm	inch	in
	millimeter	mm	inch	in
	micrometer	μm		
Mass				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		
Mass per mass				
	milligram per kilogram	mg/ kg	parts per million	ppm
Power				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu per hour	Btu/hr
			Btu per minute	Btu/min
Pressure or stress (Force per area)				
	kilopascal	kPa	pound per square inch	psi
			inch of mercury	inHg
	pascal	Pa	inch of water	inH ₂ O
	megapascal	MPa	pound per square inch	psi
	millibar	mbar		
	bar	bar		

1 - GENERAL INFORMATION

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Temperature (other than thermodynamic)				
	degrees Celsius	°C	degrees Fahrenheit	°F
Time				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
Torque (includes bending moment, moment of force, and moment of a couple)				
	newton meter	N m	pound foot	lb ft
			pound foot	lb in
Velocity				
	kilometer per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimeter per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
Volume (includes capacity)				
	cubic meter	m ³	cubic yard	yd ³
				cu yd
	liter	l	cubic inch	in ³
	liter	l	US gallon	US gal
			UK gallon	UK gal
			US quart	US qt
			UK quart	UK qt
	milliliter	ml	fluid ounce	fl oz
Volume per time (includes discharge and flow rate)				
	cubic meter per minute	m ³ /min	cubic foot per minute	ft ³ /min
	liter per minute	l/min	US gallon per minute	US gal/min
	milliliter per minute	ml/min	UK gallon per minute	UK gal/min
Sound power level and sound pressure level				
	decibel	dB	decibel	dB
Water hardness				
	German hardness	°dH	English hardness	°e
	French hardness	°fH	parts per million	ppm

Glossary

Acronym	Definition
DEF	Diesel Exhaust Fluid
ISO	International Organization for Standardization
MSDS	Material Safety Data Sheet
NOx	Nitrogen Oxide
PPE	Personal Protective Equipment
SCR	Selective Catalytic Reduction
ULSD	Ultra Low Sulfur Diesel
%	Percent
<	Less than
>	Greater than

To the owner

GENERAL INFORMATION

This Manual has been prepared to assist you in the correct procedure for running- in, driving and operating and for the maintenance of your new tractor. Read this Manual carefully. Your tractor is intended for use in normal and customary agricultural applications.

If at any time you require advice concerning your tractor, do not hesitate to contact your authorised dealer. He has factory trained personnel, genuine manufacturers' parts and the necessary equipment to carry out all your service requirements.

The specification are provided for your information and guidance. For further information concerning your tractor and equipment, consult your authorised dealer.

All data given in this manual is subject to production variations. Dimensions and weight are approximate only. The illustrations do not necessarily show tractors in standard condition or imply that these features are available in all countries. For exact information about any particular tractor, please consult your authorised dealer.

Your tractor has been designed and built to give maximum performance, economy and ease of operation under a wide variety of operating conditions. Prior to delivery, the tractor was carefully inspected, both at the factory and by your dealer to ensure that it reaches you in optimum condition. To maintain this condition and ensure trouble-free operation, it is important that the routine services, as specified in Maintenance of this Manual, are carried out at the recommended intervals.

ABOUT THIS MANUAL

This manual gives information for use of your machine, as intended and under the conditions foreseen by the manufacturer during normal operation and routine service and maintenance.

Read and understand; keep it in good condition and always safely store it in the provided pocket in the back of your seat for later easy retrieval.

This manual does not contain all the information related to periodical service, converting and repairs to be carried out by professional service personnel.

The Table of Contents page(s) are provided to have an overview of main manual's topics. A detailed alphabetic index is available at the end of this manual for locating specific items.

Normal operation

- Normal operation means the use of the tractor for the purpose intended by the manufacturer by an operator familiar with the tractor and the mounted or towed equipment and complying with the information for op-

eration and safe practices, as specified by the manufacturer in this manual and by the decals on the tractor and the equipment.

- Normal operation includes the preparation and storage of the tractor, swinging components into work position and vice versa, adding or removing ballast and picking up and setting off attachments.
- Normal operation includes the adjustment and setting of the tractor and equipment, for the specific condition of the field and/ or the crop.

Routine service

- Routine service and maintenance means activities that must be done daily by an operator familiar with the tractor characteristics and complying with the information for routine service and safe practices, as specified by the manufacturer in this manual and by decals on the tractor, in order to maintain its proper function. Routine service includes activities such as fueling, cleaning, washing, topping up fluid levels, greasing, replacing of consumable articles such as lamp bulbs.

Converting, periodical service and repair

- Periodical service means activities that must be done at defined intervals by trained personnel familiar with the tractor characteristics and which are complying with the information for periodical service and safe practices, as partly specified by the manufacturer in this manual and in other Company literature, in order to maintain the expected life time of the tractor.
- Converting means activities that must be done by professional service personnel familiar with the tractor characteristics and complying with the information for converting, as partly specified by the manufacturer in this manual, in assembly instructions or in other Company literature, in order to fit the tractor to a specific configuration.
- Repair means activities that must be done by professional service personnel only familiar with the tractor characteristics and complying with the information for repair, as specified by the manufacturer in the dealer's workshop manual, in order to restore the proper function of the tractor after a failure or degradation of performance.

CLEANING THE TRACTOR

Your tractor is a state- of- the- art machine with sophisticated, electronic controls. This should be taken into consideration when cleaning the tractor, particularly if using a high pressure washer. Even though every precaution has been taken to safeguard electronic components and connections, the pressure generated by some of these machines is such that complete protection against water ingress cannot be guaranteed.

When using a high pressure washer, do not stand too close to the tractor and avoid directing the jet at electronic components, electrical connections, breathers, seals, filler caps, etc. Never direct a cold water jet at a hot engine or exhaust.

Failure to comply with these rules will render the warranty null and void.

SAFETY

The pages in Section 2 list the precautions to be observed to ensure your safety and the safety of others. Read the safety precautions and follow the advice offered before operating the tractor.

FIRST 50 HOUR SERVICE

In Section 11, at the back of this Manual, you will find the 50- hour service reports.

NOTICE: *It is important the 50 hour service is carried out as recommended to ensure your tractor provides optimum performance and efficiency.*

After you have operated the tractor for 50 hours, take your tractor, together with this Manual, to your dealer. He will then perform the factory recommended 50 hour service and complete the service report sheets. The first sheet (page) is your copy of the service performed. The second sheet (page) is the dealer's copy and should be removed by the dealer after the service has been carried out. Ensure that you and the dealer sign both copies.

SERVICE PARTS

It should be pointed out that genuine parts have been examined and approved by the Company. The installation and/ or use of 'non- genuine' products could have negative effects upon the design characteristics of your tractor and thereby affect it's safety. The Company is not liable for any damage caused by the use of 'non- genuine' parts and accessories. Only genuine replacement parts should be used. The use of non- genuine parts may invalidate legal approvals associated with this product.

It is prohibited to carry out any modifications to the tractor unless specifically authorised, in writing, by the After Sales Service department of the Company.

WARRANTY

Your tractor is warranted according to legal rights in your country and the contractual agreement with the selling dealer. No warranty shall, however, apply if the tractor has not been used, adjusted and maintained according to the instructions given in the Operator's Manual.

USE OF BIODIESEL FUELS

NOTICE: *Before using Biodiesel fuels in your tractor, refer to the information on page regarding the storage and use of Bio diesel fuels.*

EMISSION CONTROLS

NOTE: *The engine and fuel system on your machine is designed and built to government emissions standards. Tampering by dealers, customers, operators and users is strictly prohibited by law. Failure to comply could result in government fines, rework charges, invalid warranty, legal action and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!*

ELECTRO MAGNETIC INTERFERENCE (EMC)

This tractor complies strictly with the European regulations on electro magnetic emissions. However, interference may arise as a result of add on equipment which may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- Ensure that each piece of non New Holland equipment fitted to the tractor bears the CE mark.
- The maximum power of emission equipment (radio, telephones, etc,) must not exceed the limits imposed by the national authorities of the country where you use the tractor.
- The electro magnetic field generated by the add on system should not exceed **24 V/m** at any time and at any location in the proximity of electronic components.

Failure to comply with these rules will render the New Holland warranty null and void.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com