

ORIGINAL INSTRUCTIONS - according to Regulation (EU) 2014/1322, Annex XXII

OPERATOR'S MANUAL

T7.230 AutoCommand™

T7.245 AutoCommand™

T7.260 AutoCommand™

T7.270 AutoCommand™

Tractor - STAGEV

*PIN HACT72***KD401001 and above*

Part number 51607733

2nd edition English

April 2019

Replaces part number 51453847



Contents

NOTE: The Operator's Manual consists of two volumes. The first volume contains operating information, the second volume the maintenance and diagnostic information.

1 GENERAL INFORMATION

Metric and imperial units abbreviations.....	1-1
To the owner.....	1-3
Electro-magnetic interference (EMC).....	1-5
Operator's manual storage.....	1-6
Product identification.....	1-7
Engine identification.....	1-8
Drive line identification.....	1-9
Cab identification.....	1-9
Product identification plate.....	1-10
Noise level information sheet.....	1-11
Programming tractor functions.....	1-12
Before operating the tractor.....	1-13
International symbols.....	1-14
Vibration level information sheet.....	1-15
Machine stability.....	1-16
Selective Catalytic Reduction (SCR) system.....	1-20

2 SAFETY INFORMATION

Safety precautions.....	2-1
Safety decals.....	2-3
Safety rules.....	2-12
Burn prevention.....	2-19
Prevention of fire or explosions.....	2-20
Fire extinguisher.....	2-21
Protection offered by the tractor.....	2-22
Ecology and the environment.....	2-25
Hazardous substances.....	2-26
Emergency exit.....	2-27
Wheel chocks.....	2-28
Intended use statement.....	2-29
Passenger's seat.....	2-31
Safety aspects in accordance with Regulation (EU) 1322/2014 - Annex XXII and subsequent amendments and modifications.....	2-32

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Introduction.....	3-1
Cab air filters.....	3-5
In cab storage (where fitted).....	3-6
Cable and wiring routing.....	3-7
Mobile telephone usage.....	3-7
Implement monitor installation.....	3-8

OPERATOR'S SEAT

Operator's seat	3-9
Air suspension seat deluxe	3-10
Air suspension seat with passive or Dynamic Damping System (DDS).....	3-15
Air suspension seat 'evolution active'	3-21
Seat belt	3-28

PASSENGER'S SEAT

Passenger seat	3-29
----------------------	------

FORWARD CONTROLS

Ignition key	3-30
Hazard lights switch	3-30
Lights and turn indicator lever	3-31
Follow me home lights.....	3-31
Windshield wiper and washer controls	3-32
Electronic parking brake.....	3-33
Anti-lock braking system ABS Operation	3-37
Clutch pedal	3-43
Foot brakes.....	3-43
Exhaust brake (where fitted)	3-47
Steering column	3-47

LEFT-HAND SIDE CONTROLS

Handbrake.....	3-48
----------------	------

RIGHT-HAND SIDE CONTROLS

Integrated control panel	3-49
Multifunction Handle	3-50

REARWARD CONTROLS

Switches on C-pillar	3-51
Battery isolator switch (where fitted)	3-52
Heated screens (where fitted)	3-53
ISO bus functionality	3-54
Hydraulic master switch	3-55
Switches on right-hand trim	3-56
Advanced Steering Control activation switch	3-57
Variable Ratio Steering (VRS).....	3-58
Autoguidance system.....	3-61
Autoguidance - Variable ratio steering.....	3-62
Variable ratio steering and Autoguidance symbols on color display (where fitted)....	3-63

OVERHEAD CONTROLS

Switch panel work lights.....	3-64
-------------------------------	------

Left-hand and right-hand outermost work light switch	3-65
Interior light	3-66
Climate controls	3-67
Manual temperature control	3-68
Automatic Temperature Control (ATC)	3-69

INSTRUMENT CLUSTER

Analog Digital Instrument Cluster (ADIC)	3-70
Gauges	3-71
Indicator and warning lights	3-72
Displays	3-74
Keypad enhanced	3-77
Selecting or changing the display settings	3-79
Active and Manual Catalyst Management	3-80
Manual Catalyst Management	3-82
Ground speed calibration	3-88
Performance monitor	3-91
Armrest color display	3-96
Pop-up screens on color display	3-99
Performance monitor on color display	3-104
Programming the displays	3-109
Alarm functions	3-112
Accessing stored error codes	3-114
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	3-115
Warning and advisory symbols	3-124
Warning and advisory symbols	3-138

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Refueling the tractor	4-1
-----------------------------	-----

STARTING THE UNIT

Starting the engine	4-3
Grid heater cold start aid (where fitted)	4-5
Fuel heater (where fitted)	4-5
Coolant immersion heater (where fitted)	4-6
Transmission oil heater (where fitted)	4-7
Boosting the battery	4-8

STOPPING THE UNIT

Stopping the engine	4-9
Automatic engine shut down with enhanced keypad (where fitted)	4-10

MOVING THE UNIT

Operating in cold temperatures	4-11
Low idle speed management	4-14
Reversible engine fan	4-15

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

Carrying the tractor on a transporter	5-1
Secure the high visibility roof panel	5-1

RECOVERY TRANSPORT

Freeing a stuck tractor.....	5-2
Towing the tractor.....	5-3

6 WORKING OPERATIONS

GENERAL INFORMATION

Variable engine power management	6-1
Constant engine speed.....	6-3
Differential lock	6-6
Four wheel drive.....	6-8
Front axle suspension (where fitted)	6-10
HTS standard.....	6-12
Headland turn sequence - Quick guide.....	6-12
Recording and replaying	6-14
Explanation of symbols.....	6-16
Recording a sequence	6-18
Replaying a sequence.....	6-20
HTS advanced.....	6-24
Headland turn sequence	6-24
Universal symbols	6-25
Recording a sequence	6-28
Creating a sequence in standstill.....	6-33
Replaying a sequence.....	6-35
Saving a sequence	6-39
Edit a sequence	6-42
Recalling a sequence.....	6-45
Deleting a sequence.....	6-49
Headland turn sequence error codes.....	6-50
HTS advanced with Automatic End Of Row Turn functionality.....	6-53
Automatic End Of Row Turn functionality	6-53
Implement setup.....	6-55
Creating field boundaries and headlands	6-56
Recording a sequence	6-60
Replaying a sequence.....	6-64

TRANSMISSION

CVT transmission operation.....	6-68
Transmission operation.....	6-68
Anti jack knife.....	6-69
Stationary control.....	6-71
Engine speed control	6-72
Shuttle lever	6-74

Transmission controls	6-76
Drive pedal	6-79
Programming maximum speed	6-80
Transmission display	6-82
Manual mode	6-84
Automatic mode	6-85
Cruise mode	6-87
PTO mode	6-90
Speed matching	6-90
Pneumatic Trailer Brake Stabilization System	6-91
Fault codes	6-93

REAR POWER TAKE-OFF (PTO)

Power Take-Off (PTO) operating precautions	6-94
Changing the PTO output shaft	6-95
Attaching PTO driven equipment	6-96
PTO operation	6-97
PTO shiftable multi speed	6-102
Electronic PTO displays Electronic (where fitted)	6-104
External PTO controls	6-105
Auto PTO operation	6-107

FRONT POWER TAKE OFF

PTO operation	6-110
Auto PTO operation	6-113

REAR HITCH

Electronic Draft Control (EDC)	6-115
Settings and adjustments	6-119
Electronic Draft Control (EDC) operation	6-121
External hitch controls	6-126

FRONT HITCH

Settings and adjustments	6-128
Front hitch operation	6-131
External hitch controls	6-137
Front hitch management	6-138
Auxiliary front couplers (where fitted)	6-143
External controls for front couplers	6-145

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

Remote control valves	6-146
Settings and adjustments	6-154
Valve priority	6-160
Programming tractor functions	6-161
Connecting remote cylinders	6-168
Operating with remote valves	6-171
Joystick operation with a front loader	6-173

Mid mount remote valves	6-178
EHR implement control setting	6-179
External EHR controls	6-183
Transmission rear axle and hydraulic system oil level	6-184

HYDRAULIC POWER BEYOND PORT

Power beyond circuit	6-186
Power beyond valve - Static description	6-186
ISO Power beyond couplings	6-188

THREE POINT HITCH

Attaching three-point hitch equipment	6-189
Lift rod adjustment	6-191
Top link adjustment	6-194
Quick hitch	6-196
Stabilizers	6-198

DRAWBARS AND TOWING ATTACHMENTS

Drawbars and towing attachments	6-202
Swinging drawbar	6-205
Automatic pickup hitch	6-208
Rear trailer hitches	6-212

TRAILER BRAKING SYSTEMS

Trailer brake release switch	6-219
Air-operated trailer brakes (Universal type)	6-220
Air-operated trailer brakes (UK type)	6-223
Air-operated trailer brakes (Italian type)	6-224
Auxiliary air supply connector (where fitted)	6-225
Hydraulic trailer brakes (Universal type - Dual line)	6-226
Hydraulic trailer brakes (Universal type - Single line)	6-229
Hydraulic trailer brakes (Italian type)	6-230

WHEEL TRACK ADJUSTMENT

Tire combinations	6-231
Front wheel track adjustment	6-233
Front wheel alignment	6-238
Steering stops	6-239
Front axle oscillation stops	6-240
Front wheel fenders	6-241
Rear wheel track adjustment	6-243
Flange type axle (where fitted)	6-243
Bar type axle (where fitted)	6-247
Dual rear wheels (where fitted)	6-253

BALLASTING AND TIRES

Ballasting and tires	6-257
----------------------------	-------

Iron weights (where fitted)	6-260
Liquid ballast	6-265
Tire inflation.....	6-267
Tire pressures and permissible loads	6-268

AUXILIARY POWER CONNECTIONS

Diagnostic socket.....	6-270
Trailer electrical socket	6-271
Electrical power connectors	6-272
Internal power connectors	6-272
External power connectors	6-274
ISO bus classes	6-276
ISO bus functionality	6-278
Reconfigurable inputs for ISO Bus function	6-286

7 MAINTENANCE

GENERAL INFORMATION

Introduction	7-1
Fuel requirement - Diesel fuel	7-2
Fuel - Storage, handling and transport	7-2
Biodiesel fuel	7-3
Engine oils.....	7-5
Protective devices	7-6
Tractor jacking points.....	7-8
General specifications	7-9
Capacities	7-10
Organic Acid Technology (OAT) coolant.....	7-11

MAINTENANCE CHART

Maintenance chart.....	7-12
------------------------	------

WHEN THE WARNING LAMP LIGHTS

Change the engine air cleaner outer element.....	7-14
Drain the fuel system water separator.....	7-15
Check the brake fluid level	7-16

EVERY 10 HOURS OR EACH DAY

Check the engine coolant level.....	7-17
Check the engine oil level	7-18
Check the remote control valve drain bottles.....	7-18
Check windscreen washer reservoir	7-19
Drain air reservoir on air operated trailer brake	7-19

FIRST 50 HOURS

Service operations.....	7-20
-------------------------	------

EVERY 50 HOURS

Clean the cab air filter	7-21
--------------------------------	------

Clean the SCR cover air ducts	7-23
Clean the cooler section.....	7-24
Grease all fittings	7-25
Check the front and the rear wheel nuts	7-32
Check the tire pressures and the tire condition.....	7-32

EVERY 150 HOURS

Inspect the compressor drive belt	7-33
---	------

EVERY 375 HOURS

Check the battery fluid level	7-34
Inspect the poly V-belt.....	7-36
Check the transmission oil level, the rear axle oil level and the hydraulic oil level	7-37
Adjust the hand brake	7-38
Check the front PTO gearbox oil level.....	7-38

EVERY 750 HOURS

Change engine oil and filter	7-39
Change the first stage fuel filter and the fuel filter element.....	7-41
Change the hydraulic charge pump oil filter and the transmission oil filter	7-43
Check the air intake system	7-44
Check the transmission oil cooler pipe couplings	7-45

EVERY 750 HOURS OR EVERY YEAR

Change the engine air cleaner outer element	7-46
---	------

EVERY 750 HOURS OR EVERY 2 YEARS

Change the 4WD planetary hub oil.....	7-46
---------------------------------------	------

EVERY YEAR

Check the accumulators (where fitted)	7-47
---	------

EVERY 1500 HOURS

Change the front PTO gearbox oil.....	7-48
---------------------------------------	------

EVERY 1500 HOURS OR EVERY YEAR

Change the cab air filters	7-48
----------------------------------	------

EVERY 1500 HOURS OR EVERY 2 YEARS

Change the Diesel Exhaust Fluid (DEF)/AdBlue® suction filter	7-50
Change the engine air cleaner inner element	7-51
Change the air brake drier reservoir.....	7-52
Change the transmission oil, the rear axle oil and the hydraulic oil	7-53
Change the hydraulic suction pump oil filter.....	7-54
Change the 4WD differential oil	7-55

Change the engine breather filter 7-56

EVERY 2 YEARS

Change the air conditioning receiver drier..... 7-57

EVERY 1500 HOURS OR EVERY 4 YEARS

Change the poly V-belts 7-58

EVERY 2250 HOURS

Check the engine tappet valve clearance 7-60

EVERY 3750 HOURS OR EVERY 3 YEARS

Change the DEF/AdBlue® main filter 7-61

EVERY 3750 HOURS OR EVERY 4 YEARS

Change the engine coolant fluid..... 7-62

GENERAL MAINTENANCE

Cleaning the tractor..... 7-66

Fuel system water separator 7-68

Bleeding the fuel system 7-68

Hydraulic system hoses 7-69

Electrical socket maintenance 7-70

Brake Pedal 7-71

Cab suspension, if equipped 7-72

Adjust the automatic pickup hitch 7-73

Headlight adjustment..... 7-74

Work light adjustment 7-74

Bulb replacement..... 7-75

Fuses and relays 7-77

Protecting the electronic and electrical systems during battery charging or welding.. 7-89

Battery removal and installation 7-90

STORAGE

Tractor storage 7-92

Removing the machine from storage..... 7-92

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Introduction 8-1

ALARM(S)

Fault codes and symbols 8-2

SYMPTOM(S)

Engine	8-4
Transmission	8-5
Hydraulics	8-6
Three-point hitch	8-6
Brakes	8-7
Cab	8-7
Electrical system	8-8

9 SPECIFICATIONS

General dimensions	9-1
General dimensions	9-1
Minimum turn radius	9-3
Axle dimension	9-4
Maximum permissible operating weights	9-5
Tractor weights	9-5
Capacities	9-6
Transmission - Capacity	9-6
Front axle system - Capacity	9-6
Engine	9-7
Transmission	9-8
Rear Power Take-Off (PTO)	9-9
Front Power Take-Off (PTO)	9-10
Hydraulic system	9-11
Three-point hitch	9-13
Remote control valves	9-13
Three-point hitch	9-13
Brakes	9-14
Steering	9-14
Electrical equipment	9-15
Minimum hardware tightening torques	9-16

10 ACCESSORIES

Radio (where fitted)	10-1
External rear view mirrors	10-2
Border marker plates	10-4
Auxiliary head lights and signature lights	10-5
Rotating beacon	10-5
Front-end loader fixation points	10-6

11 FORMS AND DECLARATIONS

Service record 1st 50 hour, Owner copy	11-1
Service record 1st 50 hour, Dealer copy	11-3
Telematics module declaration of conformity	11-4

1 - GENERAL INFORMATION

Metric and imperial units abbreviations

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Area (Land area)				
	hectare	ha	acre	ac
	square meter	m ²	square foot	ft ²
			square inch	in ²
	square millimeter	mm ²	square inch	in ²
Electricity				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	μF	microfarad	μF
	ohm	Ω	ohm	Ω
Force				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
Force per length				
	newton per meter	N/m	pound per foot	lb/ft
			pound per inch	lb/in
Frequency				
	megahertz	MHz	megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
Frequency - Rotational				
	revolution per minute	r/min	revolution per minute	r/min ^a
		rpm		rpm
Length				
	kilometer	km	mile	mi
	meter	m	foot	ft
	centimeter	cm	inch	in
	millimeter	mm	inch	in
	micrometer	μm		
Mass				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		
Mass per mass				
	milligram per kilogram	mg/ kg	parts per million	ppm
Power				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu per hour	Btu/hr
			Btu per minute	Btu/min
Pressure or stress (Force per area)				
	kilopascal	kPa	pound per square inch	psi
			inch of mercury	inHg
	pascal	Pa	inch of water	inH ₂ O
	megapascal	MPa	pound per square inch	psi
	millibar	mbar		
	bar	bar		

1 - GENERAL INFORMATION

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Temperature (other than thermodynamic)				
	degrees Celsius	°C	degrees Fahrenheit	°F
Time				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
Torque (includes bending moment, moment of force, and moment of a couple)				
	newton meter	N m	pound foot	lb ft
			pound foot	lb in
Velocity				
	kilometer per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimeter per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
Volume (includes capacity)				
	cubic meter	m ³	cubic yard	yd ³
				cu yd
	liter	l	cubic inch	in ³
	liter	l	US gallon	US gal
			UK gallon	UK gal
			US quart	US qt
			UK quart	UK qt
	milliliter	ml	fluid ounce	fl oz
Volume per time (includes discharge and flow rate)				
	cubic meter per minute	m ³ /min	cubic foot per minute	ft ³ /min
	liter per minute	l/min	US gallon per minute	US gal/min
	milliliter per minute	ml/min	UK gallon per minute	UK gal/min
Sound power level and sound pressure level				
	decibel	dB	decibel	dB
Water hardness				
	German hardness	°dH	English hardness	°e
	French hardness	°fH	parts per million	ppm

Glossary

Acronym	Definition
DEF	Diesel Exhaust Fluid
ISO	International Organization for Standardization
MSDS	Material Safety Data Sheet
NOx	Nitrogen Oxide
PPE	Personal Protective Equipment
SCR	Selective Catalytic Reduction
ULSD	Ultra Low Sulfur Diesel
%	Percent
<	Less than
>	Greater than

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com