


**Tractor, Full tracked  
NSN: 2410-01-254-1667  
Model MC 1150E**

**Operator's Manual**

9-13230

Reprinted

**CASE III**




 *THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.*

M171B

If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



# WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

# **Operator's Manual**

**Tractor, Full tracked  
NSN: 2410-01-254-1667  
Model MC 1150E**

**JI Case Company  
Racine WI 53404**

**Burl 9-13230**



*This symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED.** The message that follows the symbol contains important information about safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.*

84-01

**BEFORE THE OPERATOR STARTS THE ENGINE:**

1. GIVE INSTRUCTION TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
2. MAKE SURE THE OPERATOR READS AND UNDERSTANDS THE OPERATORS MANUAL FOR THIS MACHINE.



# WARNING

**IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH.**


**BEFORE STARTING THE ENGINE, DO THE FOLLOWING:**

1. READ THE OPERATORS MANUAL
2. READ ALL THE SAFETY DECALS ON THE MACHINE
3. CLEAR THE AREA OF OTHER PERSONS

**LEARN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, CLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.**

It is your responsibility to observe pertinent laws and regulations and to follow manufacturers instructions on machine operation and maintenance.

84-02




**CAUTION**  
HEARING PROTECTION  
REQUIRED

## TABLE OF CONTENTS

<p>Service Requirements of Operator ..... 3</p> <p style="padding-left: 20px;">Operators Daily Service ..... 5</p> <p style="padding-left: 40px;">Identification of Machine Components ..... 6</p> <p>Safety ..... 7</p> <p style="padding-left: 20px;">Personal ..... 8</p> <p style="padding-left: 20px;">Before Starting Engine ..... 10</p> <p style="padding-left: 20px;">Starting Engine ..... 12</p> <p style="padding-left: 20px;">Machine Operation ..... 12</p> <p style="padding-left: 20px;">Dozer Operation ..... 15</p> <p style="padding-left: 20px;">Winch Operation ..... 16</p> <p style="padding-left: 20px;">Parking the Machine ..... 17</p> <p style="padding-left: 20px;">Maintenance ..... 17</p> <p>ROPS ..... 21</p> <p style="padding-left: 20px;">Cast Iron Parts ..... 21</p> <p style="padding-left: 20px;">Machine Transport ..... 21</p> <p style="padding-left: 20px;">Spark Arrester ..... 21</p> <p style="padding-left: 20px;">Safety Decals ..... 22</p> <p>Specifications ..... 24</p> <p>Product Identification and Serial Numbers ..... 34</p> <p>Controls and Instruments ..... 36</p> <p style="padding-left: 20px;">Instrument Panel ..... 36</p> <p style="padding-left: 20px;">Brake Pedals ..... 39</p> <p style="padding-left: 20px;">Transmission Controls and Engine Foot Throttle ..... 40</p> <p style="padding-left: 20px;">Neutral Lock and Starter Button ..... 41</p> <p style="padding-left: 20px;">Master Disconnect ..... 41</p> <p style="padding-left: 20px;">Parking Brake ..... 41</p> <p style="padding-left: 20px;">Operators Seat Belt ..... 42</p> <p style="padding-left: 20px;">Cab Controls ..... 43</p> <p style="padding-left: 20px;">Power Angle Tilt Dozer Controls ..... 45</p> <p style="padding-left: 20px;">Winch Control ..... 46</p> <p>Operating Instructions ..... 47</p> <p style="padding-left: 20px;">Engine Operation ..... 47</p> <p style="padding-left: 40px;">Walk-Around Inspection ..... 47</p> <p style="padding-left: 40px;">Starting the Engine ..... 48</p> <p style="padding-left: 40px;">Operating Turbocharged Engine ... 49</p> <p style="padding-left: 40px;">Engine Speed ..... 49</p> <p style="padding-left: 20px;">Parking the Machine and Stopping the Engine ..... 49</p> <p style="padding-left: 20px;">Turbocharged Engine ..... 50</p> <p style="padding-left: 20px;">Methods to Help Start the Engine During Cold Weather ..... 51</p> <p style="padding-left: 20px;">Slave Receptacle ..... 51</p>	<p>Ether Start Aid ..... 52</p> <p>Crawler Operation ..... 53</p> <p style="padding-left: 20px;">Transmission Controls ..... 54</p> <p style="padding-left: 20px;">Steering ..... 55</p> <p style="padding-left: 20px;">Stopping the Crawler ..... 57</p> <p style="padding-left: 20px;">Operating on a Hill ..... 58</p> <p style="padding-left: 20px;">Procedure to Transport the Machine ..... 58</p> <p style="padding-left: 20px;">Dozer Operating Tips ..... 59</p> <p style="padding-left: 20px;">Operating in Cold Weather ..... 62</p> <p style="padding-left: 20px;">Operating in Hot Weather ..... 63</p> <p>Maintenance and Lubrication ..... 64</p> <p style="padding-left: 20px;">Lubrication Chart ..... 65</p> <p style="padding-left: 20px;">Fluids and Lubricants ..... 67</p> <p style="padding-left: 20px;">Run-In Period ..... 70</p> <p style="padding-left: 20px;">Run-In Maintenance ..... 70</p> <p style="padding-left: 20px;">Engine Lubrication System ..... 71</p> <p style="padding-left: 20px;">Air Cleaning System ..... 73</p> <p style="padding-left: 20px;">Engine Cooling System ..... 78</p> <p style="padding-left: 20px;">Engine Fuel System ..... 81</p> <p style="padding-left: 20px;">Hydraulic System ..... 84</p> <p style="padding-left: 20px;">Transmission and Torque Converter ..... 87</p> <p style="padding-left: 20px;">Final Drive ..... 90</p> <p style="padding-left: 20px;">Batteries ..... 91</p> <p style="padding-left: 20px;">Track System ..... 92</p> <p style="padding-left: 20px;">Cab Service ..... 95</p> <p style="padding-left: 20px;">Transmission Control Lever Adjustment ..... 97</p> <p style="padding-left: 20px;">Spark Arrester Muffler ..... 98</p> <p style="padding-left: 20px;">Parking Brake and Manual Foot Brake Adjustment ..... 99</p> <p style="padding-left: 20px;">Machine Storage ..... 101</p> <p style="padding-left: 20px;">Seat Belts ..... 102</p> <p style="padding-left: 20px;">Ether Starting Fluid Can ..... 103</p> <p style="padding-left: 20px;">Decals ..... 104</p> <p style="padding-left: 20px;">Roll-Over Protective Structure ..... 106</p> <p>Winch - Table of Contents ..... 110</p> <p style="padding-left: 20px;">General Safety Recommendation .... 111</p> <p style="padding-left: 20px;">Specifications ..... 113</p> <p style="padding-left: 20px;">Theory of Operation ..... 114</p> <p style="padding-left: 20px;">Wire Rope Installation ..... 116</p> <p style="padding-left: 20px;">Preventative Maintenance ..... 116</p> <p style="padding-left: 20px;">Recommended Planetary Gear Oil ... 118</p> <p style="padding-left: 20px;">Recommended Bolt Torque ..... 118</p>
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

# SERVICE REQUIREMENTS OF OPERATOR

## Basic Machine, Dozer, and Winch



### Service Upon Receipt of Equipment

1. General. Upon receipt of equipment, the operator is to inspect the dozer to insure that no damage has occurred since initial preparation for use and that the equipment is ready for use.

2. Lubrication. Check to be sure that the dozer has been lubricated in accordance with the current lubrication chart.

3. Completeness of Equipment. Check the following equipment and publications to insure they are properly attached or stowed on the equipment.

1. Rifle rack.
2. Operators manual.
3. Lubrication chart.

### Preventive Maintenance

1. General. To insure that the equipment is ready for operation at all times, it must be inspected systematically before operation, during operation, and after operation, so that defects may be discovered and corrected before they result in serious damage or failure. The necessary preventive maintenance services will be performed before operation. Defects discovered during operation of the unit will be noted for future correction, to be made as soon as operation has ceased. Stop operation immediately if a deficiency is noted during operation which would damage the equipment if operation were continued. After-operation-services shall be performed by the operator after every operating period. After-operation-services will be performed at intervals based on the normal operations of the equipment. Reduce

## SERVICE REQUIREMENTS OF OPERATOR \_\_\_\_\_

interval to compensate for abnormal conditions. Defects or unsatisfactory operating characteristics beyond the scope of the operator to correct must be reported at the earliest opportunity to organizational maintenance.

2. Operator's daily services. The daily services to be performed by the operator are listed in table 1-1.



**Buy Now**



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)