1600 Mower-Conditioner

LITHO IN U.S.A. ENGLISH

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

CAUTION: This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center. This manual is part of a total product support program.

FOS MANUALS—REFERENCE


TECHNICAL MANUALS—MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.



E33300

EX,TM1474,IFC -19-26APR93

Dealer Presentation Sheet

JOHN DEERE DEALERS

IMPORTANT: Please remove this page and route through your service department.

This is a complete revision for TM1474, 1600 Mower-Conditioner.

Listed below is a brief explanation of what was changed.

- 1. The information on the double overlap cutterbar.
- 2. The information on the diagnostic procedure for the platform hydraulic drive system.
- 3. The procedure for installing bushings in the wheel drops.
- 4. The repair and adjustment of the conditioner roll drive.
- 5. The repair and adjustment of the platform auger drive.
- 6. The repair of the knife drive case.

EX,TM1474,DLR -19-26APR93

Contents

SECTION 10—General

Group 05—Safety

Group 10—General Information

Group 15—Specifications

Group 20—Lubrication

20 Eddinodion

SECTION 20—Cutting ComponentsGroup 05—General Information

Group 10—Diagnosing Malfunctions

Group 15—Cutterbar

Group 20-Knife Drive Case

SECTION 30—Platform

Group 05—General Information

Group 10—Diagnosing Malfunctions

Group 15—Platform Frame

Group 20—Reel

Group 25—Augers

Group 30—Platform Drives

SECTION 40—Conditioner

Group 05—General Information

Group 10—Diagnosing Malfunctions

Group 15—Chain Drive

Group 20-Roll Arms

Group 25-Rolls

SECTION 50—Carrier Frame

Group 05—General Information

Group 10—Diagnosing Malfunctions

Group 15—Frame Components

Group 20—Tongue

Group 25—Wheel Hub and Support

Group 30—Electrical System

SECTION 60—Hydraulics

Group 05—General Information

Group 10—Diagnosing Malfunctions

Group 15—Hydraulic Tests

Group 20—Hydraulic Pump

Group 25—Planetary Gear Case

Group 30—Hydraulic Motor

Group 35—Relief Valve and Filter

Group 40—Steering Cylinder Group 45—Lift Cylinders

Index

30

10

20

40

50

60

INDX

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

i

TM1474-19-15JAN02

COPYRIGHT® 1993
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRUCTION® Manual
Previous Editions
Copyright 1992, 1990 Deere & Company

Section 10 General

Contents

	Page
Group 05—Safety	10-05-1
Group 10—General Information Machine Description	10-10-1 10-10-1 10-10-2
Group 15—Specifications Machine Specifications Metric Cap Screw Torque Values Inch Cap Screw Torque Values Tighten O-Ring Fittings Tighten Flare-Type Tube Fittings	10-15-1 10-15-3 10-15-4 10-15-5 10-15-6
Group 20—Lubrication Hydrostatic Drive Oil	10-20-1 10-20-1 10-20-2 10-20-2

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com