


**OPERATOR'S MANUAL**

# **DEBRIS BLOWER**

**| BL1130**



**FRONTIER**  
EQUIPMENT™

**OM 0400-A  
01/11**

---

## TABLE OF CONTENT

---

SPECIFICATIONS.....	3
INTRODUCTION – TO THE PURCHASER.....	4
SECURITY.....	5-9
Before Operation.....	5
Notice .....	6
Debris Blower .....	6
Before Operation.....	6
Debris blower Operation.....	7
The Tractor .....	8
General Information .....	8
Operating the Tractor.....	8
During Operation.....	8
Maintenance .....	9
Transportation .....	9
Storage .....	9
DECALS .....	10
ASSEMBLY.....	11-18
Tractor Preparation .....	11
Debris Blower Assembly.....	11
Debris Blower removing front wooden crate .....	11
Debris Blower Installation on a Three Point Hitch.....	12
Installation of the Debris Blower with a Quick Hitch Cat. 1 .....	13
Installation of the Debris Blower with a Quick Hitch Cat. 2.....	13
Driveline Preparation.....	14
How To Determine Driveline Angles.....	14
Angles at Each End Of Driveline .....	15
Determining Driveline Length.....	15-16
Driveline Installation.....	17
Removing Debris Blower from Tractor.....	18

---

## TABLE OF CONTENT

---

OPERATION .....	19-21
General Preparation.....	19
Roadway Transport .....	19
OPERATION .....	20
Debris Blower Commands .....	20
Debris Blower Utilisation.....	20
Nozzle air ejection Orientation .....	20
Adjustments .....	21
Reduction Chain Tension Adjustment .....	21
MAINTENANCE.....	22-28
Maintenance .....	22
Shear Bolt.....	22
Lubrication.....	23
Periodic Checks .....	23
Belt Replacement.....	24
Impeller Removing and Reinstallation.....	25
Driveline Troubleshooting .....	26-28
PARTS .....	29-35
Introduction .....	29
Manual Holder.....	29
Debris Blower – Housing .....	30
Debris Blower – Drum.....	31
Debris Blower – Belt Drive.....	32-33
Debris Blower – Hitch and Wheels.....	34
Driveline 5RD4700159 .....	35
TORQUE SPECIFICATION TABLE .....	36

---

## SPECIFICATION

---

Features and Specifications	BL1130
Power source	30HP tractor – PTO 540 rpm 25 HP PTO
Category Compatibility 3 point	Standard cat.1 & cat.2
Quick Hitch Compatibility	ASABE Compatible Cat. 1 & 2
Air flow	6061 cfm
Impeller dimension	29 3/4" x 10" – 12 blades
Impeller speed	1453 rpm to 540 rpm
Air velocity	141 m/h – 227 km/h
Outlet area	70.4 cu.in – 454.2 cu.cm
Drive	Belt 4-5VX560 "power band"
Driveline	40 series
Directional control	Manual Panel – left or right
Ground clearance	3 1/8"
Height adjustment	Determined by tractor
Caster wheel	3 wheels – 12" dia. X 3" pneumatic
Impeller housing	Rear & front panel: 10ga Housing edge : 12ga
Dimension	46 1/2" length x 48 1/2" height x 49 1/4" width
Weight	655 lbs

**Thank you so much for reading.**

**Please click the “Buy Now!”  
button below to download the  
complete manual.**

***Buy Now***



**After you pay.**

**You can download the most  
perfect and complete manual in  
the world immediately.**

**Our support email:**

**ebooklibonline@outlook.com**