
Ref: B0.01.1 (1)



| Fig. | P/n | QTY | Name |
|------------|--------------------|-----|------------------------------|
| | | | |
| Notes: | | | |
| [DURADU 80 | 5 CLASSIC -> 9001] | | |
| 3 | 2.3199.312.2/20 | 1 | plug m 35x1.5x9.5 |
| 5 | 2.0439.273.7 | 8 | stud bolt m 8 |
| 6 | 2.1559.188.2 | 4 | bush 11.4 x 14 x16 |
| 7 | 2.1539.259.0 | 8 | special oil seal 107.62x2.62 |
| 8 | 2.1560.010.0 | 1 | gasket 14.2 x 20 |
| 9 | 2.3199.292.0 | 1 | plug 1/4" gas |
| 11 | 0.066.1152.0/10 | 4 | gasket |
| 13 | 2.1549.154.2 | 4 | bush 4.8x5.8x16 |
| 14 | 0.015.2988.4/10 | 1 | crankcase |
| 14.1 | 2.3130.001.1 | 10 | plug 1/8" gas |
| 14.2 | 2.3130.002.1 | 2 | plug 1/4" gas |
| 14.3 | 2.3130.003.1 | 6 | plug 3/8" gas |
| 14.4.1.1.1 | 0.065.1112.7/10 | 1 | support |
| 14.4.1.2 | 2.1699.165.0 | 1 | bush 12.3x15x16 |
| 14.4.2 | 0.065.1114.0/10 | 3 | support |
| 14.4.3 | 0.065.1116.3 | 1 | support |
| 14.4.3.2 | 2.1699.165.0 | 1 | bush 12.3x15x16 |
| 14.4.5 | 0.065.1117.0 | 10 | screw m 12 x 100 |
| 14.5 | 2.3179.012.0 | 1 | plug 60 |
| 14.6 | 0.065.1140.0 | 4 | special bushing 59X55X20 |
| 14.7 | 0.065.1141.0 | 1 | special bushing 59X55X30 |
| 14.8 | 0.014.1340.0/10 | 1 | pin mm 85 |
| 25 | 0.013.4946.0/10 | 1 | sprayer nozzle |
| 26 | 2.3120.101.0 | 1 | plug m 18 p.1.5 |
| 28 | 2.1560.014.0 | 1 | washer 18.2 x 24 |


Section: B0 - ENGINE CRANKCASE

Ref: B0.01.2 (1)

MONOBLOC ENGINE-GEARBOX CONNECTING FLANGE

Section: B0 - ENGINE

| Fig. | P/n | QTY | Name |
|--------------------------|-----------------------|-----|-----------------------------------|
| Notes: [DORADO |) 86 CLASSIC -> 9001] | | |
| 1 | 0.007.7752.0/30 | 1 | flange |
| 2 | 2.0112.511.2 | 8 | screw m 14 p.2 x 30 |
| 3 | 2.1651.912.0 | 2 | cylindrical plug 12x28 |
| 4 | 2.1651.917.0 | 1 | cylindrical plug 12x40 |
| 5 | 2.0432.257.7 | 1 | stud bolt m 12 p.1.75 - 1.25 x 30 |
| 6 | 2.0439.250.7 | 1 | stud bolt m $12 / m 10 \ge 30$ |
| 7 | 0.011.9294.0/10 | 1 | bush |






Ref: B0.01.6 (1)

ENGINE OIL AND TURBO PRESSURE SWITCH UNION

| Fig. | P/n | QTY | Name |
|-------------------|---------------------|-----|--------------------|
| Notes: [DORADC | 86 CLASSIC -> 9001] | | |
| 10 | 2.3339.787.0/10 | 1 | pipe fitting 7/16" |
| 11 | 2.3110.403.1 | 1 | plug m 14 p.1.5x12 |

| 1 | | | - | r0r |
|--------------------------------------|----|-----------------|---|---------------------|
| | 12 | 2.1560.010.0 | 2 | gasket 14.2 x 20 |
| 14 2.1533.038.0 1 oil seal 15.45x2.6 | 13 | 2.1019.129.2/10 | 1 | nut m 18 p.1.5x12 |
| | 14 | 2.1533.038.0 | 1 | oil seal 15.45x2.62 |

Section: B0 - ENGINE




Section: B0 - ENGINE

Ref: B0.01.9 (1)

| PLUG | | | | |
|------|-----|-----|------|--|
| Fig. | P/n | QTY | Name | |

Notes: [DORADO 86 CLASSIC -> 9001]

1 2.3130.003.1 1 plug 3/8" gas



9_34311_06_0-A-001

Ref: B0.02.0 (1)

Section: B0 - ENGINE CRANKSHAFT PULLEY


P/n QTY Name

Notes:

Fig.

- FOR TRACTORS WITHOUT AIR CONDITIONING [DORADO 86 CLASSIC -> 9001]

| 3 | 0.007.1457.0/30 | 1 | pulley |
|---|-----------------|---|---------------------|
| 5 | 0.085.1248.0/20 | 1 | hub |
| 6 | 2.0399.144.7/10 | 1 | screw m 20 p.1.5x51 |
| 8 | 2.1720.006.0 | 1 | key 4x6.5 |



Ref: B0.02.1 (1)


Section: B0 - ENGINE CRANKSHAFT PULLEY

Fig. P/n QTY Name

Notes:

- FOR TRACTORS WITH AIR CONDITIONING [DORADO 86 CLASSIC -> 9001]

| 3 | 0.007.1458.0/40 | 1 | pulley |
|---|-----------------|---|---------------------|
| 5 | 0.085.1248.0/20 | 1 | hub |
| 6 | 2.0399.144.7/10 | 1 | screw m 20 p.1.5x51 |
| 8 | 2.1720.006.0 | 1 | key 4x6.5 |



9_37512_06_0-A-001

Section: B0 - ENGINE

Ref: B0.02.2 (1)


PULSE WHEEL

Fig. P/n QTY Name

Notes:

[DORADO 86 CLASSIC -> 9001]

1 0.011.3531.0 1 gear Z = 48



Ref: B0.02.3 (1)

COOLANT PUMP AND ALTERNATOR DRIVEBELT


Fig. P/n QTY Name

Notes:

Section: B0 - ENGINE

- FOR TRACTORS WITHOUT AIR CONDITIONING [DORADO 86 CLASSIC -> 9001]

1 2.4119.193.0 1 vee belt AV 10 x 1254 mm



Ref: B0.02.4 (1)

COOLANT PUMP AND ALTERNATOR DRIVEBELT


| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
| | | | |

Notes:

Section: B0 - ENGINE

- FOR TRACTORS WITH AIR CONDITIONING [DORADO 86 CLASSIC -> 9001]

| 1 | 2.4119.138.0 | 2 | belt AV 12.7x1380 mm |
|---|--------------|---|----------------------|
| 2 | 2.4119.134.0 | 1 | belt AV 10x794 mm |



Name


Section: B0 - ENGINE CRANKSHAFT

P/n

Fig.

Notes:

Ref: B0.02.7 (1)



| Notes: | | | |
|--------|-----------------------|---|-----------------------------|
| [DORAD | O 86 CLASSIC -> 9001] | | |
| | | | |
| 2 | 0.086.1210.3/40 | 1 | crankshaft |
| 2.2 | 0.065.1211.0/10 | 1 | crown wheel |
| 2.3 | 2.1630.608.0 | 1 | pin 6x16 |
| 2.4 | 2.1720.006.0 | 1 | key 4x6.5 |
| 2.5 | 0.065.1323.0/30 | 1 | gear Z = 29 |
| 2.6 | 2.1651.915.0 | 1 | pin 12x35 |
| 2.7 | 2.3130.001.1 | 4 | plug 1/8" gas |
| 4 | 0.065.1215.0/10 | 5 | main half bushing STANDARD |
| 5 | 0.065.1216.0/10 | 5 | main half bushing STANDARD |
| 6 | 0.065.1218.0 | 4 | shim STANDARD |
| 8 | 2.1599.524.7 | 1 | washer 21x60x12 |
| 9 | 2.1589.189.0 | 2 | shoulder ring mm 1.00 |
| 11 | 2.1529.073.0 | 1 | special oil seal 110x130x13 |
| 14 | 0.065.1254.0/20 | 1 | gasket |
| 15 | 0.007.1711.0/10 | 1 | cover |
| 16 | 2.1475.002.2 | 9 | conical washer 8 |
| 17 | 2.0112.207.2 | 9 | screw m 8 p 1.25 x 20 |
| 401 | 0.065.1215.7 | | main half bushing - mm 0.25 |
| 402 | 0.065.1215.8 | | main half bushing - mm 0.50 |
| 501 | 0.065.1216.7 | | main half bushing - mm 0.25 |
| 502 | 0.065.1216.8 | | main half bushing - mm 0.50 |
| 601 | 0.065.1218.7 | | $shim + mm \ 0.10$ |
| 602 | 0.065.1218.8 | | $shim + mm \ 0.15$ |

QTY

1/1


Ref: B0.02.9 (1)

Section: B0 - ENGINE ENGINE FLYWHEEL

| Fig. | P/n | QTY | Name |
|--------|-----|-----|------|
| | | · | |
| Notes: | | | |

| Tiones. | |
|-----------|--------------------|
| [DORADO 8 | 6 CLASSIC -> 9001] |

| 50 | 0.255.2525.0/10 | 1 | flange |
|------|-----------------|---|-----------------------|
| 51 | 0.076.1247.3/30 | 1 | flywheel |
| 51.2 | 0.065.1242.0 | 1 | crown wheel $Z = 123$ |
| 52 | 2.0139.022.2 | 6 | screw m 12 p.1.25x55 |



Name


Section: B0 - ENGINE COUNTERWEIGHTS

P/n

Fig.

Notes:


Ref: B0.02.10 (1)



| [DORADO 86 CLASSIC -> 9001] | | | | | |
|-----------------------------|-----------------|---|---------------------------|--|--|
| [Donando of | | | | | |
| 25 | 2.1589.139.0 | 1 | shoulder ring mm 0.3 | | |
| 26 | 2.1589.140.0 | 3 | shoulder ring mm 0.1 | | |
| 29 | 2.1579.628.0 | 3 | spacer 16.5x26x0.1 | | |
| 33 | 2.1579.629.0 | 6 | spacer 12.5x26x0.1 | | |
| 34 | 2.1589.048.0 | 1 | shoulder ring 16.5x26x0.3 | | |
| 35 | 2.1589.049.0 | 1 | shoulder ring 12.5x26x0.3 | | |
| 38.1.1 | 0.086.1231.0/10 | 1 | box | | |
| 38.1.2 | 2.3130.001.1 | 4 | plug 1/8" gas | | |
| 38.2 | 0.086.1233.3/30 | 1 | mass sx/lh/li | | |
| 38.2.2 | 2.1559.115.0 | 2 | special bushing 26x30x30 | | |
| 38.2.99.4 | 2.1651.302.0 | 1 | roll pin 4x6 | | |
| 38.3 | 0.065.1233.3/30 | 1 | mass dx/rh/re | | |
| 38.3.2 | 2.1559.115.0 | 2 | special bushing 26x30x30 | | |
| 38.3.99.4 | 2.1651.302.0 | 1 | roll pin 4x6 | | |
| 38.3.99.5 | 2.1410.018.7 | 1 | circlip 45 | | |
| 38.4.1 | 0.065.1234.0/10 | 1 | shaft | | |
| 38.4.2 | 2.3130.001.1 | 1 | plug 1/8" gas | | |
| 38.5 | 2.1631.717.0 | 2 | roll pin 8 x 40 | | |
| 38.6 | 2.1589.185.0 | 4 | shoulder ring 26.1x34x1 | | |
| 38.7 | 2.0522.212.7 | 1 | screw m 8 p.1.25 x 30 | | |
| 44 | 2.1579.626.0 | 2 | spacer 13.2x16x11 | | |
| 45 | 2.0139.028.2 | 4 | screw m 12 | | |
| 46 | 2.1699.191.0 | 1 | bush 7x10x16 | | |
| | | | | | |

ΟΤΥ

Ref: B0.03.3 (1)



Section: B0 - ENGINE CYLINDER - PISTON - CONNECTING ROD


| Fig. | P/n | QTY | Name |
|-------------------|---------------------|-----|--|
| Notes: [DORADO | 86 CLASSIC -> 9001] | | |
| 1 | 0.099.0065.A | 4 | cyl. piston assembly "A" - CLASS A |
| 1 | 0.099.0065.B | 4 | cyl. piston assembly "B" - CLASS B |
| 1.2 | 0.A12.2675.0 | 1 | engine cylinder "A" - CLASS A |
| 1.2 | 0.B12.2675.0 | 1 | engine cylinder "B" - CLASS B |
| 1.3 | 0.099.0060.A | 1 | complete piston "A" - CLASS A |
| 1.3 | 0.099.0060.B | 1 | complete piston "B" - CLASS B |
| 1.3.1 | 0.081.0090.6/10 | 1 | piston ring set |
| 1.3.2 | 2.1411.014.1 | 2 | circlip 35 |
| 1.3.3 | 0.078.1236.0 | 1 | piston pin Ø 18 / Ø 35 / L = mm 86 |
| 2 | 0.078.1220.3/30 | 4 | engine connecting rod |
| 2.1 | 2.1559.114.0/10 | 1 | special bushing |
| 2.2 | 2.0399.213.0 | 2 | screw m 12 p.1.25x61.5 |
| 3 | 0.065.1225.0 | 8 | con.rod half bushing STANDARD - A = 28.75 -> 29.00 |
| 3 | 0.065.1225.7 | 8 | con.rod half bushing - mm 0.25 |
| 3 | 0.065.1225.8 | 8 | con.rod half bushing - mm 0.50 |

9_M5212_01_M-A-001

Section: B0 - ENGINE

Ref: B0.04.1 (1)

| | TIMING CASE | | | | , | |
|--------------------|---------------------------------------|-----------------|-----|----------------------------------|---|--|
| | Fig. | P/n | QTY | Name | | |
| | Notes: [DORADO 86 CLASSIC -> 9001] | | | | | |
| | 4 | 2.0432.009.7 | 1 | stud bolt m 8 p.1.25 / p. 1 x 35 | | |
| | 15 | 2.0432.003.7 | 1 | stud bolt m 8 p.1.25 / p.1 x 20 | | |
| | 16 | 2.0312.214.2 | 7 | screw m 8 p.1.25 x 40 | | |
| | 17 | 2.1480.014.1 | 15 | washer 8 | | |
| 9_M8211_00_0-B-001 | 18 | 0.013.4981.0 | 1 | guard | | |
| [| 19 | 0.065.1150.0/30 | 1 | gasket | | |
| | 20 | 2.1470.004.2 | 4 | lock washer 8 | | |
| | 21 | 2.1011.405.2 | 2 | nut m 8 p.1 | | |
| | 22 | 2.0312.208.2 | 8 | screw m 8 p.1.25 x 25 | | |
| | 23 | 2.1529.167.0 | 1 | oil seal | | |



Name

Section: B0 - ENGINE CASING COVER

Ref: B0.04.3 (1)

| $\begin{array}{c c} 30 & 31 & 34 & 32 \\ \hline 0 & \end{array}$ |
|---|
| |
| |
| |
| 33 34 35 |
| |
| 9_38811_01_0-A-001 |

Notes:

Fig.

[DORADO 86 CLASSIC -> 9001]

| 30 | 0.065.1152.0 | 1 | gasket |
|----|--------------|---|--------------------------------|
| 31 | 0.013.6374.2 | 1 | cover |
| 32 | 2.0112.205.2 | 2 | screw m 8 p.1.25 x 16 |
| 33 | 2.0432.005.7 | 2 | stud bolt m 8 p.1.5 / p.1 x 25 |
| 34 | 2.1310.004.2 | 4 | flat washer 8.4x17 |
| 35 | 2.1011.405.2 | 2 | nut m 8 p.1 |

QTY

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com