PRINCE	35 ->	10001
--------	-------	-------

Ref: B0.00.0	(1)
--------------	-----

Section: B0 - ENGINE ENGINE

Fig.

101


P/n

QTY Name

•


Notes:

[PRINCE 35 -> 10001 4WD]



6.N8600.01.0	1	new engine <=50 kw
		☞ 6.N8600.01.0
		☞ 6.N8600.01.0
		☞ 6.N8600.01.0
		@ 6.N8600.01.0
		☞ 6.N8600.01.0
		@ 6.N8600.01.0


Ref: 6.N8600.01.0



01011-001E 35CV


Section: B0 - ENGINE	
CYLINDER HEAD	

Fig.	P/n	QTY	Name
1	0.010.3948.1	1	engine head
1.2	0.000.0000.1		cannot be supplied
1.2.1	0.010.2634.1	1	plug
1.2.2	0.009.4527.0	7	plug
1.2.3	0.000.0000.1		cannot be supplied
1.2.4	0.000.0000.1		cannot be supplied
1.2.5	0.010.2634.2	4	valve guide
1.2.6	0.010.2635.0	4	valve guide
1.2.7	0.000.0000.1		cannot be supplied
1.2.8	0.010.2637.1	4	special bushing
1.3	0.009.4545.1	1	plug
4	0.010.2633.1	14	screw
5	0.010.2635.2	1	gasket
6	0.009.4541.2	2	bracket
7	0.010.2633.0	2	screw




Section:	B0 - ENGINE			Ref: 6.N8600.01.0
CYLIN	DER HEAD			
Fig.	P/n	QTY	Name	
1	0.010.2637.2	4	inlet valve Ø mm 6.5	
2	0.010.2638.0	4	exhaust valve Ø mm 6.5	
3	0.010.2638.1	8	spring	
4	0.000.0000.1	8	cannot be supplied	
5	0.009.4561.2	16	stop	
6	0.009.4562.0	8	gasket	
7	0.010.2639.0	8	cap	
8	0.000.0000.1	1	cannot be supplied	
8.1	0.010.2640.1	1	screw	
8.2	0.009.4559.0	2	ring	
8.3	0.010.3949.0	8	rocker arm	
8.3.4	0.010.2641.0	8	nut	
8.3.5	0.000.0000.1		cannot be supplied	
8.3.6	0.010.3949.1	8	register	
8.7	0.010.2644.1	1	shaft	
8.7.8	0.010.2643.0	2	plug	
8.7.9	0.000.0000.1		cannot be supplied	
8.10	0.010.2642.0	1	support	
8.11	0.010.2642.1	3	support	
8.12	0.010.2643.1	3	spring	
8.13	0.010.2643.2	4	screw	
9	0.010.2644.0	1	camshaft	
10	0.009.4567.0	1	special bearing	
11	0.009.4566.0	1	washer	
12	0.009.4567.2	1	stick	
13	0.010.2639.1	1	screw	

MIT_H36_004-A-001



Section: B0 - ENGINE

Ref: 6.N8600.01.0



CAMSHAFT				
Fig.	P/n	QTY	Name	
1	0.010.3949.2	1	camshaft	
2	0.009.4555.1	1	key	
3	0.010.3950.0	1	small plate	
4	0.010.2639.1	2	screw	
5	0.010.3950.1	8	tappets	
6	0.010.2646.2	8	rod	

01031-016E

Ref: 6.N8600.01.0

-1.2-3-1.1 2 FORWARD INLET MANIFOLD


Section: B0 - ENGINE CYLINDER HEAD COVER

Fig.	P/n	QTY	Name
1	0.010.2647.1	1	cover
1.1	0.000.0000.1		cannot be supplied
1.2	0.000.0000.1		cannot be supplied
2	0.010.2647.2	1	gasket
3	0.010.2645.2	5	screw
4	0.009.4548.0	1	plug
5	0.010.2647.0	1	tube

MIT_H36_005-A-001

Section: B0 - ENGINE





01041-048E

CRANKCASE					
Fig.	P/n	QTY	Name		
1	0.010.3950.2	1	crankcase		
1.2	0.000.0000.1		cannot be supplied		
1.2.1	0.010.2652.1	3	special bushing		
1.2.2	0.010.2652.2	3	special bushing		
1.2.3	0.010.2653.0	10	screw		
1.2.4	0.010.2653.1	1	special bushing		
1.2.5	0.000.0000.1		cannot be supplied		
1.2.5.6	0.000.0000.1		cannot be supplied		
1.2.5.7	0.000.0000.1		cannot be supplied		
1.2.5.8	0.000.0000.1		cannot be supplied		
1.2.5.9	0.000.0000.1		cannot be supplied		
1.2.5.10	0.000.0000.1		cannot be supplied		
1.2.11	0.000.0000.1		cannot be supplied		
1.3	0.009.4523.2	1	guide		
1.4	0.010.2649.0	1	plug		
1.5	0.010.2649.1	3	special bushing		
1.6	0.009.4545.1	1	plug		
1.7	0.009.4524.2	4	special bushing		
1.8	0.009.4525.1	2	special bushing		
1.9	0.009.4525.2	1	special bushing		
1.10	0.009.4524.1	1	expansion plug		
1.11	0.010.3951.0	1	pin		
1.12	0.009.4523.0	2	pin		
1.13	0.010.2650.0	1	pin		
1.13.1	0.000.0000.1	1	cannot be supplied		
1.13.2	0.000.0000.1	1	cannot be supplied		
1.15	0.010.2651.0	2	pin		
1.16	0.010.2651.1	1	plug		
1.17	0.010.2648.2	1	plug		
18	0.010.2648.1	4	screw		
19	0.010.2650.2	1	pipe fitting		
20	0.010.2651.2	4	gasket		

MIT_H36_008-A-001

1/1

main half bushing STANDARD

main half bushing - mm 0.25

main half bushing - mm 0.50

main half bushing - mm 0.75

Name

plug

QTY

1

1

1

1

1

Section: B0 - ENGINE

MAIN BEARINGS

P/n

0.009.4530.0

0.009.4531.0

0.009.4531.1

0.009.4531.2

0.009.4532.0

Fig.

1


2

3

4


5

Ref: 6.N8600.01.0



MIT_H36_011-A-001

0104B1-003E



Section: B0 - ENGINE TIMING CASE				Ref: 6.N8600.01.0
Fig.	P/n	QTY	Name	
1	0.010.2658.0	1	plate	
2	0.010.2658.1	1	gasket	
3	0.010.2639.1	10	screw	
4	0.010.3951.1	1	flange	
5	0.010.2659.0	1	gasket	
6	0.010.2659.1	8	screw	
7	0.009.4537.0	1	gasket	
8	0.010.3951.2	1	plug	
9	0.010.2660.0	1	flange	
10	0.010.2660.1	1	gasket	
11	0.009.4756.0	2	cover	
12	0.010.3952.0	2	gasket	
13	0.010.2661.0	1	screw	
14	0.010.2661.1	2	nut	
15	0.010.3952.1	1	screw	
16	0.010.3952.2	2	screw	
17	0.009.4539.2	2	spring washer	
18	0.010.3953.0	1	cover	
19	0.010.2662.2	4	screw	
20	0.010.2663.0	4	washer	

MIT_H36_013-A-001

flange

screw

pin

Ref: 6.N8600.01.0

Section: B0 - ENGINE FLYWHEEL HOUSING						
Fig.	P/n	QTY	Name			
1	0.010.2654.2	1	flange			
2	0.010.2655.0	1	gasket			
3	0.010.2655.1	1	special oil seal			
4	0.010.2655.2	5	screw			

1

1

10

0.010.3953.1


0.009.4532.2

0.010.3953.2

5


6

7




MIT_H36_014-A-001

01061-019E




B0 - ENGINE		Ref: 6.N8600.0	01.0
P/n	QTY	Name	
0.010.3954.0	1	oil sump	
0.010.2664.0	1	plug	
0.010.2663.2	1	gasket	
0.000.0000.1		cannot be supplied	
0.010.3954.1	12	screw	
0.010.2664.2	1	screw	
0.010.2665.0	4	screw	
0.010.2665.1	5	washer	
0.010.2687.1	1	dipstick	
	P/n 0.010.3954.0 0.010.2664.0 0.010.2663.2 0.000.0000.1 0.010.3954.1 0.010.2664.2 0.010.2665.0 0.010.2665.1	P/n QTY 0.010.3954.0 1 0.010.2664.0 1 0.010.2663.2 1 0.000.0000.1 0 0.010.2664.2 1 0.010.2664.2 1 0.010.2665.0 4 0.010.2665.1 5	P/n QTY Name 0.010.3954.0 1 oil sump 0.010.2664.0 1 plug 0.010.2663.2 1 gasket 0.000.0000.1 cannot be supplied 0.010.2664.2 1 screw 0.010.2665.0 4 screw 0.010.2665.1 5 washer



MIT_H36_015-A-001

01071-038E

Ref: 6.N8600.01.0




Section: B0 - ENGINE PISTON - CONNECTING ROD

Fig.	P/n	QTY	Name
1	0.007.00(0.(4	
1	0.007.0060.6	4	complete piston STANDARD
1.2	0.008.0052.6	4	piston ring set STANDARD
1.3	0.010.2668.0	4	piston pin
2	0.007.0061.6	4	complete piston + mm 0.25
2.2	0.008.0053.6	4	piston ring set + mm 0.25
2.3	0.010.2668.0	4	piston pin
3	0.007.0062.6	4	complete piston + mm 0.50
3.2	0.008.0054.6	4	piston ring set + mm 0.50
3.3	0.010.2668.0	4	piston pin
8	0.010.2671.2	4	engine connecting rod
8.1	0.009.4783.0	8	nut
8.2	0.010.2668.2	8	screw
8.3	0.000.0000.1		cannot be supplied
8.4	0.000.0000.1		cannot be supplied
9	0.009.4782.1	4	con.rod half bushing STANDARD
10	0.010.2669.0	4	con.rod half bushing - mm 0.25
11	0.010.2669.1	4	con.rod half bushing - mm 0.50
12	0.010.2669.2	4	con.rod half bushing - mm 0.75

MIT_H36_016-A-001

0108A1-002 35CV



Section: B0 - ENGINE CRANKSHAFT - FLYWHEEL

Fig.	P/n	QTY	Name
1	0.010.2672.0	1	crankshaft
2	0.009.4555.1	2	key
3	0.009.4554.2	1	flat washer
4	0.009.4555.0	1	spring washer
5	0.009.4554.1	1	nut
6	0.010.2672.2	1	pulley
7	0.010.3954.2	1	flywheel
7.1	0.010.2671.0	1	crown wheel Z=110
7.2	0.000.0000.1		cannot be supplied
8	0.009.4557.0	4	screw
9	0.010.3955.0	1	gear $Z = 28$
10	0.009.4556.1	1	special bearing

1/1

Ref: 6.N8600.01.0

Section: B0 - ENGINE CAMSHAFT

Ref:	6.N8600.	.01.0

$\begin{array}{c} 2 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\$
--


CAMSHAFT				
Fig.	P/n	QTY	Name	
1	0.010.3955.1	1	gear z=56	
2	0.010.3955.2	1	gear z=56	
3	0.010.3956.0	1	gear z=39	
3.1	0.000.0000.1		cannot be supplied	
3.2	0.000.0000.1		cannot be supplied	

MIT_H36_021-A-001

01091-020E

Section: B0 - ENGINE

Ref: 6.N8600.01.0



INTAK	XE AND EXHAUS	Г		
Fig.	P/n	QTY	Name	
1	0.010.2678.0	1	cover	
1.1	0.000.0000.1		cannot be supplied	
1.2	0.000.0000.1		cannot be supplied	
2	0.010.2678.1	1	gasket	
3	0.010.2676.2	1	gasket	
4	0.010.2676.1	1	manifold	
5	0.010.2677.0	8	screw	
6	0.010.2677.1	2	screw	
7	0.010.3956.1	1	exhaust manifold	
8	0.010.3956.2	6	screw	
9	0.010.3957.0	2	screw	
10	0.009.4796.1	3	stud bolt	

MIT_H36_022-A-001

02011-039E

2 03011-001E

Section: B0 - ENGINE OIL PUMP				Ref: 6.N8600.01.0
Fig.	P/n	QTY	Name	
1	0.010.2684.2	1	oil pump	
1.1	0.010.2685.0	1	gasket	
2	0.010.2685.1	3	screw	

Ref: 6.N8600.01.0

FORWARD

2—©	
1	0000000
	03031-008E

MIT_H36_026-A-001

				TOOOT
Section:				
LUBRI	CATION			
Fig.	P/n	QTY	Name	
		·		

1	0.010.2685.2	1	tube
1.1	0.009.4634.0	1	self-locking nut
2	0.009.4634.1	1	gasket

1/1

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com