

ORIGINAL INSTRUCTIONS

OPERATOR'S MANUAL

T7030

T7040

T7050

T7060

Power Command Transmission

Part number 47460292

2nd edition English

March 2013



TO THE OWNER

This manual contains information concerning the adjustment and maintenance of your New Holland T7030, T7040, T7050, T7060, T7070 Tractor. You have purchased a dependable machine, but only by proper care and operation can you expect to receive the performance and long service built into this tractor. Please have all operators read this manual carefully and keep it available for ready reference.

This machine was designed to power and propel itself. It is intended to load and move materials with a variety of buckets and forks. Allied attachments built and supplied by other manufacturers can be used on the tractor where recommended and approved by New Holland.

Your New Holland dealer will instruct you in the general operation of your tractor. (Refer to the "Delivery Report" at the back of this manual.) Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your tractor.

Your New Holland dealer carries a complete line of genuine New Holland service parts. These parts are manufactured and carefully inspected to insure high quality and accurate fitting of any necessary replacement parts. Be prepared to give your dealer the model and PIN number of the engine and tractor, when ordering parts. Locate these numbers now and record them below. Refer to the "General Information" section of this manual for the location of the model and PIN numbers of your tractor.

Model _____ Engine Model _____
PIN Number _____ Engine Serial Number _____

IMPROVEMENTS

CNH America LLC is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

CONTENTS

Title	Page
Section 1 - General Information and Safety	
To the Owner	1- 1
Product Identification	1- 4
Ecology and the Environment	1- 7
Safety Precautions	1- 9
Safety Decals	1- 18
International Symbols	1- 23
Airborne Noise Emission	1- 24
Section 2 - Controls, Instruments and Operation	
Cab	2- 4
Electrical Power Sockets	2- 20
Seats	2- 24
Steering Column Controls	2- 32
Analogue/Digital Instruments	2- 36
Enhanced Keypad	2- 42
Brake Controls and Operation	2- 86
Power Command Transmission	2- 93
Differential Lock and Four Wheel Drive	2- 116
Front Axle Suspension	2- 120
Section 3 - Field Operation	
Important Information	3- 1
Boosting the Tractor Battery	3- 8
Starting the Engine	3- 9
Stopping the Engine	3- 12
Engine Power Management	3- 14
Engine Speed Management	3- 16
Headland Turn Sequence	3- 19
Fast Steer	3- 36
Rear Power Take- Off	3- 38
Front Power Take- Off and Hydraulic Lift	3- 55
Electronic Draft Control	3- 81
Hydraulic Remote Control Valves	3- 96
Three- point Hitch	3- 109
Quick Hitch	3- 115
Linkage Stabilisers	3- 117
Drawbars and Towing Attachments	3- 123
Trailer Braking Systems	3- 137
Front Wheel Track Adjustment	3- 144
Dynamic Front Fenders	3- 149
Rear Wheel Track Adjustment	3- 152
Ballasting and Tyres	3- 163

Section 4 - Lubrication and Maintenance

General Information	4- 1
Guard Removal	4- 8
Lubrication and Maintenance Chart	4- 12
Servicing: When Warning Lights Illuminate	4- 15
10- hour/daily service	4- 19
50- hour service	4- 20
100- hour service	4- 32
300- hour service	4- 31
600- hour service	4- 34
1200- hour/12 month service	4- 42
1200- hour/24 month service	4- 49
Every 3 years	4- 56
General Maintenance - as required	4- 58
Storing the tractor	4- 77

Section 5 - Fault Finding

Introduction	5- 1
Engine	5- 4
Transmission	5- 7
Hydraulics	5- 8
3-point hitch	5- 9
Brakes	5- 10
Cab	5- 10
Electrical	5- 11

Section 6 - Accessories

Rotating Beacon	6- 2
Auxiliary Headlights	6- 2
Battery Isolator Switch	6- 3

Section 7 - Specification

General Dimensions	7-2
Vehicle Weights	7-6
Lubricant and Fluid Capacities	7-7
Engine	7-8
Fuel System	7-8
Cooling System	7-9
Transmission Options	7-9
Maximum Operating Angle	7-10
Rear Power Take-Off	7-10
Front Power Take-Off	7-10
Hydraulic System	7-11
Three-Point Lift	7-11
Remote control valves	7-15
Front 3- Point Hitch	7-15
Front Remote Valves	7-15
Brakes	7-16
Steering	7-16
Electrical Equipment	7-17
Hardware Torque Tables	7-18

Section 8 - First 50- hour Service Forms	8-5
---	-----

Section 9 - Index	9-1
--------------------------------	-----

All data given in this manual is subject to production variations. The dimensions and weights provided are approximate values only and some machine features shown in this manual may not correspond to standard models. For precise information on specific models, features and specifications, please contact your authorised dealer.

**(North America Only)
(California Only)**

**CALIFORNIA
Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

SECTION 1

GENERAL INFORMATION AND SAFETY

TO THE OWNER

GENERAL INFORMATION

This Manual has been prepared to assist you in the correct procedure for running-in, driving and operating and for the maintenance of your new tractor. Read this Manual carefully. Your tractor is intended for use in normal and customary agricultural applications.

If at any time you require advice concerning your tractor, do not hesitate to contact your authorised dealer. He has factory trained personnel, genuine manufacturers' parts and the necessary equipment to carry out all your service requirements.

Your tractor has been designed and built to give maximum performance, economy and ease of operation under a wide variety of operating conditions. Prior to delivery, the tractor was carefully inspected, both at the factory and by your dealer to ensure that it reaches you in optimum condition. To maintain this condition and ensure trouble-free operation, it is important that the routine services, as specified in Section 4 of this Manual, are carried out at the recommended intervals.

OPERATORS MANUAL

The Operators Manual supplied with your tractor is an important source of information and should be stored safely.

The manual is prepared specifically for your tractor so it is important that you make a note of the print number and issue date which can be found on the cover. In the event the manual is lost or damaged it can be replaced with the correct version.

A storage pocket for the Operators Manual can be found on the rear of the seat. The manual should be kept in this pocket at all times when not in use.

SAFETY

Pages 1-9 to 1-16 inclusive, list the precautions to be observed to ensure your safety and the safety of others. Read the safety precautions and follow the advice offered **before** operating the tractor.

CLEANING THE TRACTOR

Your tractor is a state-of-the-art machine with sophisticated, electronic controls. This should be taken into consideration when cleaning the tractor, particularly if using a high pressure washer. Even though every precaution has been taken to safeguard electronic components and connections, the pressure generated by some of these machines is such that complete protection against water ingress cannot be guaranteed.

When using a high pressure washer, do not stand too close to the tractor and avoid directing the jet at electronic components, electrical connections, breathers, seals, filler caps, etc. Never direct a cold water jet at a hot engine or exhaust.

ELECTRO-MAGNETIC INTERFERENCE (EMC)

This tractor complies strictly with the European Regulations on electro-magnetic emissions. However, interference may arise as a result of add-on equipment which may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- Ensure that each piece of non-New Holland equipment fitted to the tractor bears the CE mark.
- The maximum power of emission equipment (radio, telephones, etc.) must not exceed the limits imposed by the national authorities of the country where you use the tractor.
- The electro-magnetic field generated by the add-on system should not exceed 24 V/m at any time and at any location in the proximity of electronic components.

Failure to comply with these rules will render the New Holland warranty null and void.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com