

**NEW HOLLAND**

**OPERATOR'S  
MANUAL**

**Series 716B**

72" Front Mount Snowblower - #716734006

TC35, TC35D, TC40, TC40D, TC45, TC45D Tractor Sub-frame - #715452006

TC35D, TC40D, TC45D Super Steer Tractor Sub-frame - #715451006



# INTRODUCTION

## TO THE PURCHASER

This new snowblower was carefully designed to give years of dependable service.

This manual has been provided to assist in the safe operation and service of your snowblower.

**NOTE:** All drawings and illustrations in this manual may not necessarily depict the actual models or equipment, but are intended for reference only and are based on the latest product information available at the time of publication.

Familiarize yourself fully with the safety recommendations and operating procedures before putting the machine to use. Carefully read, understand and follow these recommendations, and insist that those who work with you follow them.



**THIS SAFETY ALERT SYMBOL IDENTIFIES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE IT, BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY AND CAREFULLY READ THE MESSAGE THAT FOLLOWS.**


Record your snowblower model and serial number. Your dealer requires this information to give you prompt, efficient service when ordering parts or attachments. Service with genuine **NEW HOLLAND** parts when replacement parts are required.

Right hand and left hand of the snowblower is determined by facing the direction of travel during operation.

MODEL: \_\_\_\_\_

SERIAL NUMBER: \_\_\_\_\_

DATE PURCHASED: \_\_\_\_\_


|   |            |
|---|------------|
|  |            |
| <b>NEW HOLLAND</b>  |            |
| MODEL NO.   | SERIAL NO. |
|   |            |
| COMPONENT   |            |
|   |            |
| NEW HOLLAND NORTH AMERICA, INC.   |            |
| MADE IN U S A   |            |

THE SERIAL NUMBER PLATE IS LOCATED ON THE REAR OF THE IMPELLER HOUSING.

# OPERATING INSTRUCTIONS FOR SNOWBLOWER



## SAFETY



Before you attempt to operate this machine, read and study the following safety information, in addition, make sure that every individual who operates or works with this equipment, whether family member or employee, is familiar with these safety precautions.










**The safety alert symbol above means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**













REMEMBER: The careful operator is the best operator. Most accidents are caused by human error. Certain precautions must be observed to prevent the possibility of injury or damage.

## HAZARD WARNINGS

The use of the words **CAUTION**, **WARNING**, or **DANGER** herein and on the machine itself signals three degrees of hazard. **CAUTION** is used for general reminders of good safety practice or to direct attention to unsafe practices. **WARNING** is used to denote a specific potential hazard. **DANGER** is used to denote the most serious potential hazard.

The following **HAZARD WARNINGS** are used here and on the snowblower. Be **very** familiar with them before operating this machine:

-  **CAUTION:** Do not start, operate, or work on this machine until you have carefully read and thoroughly understand the contents of the operator manual.
-  **CAUTION:** Failure to follow safety, operating, and maintenance instructions could result in death or serious injury to the operator or bystanders, poor operation, and costly breakdown.
-  **CAUTION:** Unless otherwise instructed by decal or operator's manual, stop engine before leaving operators position, and wait for all movement to stop before attempting to adjust, lubricate, unclog, or inspect. Exercise mandatory shut-down procedure.
-  **CAUTION:** Always observe safety rules shown on decals. If decals become damaged, or if the unit is repainted, replace the decals. If repainting, be sure that all decals which apply to your machine, are affixed to your unit.
-  **CAUTION:** Become familiar and know how to use all safety devices and controls on the snowblower before attempting to operate the unit. Know how to stop the unit before starting it.
-  **CAUTION:** Before proceeding to perform any service routines on the snowblower, exercise the mandatory shut-down procedure. After service has been performed be sure to restore all guards, shields, and covers to their original position.
-  **CAUTION:** Before working under any hydraulically controlled implement, be certain it is securely blocked.
-  **CAUTION:** Keep children and spectators off and away from the machine while it is operating.
-  **WARNING:** Keep all guards, shields, and decals in place.

-  **WARNING:** Be sure PTO shield turns freely.
-  **WARNING:** Keep hands, feet and clothing away from moving or power driven parts.
-  **WARNING:** Do not wear loose or baggy clothing around moving machinery. Machine must be clear of people, tools, and other objects before engaging PTO.
-  **WARNING:** Engage the PTO slowly to prevent unnecessary shearing of pins or damage to blower.
-  **WARNING:** Read and observe all warnings on machine before attempting to operate the snowblower. Do not attempt to operate this machine unless factory installed safety devices are in place
-  **WARNING:** Never attempt to lubricate the blower with the engine running. Always be sure to exercise the mandatory shut-down procedure.
-  **DANGER:** Escaping fluid under pressure can be invisible and can penetrate the skin. Do not use hands to search for leaks!
-  **DANGER:** Hydraulic lines or other components can be hot after operation! Do not touch!
-  **DANGER:** Keep hands out! Do not step on or climb over the unit while machine is in operation!
-  **DANGER:** Rotating auger can catch hands or feet!
-  **DANGER:** Keep hands out! Rotating components can catch hands!
-  **DANGER:** Rotating drive line. Personal injury or death can result from entanglement!

## **MANDATORY SHUT-DOWN PROCEDURE**

Work of any type on machinery is always more dangerous when the machine is operating. Before cleaning, adjusting, lubricating or servicing any part of this unit, the following mandatory shut-down procedure should always be followed:

1. **Disengage all power to snowblower, (PTO, hydraulic valve, or clutch, etc.)**
2. **Move throttle to slow idle position, shut off engine and remove ignition key.**

Read and observe all safety information and decals on the blower before operating the unit. In addition, familiarize yourself with all of the safety devices and periodically check that they are functioning properly.

Remember, it is the owner's responsibility for communicating information on the safe use and proper maintenance

## **OPERATING THE SNOWBLOWER:**

The following precautions are suggested before operating this attachment to prevent accidents.

- Before starting, remove any ice that has accumulated in the collector and impeller.
- Adjust collector housing height to clear gravel or crushed rock surfaces.

- Before the snow season, thoroughly inspect the area where the equipment is to be used, and remove all boards, wires and other foreign objects.
- Never allow anyone to ride on the attachments.
- Clear the area of people and debris before beginning operation.
- Never allow children to operate equipment, or any adults that have not had proper instructions and training.
- Always keep the attachment discharge spout pointed away from all objects that could be struck by flying debris.
- Never allow anyone in front of the snowblower.
- Never leave the attachment in a raised position.
- Never operate the attachment without good visibility and lighting.
- Never clean or perform any maintenance on PTO driven equipment with the tractor engine running.
- When operating PTO driven equipment, always shut off the engine and wait for the PTO to stop turning before getting off the tractor, before unplugging the collector/impeller housing or discharge chute and before making any repairs, adjustments or inspections.
- Take all possible precautions when leaving the tractor unattended. Disengage the PTO, lower the attachments, shift into neutral, set the parking brake, stop the engine and remove the key.
- Disengage power to attachment when transporting or when not in use.
- The operator should never get off the tractor while is in motion.
- Exercise extreme caution when operating on or crossing gravel drives, walks or roads. Stay alert for the hidden hazards of traffic.
- Do not put hands or feet near rotating parts, to unplug discharge chute or near any moving parts.
- Keep a careful watch for debris that could enter the blower while operating.
- Never operate the attachment without guards, shields and other safety protective devices in place.
- Never operate blower at high transport speeds and use special care when backing up.
- After striking a foreign object, stop the engine, wait for all movement to stop, thoroughly inspect the attachment for damage and make any repairs needed before restarting and operating the attachment.
- If the snowblower should start to vibrate abnormally, stop the engine immediately and check the probable cause, repair before continuing.
- Do not drive diagonally across the face of the sloped area for snow removal. Exercise extreme caution when changing direction on slopes or attempt to clear steep slopes.

### **OPERATING THE TRACTOR:**

Read the tractor operator's manual carefully to become familiar with the proper procedures of operation before using.

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)