

**OPERATOR'S MANUAL
20C 25C
06381058 Edition 02 (English)**

MANUFACTURER



JOHN DEERE

JOHN DEERE IBERICA, S.A.
GETAFE - MADRID - SPAIN

Internet: www.deere.com

MODELS AND VERSIONS



20C
25C

TABLE OF CONTENTS

MANUFACTURER

MODELS AND VERSIONS	2
----------------------------------	----------

GENERAL INFORMATION

INTRODUCTION	5
MACHINE IDENTIFICATION	6
Identification criteria	6
Decals	6
Punch marks on chassis	7
Metal plate	7
IDENTIFICATION OF THE COMPONENTS	8
Engine	8
Safety frame	8
Towing attachments (optional)	8
AFTER SALES	9
Warranty	9
Assistance	9
Spares	9
HOW TO READ THE MANUAL	10
Standard symbols	11

SAFETY

SAFETY REGULATIONS	12
SAFETY OPERATIONS	14
Training	14
Preparation	14
Operation	15
Maintenance and Storage	17
Parking Safely	17
Avoid Tipping	18
Keep Riders Off	19
Towing Loads Safely	19
Stay Clear of Rotating	20
Checking Wheel Hardware	20
Wear Appropriate Clothing	20
Practice Safe Maintenance	21
Avoid High Pressure Fluids	22
Prevent Fires	23
Tire Safety	23
Handling Fuel Safely	24
Handling Waste Product and Chemicals	25
SAFETY DEVICES	26
Safety frame	26
Safety belts (optional)	26
SAFETY DECALS	27

NOISE	28
Table of maximum noise levels	28
Noise level information	28
Recommendations for the user	28
ECOLOGY	29

OPERATING INSTRUCTIONS

CONTROLS AND INSTRUMENTS	30
Dashboard	30
Multifunction instrument	31
Controls in front part	33
Controls on rh side	33
Controls on lh side	34
Seat controls	34
STARTING AND STOPPING THE ENGINE	35
How to start the engine	35
Before starting the engine	35
Ignition switch	35
How to stop the engine	36
HOW TO START AND STOP THE MACHINE	37
Safety frame	37
How to start the machine	38
How to stop the machine	38
Light switch	38
Horn	38
Turn indicator	39
Lights	39
TRANSMISSION	40
Main clutch	40
Gearbox	40
Gearshift lever	41
Reverse shuttle lever	41
Final drive lever	42
Hand throttle	42
Rear diff lock	43
BRAKING SYSTEM	44
Main brake	44
Parking brake	45
POWER TAKE-OFF	46
Rear power take-off (PTO)	46
Independent power take-off	47
REAR POWER LIFT	48
Up-down	48
Position control	49
Floating mode	49
TOWING ATTACHMENTS	50
Drawbar	51
Front tow hook	51
"CLASS B CUNA" tow hook (optional)	52
Towing the machine	53
Seven-pin trailer socket	53

BALLAST	54
Ballast (optional).....	54
Front ballast (optional).....	54
Wheel ballasting by filling the tyres with fluid.....	55
WHEELS	56
Tyres.....	56

MAINTENANCE

Routine maintenance chart.....	58
ENGINE UNIT	63
How to open the bonnet.....	63
Engine.....	63
Fuel tank.....	63
Dry air filter.....	64
Cooling system.....	65
TRANSMISSION UNIT	67
Gearbox housing, rear differential, power lift.....	67
Front differential.....	68
Clutch.....	69
Steering.....	70
Brakes.....	70
ELECTRICAL SYSTEM	71
Battery.....	71
Headlights.....	72
Rear lights.....	73
Fuses.....	74
Engine air filter clogging sensor.....	76
BODYWORK	77

TECHNICAL SPECIFICATIONS

DIMENSIONS AND WEIGHTS	78
Table of Machine Dimensions and Weights.....	78
Engine.....	78
Maximum load per axle.....	78
SPEEDS	79
Speed Chart.....	79
RECOMMENDED LUBRICANTS AND FLUIDS	80
Original lubricants.....	80
Original protective fluids.....	80

DECLARATION OF CONFORMITY

GENERAL INFORMATION



ORIGINAL INSTRUCTIONS

INTRODUCTION

This manual contains a description of how the machine operates and instructions about how to correctly use the machine and perform the main routine and supplementary servicing operations.

This manual is divided into chapters for practical consultation.

This manual must always be consigned together with the machine if this is transferred or sold. If the manual is damaged or lost, order a new copy from the manufacturer or from the previous owner. This manual is an integral part of the machine

The confidence you have shown in our company by choosing equipment carrying our trademark will be amply repaid by the excellent service it will give you over the years.

Correct use and normal routine maintenance will generously rewarded in performance, output and savings.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com