

F910/F930 Front Mower



JOHN DEERE

TECHNICAL MANUAL

F910/F930
Front Mower

TM1301 (01APR86) English



TM1301 (01APR86)

LITHO IN U.S.A.
ENGLISH



F910/F930 FRONT MOWER TECHNICAL MANUAL TM-1301 (Apr-86)

SECTION AND GROUP CONTENTS

SECTION 10—GENERAL

- Group 05—Introduction and Safety Information
- Group 10—General Specifications
- Group 15—Cap Screw Torque
- Group 20—Tune-Up
- Group 25—Fuel and Lubrication
- Group 30—Serial Numbers

SECTION 20—ENGINE REPAIR

- Group 05—Engine Removal and Installation
- Group 10—Muffler

SECTION 30—FUEL AND AIR REPAIR

- Group 05—Fuel Pump
- Group 10—Fuel Tanks, Fuel Filters, Fuel Valve
and Lines

SECTION 40—ELECTRICAL REPAIR

- Group 05—PTO Clutch

SECTION 50—POWER TRAIN REPAIR

- Group 05—Transmission
- Group 10—Transmission Hand Control Linkage
(-360,000)
- Group 11—Transmission Foot Control Linkage
(360,001-)
- Group 15—Differential
- Group 20—Axles

SECTION 60—STEERING AND BRAKES REPAIR

- Group 05—Steering Valve
- Group 10—Brakes
- Group 15—Brake and Park Brake Linkage (-
360,000)
- Group 16—Brake and Park Brake Linkage (360,001-
)
- Group 20—Rear Axle and Wheels

SECTION 70—HYDRAULICS REPAIR

- Group 05—Hydraulic Control Valve
- Group 10—Weight Transfer Valve

Continued on next page

SECTION 80—MISCELLANEOUS REPAIR

- Group 05—Mower Gearbox
- Group 10—Mower Spindle

SECTION 210—GENERAL

- Group 05—Machine Operational Checkout

SECTION 220—ENGINE OPERATION AND TESTS

- Group 05—System Checkout
- Group 10—System Diagnosis

SECTION 230—FUEL AND AIR OPERATION AND TESTS

- Not used—Refer to Section 220

SECTION 240—ELECTRICAL OPERATION AND TESTS

- Group 05—System Checkout
- Group 10—System Diagnosis
- Group 15—Component Tests
- Group 20—Theory of Operation

SECTION 250—POWER TRAIN OPERATION AND TESTS

- Group 05—Transmission Hand Control Linkage Adjustment (, -360,000)
- Group 06—Transmission Foot Control Linkage Adjustment (360,000- ,)
- Group 10—Power Train Test and Adjustment
- Group 15—Theory of Operation

SECTION 260—STEERING AND BRAKES OPERATION AND TESTS

- Group 05—Theory of Operation

SECTION 270—HYDRAULICS OPERATION AND TESTS

- Group 05—Theory of Operation

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT® 1986
DEERE & COMPANY
Moline, Illinois
All rights reserved
A JOHN DEERE ILLUSTRATION

M45;0000A 1A 160486

Section 10

GENERAL INFORMATION

CONTENTS

	Page		Page
GROUP 05—INTRODUCTION AND SAFETY		GROUP 25—FUEL AND LUBRICATION	
Introduction	10-05-1	Fuel	10-25-1
Safety	10-05-2	Fuel Storage	10-25-1
GROUP 10—GENERAL SPECIFICATIONS		Engine Oil	10-25-2
Specifications		Transmission-Hydraulic Oil	10-25-2
F910 Front Mower	10-10-1	General Purpose Grease	10-25-3
F930 Front Mower	10-10-2	Cold Weather Operation	10-25-3
GROUP 15—CAP SCREW TORQUE		Alternative Lubricants	10-25-3
Bolt Torque Chart	10-15-1	Lubricant Storage	10-25-4
Metric Hardware Torque Specifications	10-15-2	GROUP 30—SERIAL NUMBERS	
O-Ring Boss Fitting Service		Serial Numbers	
Recommendations	10-15-3	Tractor PIN	10-30-1
GROUP 20—TUNE-UP		Engine	10-30-1
Tune-Up		Transmission	10-30-2
Specifications	10-20-1	Differential	10-30-2
Adjustments	10-20-2	Hydraulic Control Valve	10-30-2

M45;1000A 1 271185

INTRODUCTION

This manual is part of a total service support program.

FOS Manuals—reference


Technical Manuals—machine service

Component Manuals—component service

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand alone manuals covering multiple machine applications.



AB6;RW5559 053;INTRO2 030785

FEATURES OF THIS TECHNICAL MANUAL

John Deere ILLUSTRATION format emphasizing illustrations and concise instructions in easy-to-use modules.

Emphasis on diagnosis, analysis, and testing so you can understand the problem and correct it.


Diagnostic information presented with the most logical and easiest to isolate problems first to help you identify the majority of routine failures quickly.

Step-by-step instructions for teardown and assembly.

Summary listing at the beginning of each group of all applicable specifications, wear tolerances, torque values, essential tools, and materials needed to do the job.

An emphasis throughout on safety—so you do the job right without getting hurt.

This technical manual was planned and written for you—an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.



AB6;RW5560 053;INTRO3 071085

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com