

300A Auger Platform and 300 Grass Seed Special

**John Deere Ottumwa Works
TM1526 (08APR02)**

LITHO IN U.S.A.
ENGLISH

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center.

This manual is part of a total product support program.

FOS MANUALS—REFERENCE

TECHNICAL MANUALS—MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

Contents

SECTION 10—General

- Group 05—Safety
- Group 10—General Information
- Group 15—Specifications
- Group 20—Lubrication
- Group 25—Platform Lift Cylinder Lockout

- Group 10—Diagnosing Malfunctions
- Group 15—Hay Conditioner (All Models)
- Group 20—Hay Conditioner (36-66)
- Group 25—Hay Conditioner (31-61)

SECTION 20—Drive Train

- Group 05—General Information, Specifications, and Torque Values
- Group 10—PTO Driveline
- Group 15—Platform Gear Case
- Group 20—Right and Left Cross Shafts
- Group 25—Adjustments

SECTION 99—Fabricated Tools

Index

SECTION 30—Reel

- Group 05—General Information, Specifications and Torque Values
- Group 10—Diagnosing Malfunctions
- Group 15—Repair Reel
- Group 20—Adjust Reel

SECTION 40—Auger

- Group 05—General Information, Specifications and Torque Values
- Group 10—Diagnosing Malfunctions
- Group 15—Repair Auger
- Group 20—Adjust Auger

SECTION 50—Cutting Components

- Group 05—General Information, Specifications, and Torque Values
- Group 10—Diagnosing Malfunctions
- Group 15—Cutterbar
- Group 20—Knife Drive Case

SECTION 60—Electrical

- Group 05—General Information
- Group 10—Warning Light
- Group 15—Connector
- Group 20—Contact

SECTION 70—Hay Conditioner

- Group 05—Specifications and Torques

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1526-19-08APR02

COPYRIGHT© 1992
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual

Section 10 General

Contents

Page

Group 05—Safety 10-05-1

Group 10—General Information

Group 15—Specifications

300A Auger Platform 10-15-1

300 Grass Seed Special 10-15-2

Torque Values 10-15-3

Group 20—Lubrication

Group 25—Platform Lift Cylinder Lockout

Engage 10-25-1

Disengage 10-25-1

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-04JUN90

10
05
1
T81389 -UN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-09JAN92

TS187 -19-30SEP88

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90

TS227 -UN-23AUG88

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com