

1600A Mower-Conditioner

**John Deere Ottumwa Works
TM1571 (27FEB97)**

LITHO IN U.S.A.
ENGLISH

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

CAUTION: This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center.

This manual is part of a total product support program.

FOS MANUALS—REFERENCE


TECHNICAL MANUALS—MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.



E37930
-JUN-03MAR94

EX, TM1571, IFC -19-14MAR94

Contents

SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—General Information
- Group 15—Specifications
- Group 20—Lubrication

Group 45—Lift Cylinders

Index

SECTION 20—CUTTING COMPONENTS

- Group 05—General Information
- Group 10—Diagnosing Malfunctions
- Group 15—Cutterbar
- Group 20—Knife Drive Case

SECTION 30—PLATFORM

- Group 05—General Information
- Group 10—Diagnosing Malfunctions
- Group 15—Platform Frame
- Group 20—REEL
- Group 25—Augers
- Group 30—Platform Drives

SECTION 40—CONDITIONER

- Group 05—General Information
- Group 10—Diagnosing Malfunctions
- Group 15—Roll Drive Chain
- Group 20—Upper Conditioner Roll Arms
- Group 25—Conditioner Rolls

SECTION 50—CARRIER FRAME

- Group 05—General Information
- Group 10—Diagnosing Malfunctions
- Group 15—Frame Components
- Group 20—Tongue
- Group 25—Wheel Hub and Support
- Group 30—Electrical System

SECTION 60—HYDRAULICS

- Group 05—General Information
- Group 10—Diagnosing Malfunctions
- Group 15—Hydraulic Tests
- Group 20—Hydraulic Pump
- Group 25—Planetary Gear Case
- Group 30—Hydraulic Motor
- Group 35—Relief Valve And Oil Filter
- Group 40—Steering Cylinder

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1571-19-27FEB97

COPYRIGHT© 1994
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual

Section 10 GENERAL INFORMATION

Contents

Page

Group 05—Safety 10-05-1

Group 10—General Information

Machine Description 10-10-1

Tractor Requirement 10-10-2

Three-Point Hitch 10-10-2

Group 15—Specifications

Machine Specifications 10-15-1

Metric Cap Screw Torque Values 10-15-3

Inch Cap Screw Torque Values 10-15-4

Tighten O-Ring Fittings 10-15-5

Tighten Flare-Type Tube Fittings 10-15-6

Group 20—Lubrication

Extreme Pressure Grease 10-20-1

Hydrostatic Drive Oil 10-20-1

Knife Drive Case Oil 10-20-2

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90


10
05
-JUN-23AUG88
TS227

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

-JUN-23AUG88
TS291

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com