



9940 Cotton Picker



JOHN DEERE


TECHNICAL MANUAL

9940
Cotton Picker

TM1356 (01SEP85) English

TM1356 (01SEP85)

LITHO IN U.S.A.
ENGLISH



9940 COTTON PICKER TECHNICAL MANUAL TM-1356 (SEP-85)

CONTENTS

Publication Number Change

This technical manual was formerly TM-1241. The number was changed when engine information was removed. Some pages still carry the old publication number. For engine information, refer to Engine Component Technical Manual, CTM-1.

SECTION 10—GENERAL

- Group 00—General Specifications
- Group 05—Predelivery, Delivery and After-Sale Services
- Group 10—Tune-Up and Adjustment
- Group 15—Fuels and Lubricants

SECTION 20—ENGINE REPAIR

- Group 05—Remove and Install Engine
- Group 29—Remove/Install Cooling System

SECTION 30—FUEL AND AIR REPAIR

- Group 00—Specifications and Special Tools
- Group 04—Remove/Install Air Intake System
- Group 09—Remove/Install Diesel Fuel System

SECTION 40—ELECTRICAL REPAIR

- Group 00—Specifications and Special Tools
- Group 10—Charging Circuit Repair
- Group 15—Starting Circuit Repair
- Group 20—Lights, Instruments, and Accessory Circuits Repair

SECTION 50—POWER TRAIN REPAIR

- Group 00—Specifications and Special Tools
- Group 10—Transmission
- Group 15—Axles and Differential
- Group 25—Sundstrand Hydrostatic Drive
- Group 26—Eaton Hydrostatic Drive

SECTION 60—STEERING/BRAKES REPAIR

- Group 00—Specifications and Special Tools
- Group 05—Steering
- Group 10—Brakes

SECTION 70—HYDRAULIC REPAIR

- Group 00—Specifications and Special Tools
- Group 05—Reservoir
- Group 10—Hydraulic Pump
- Group 15—Main Control Valve
- Group 20—Hydraulic Cylinders
- Group 25—Hydraulic Motors
- Group 30—Height Control

SECTION 80—AXLES AND WHEELS REPAIR

- Group 00—Specifications
- Group 05—Guide Axle
- Group 10—Wheels

SECTION 90—OPERATOR STATION REPAIR

- Group 00—Specifications and Special Tools
- Group 05—Air Conditioning System
- Group 10—Heating System
- Group 15—Miscellaneous Components

SECTION 120—PICKING UNITS REPAIR

- Group 00—Specifications and Special Tools
- Group 05—Picking Units Removal and Installation
- Group 10—Grid Bars and Pressure Plates
- Group 15—Spindles and Picker Bars
- Group 20—Picker Drums, Drive Shafts, and Gears
- Group 25—Idler Gears and Bearings
- Group 30—Doffers, Stub Shaft and Drive
- Group 35—Moistener Columns
- Group 40—Gear Cases, Universal Joints, and Countershafts
- Group 45—Picking Unit Cabinets and Cam Tracks

SECTION 130—MOISTENER AND AIR SYSTEMS REPAIR

- Group 00—Specifications
- Group 05—Moistener System
- Group 10—Air System

CONTENTS—Continued

SECTION 220—ENGINE OPERATION AND TESTS

- Group 00—Specifications and Special Tools
- Group 05—System Operation
- Group 10—System Tests and Diagnosis

SECTION 230—FUEL/AIR OPERATIONS AND TESTS

- Group 00—Specifications and Special Tools
- Group 05—Air Intake System
- Group 10—Diesel Fuel System

SECTION 240—ELECTRICAL OPERATION AND TESTS

- Group 00—Specifications and Special Tools
- Group 05—General Information and Diagrams
- Group 10—Charging Circuit
- Group 15—Starting Circuit
- Group 20—Lights, Instruments, and Accessory Circuits

SECTION 250—POWER TRAIN OPERATION AND TESTS

- Group 00—Specifications and Special Tools
- Group 10—Transmission
- Group 15—Axles and Differential
- Group 25—Hydrostatic Drive

SECTION 260—STEERING/BRAKES OPERATION AND TESTS

- Group 00—Specifications and Special Tools
- Group 05—Steering
- Group 10—Brakes

SECTION 270—HYDRAULIC OPERATION AND TESTS

- Group 00—Specifications and Special Tools
- Group 05—System Operation and Tests
- Group 10—Hydraulic Pump
- Group 15—Main Hydraulic Valve
- Group 20—Hydraulic Cylinders
- Group 25—Hydraulic Motors
- Group 30—Height Control

SECTION 290—OPERATOR STATION OPERATION AND TESTS

- Group 00—Specifications and Special Tools
- Group 05—Pressurizer System
- Group 10—Air Conditioning System Operation
- Group 15—Air Conditioning System Tests and Diagnosis
- Group 20—Heating System

SECTION 325—PICKING, MOISTENER, AND AIR SYSTEMS

- Group 00—Specifications and Special Tools
- Group 05—Systems Operation and Diagnosis

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1985
DEERE & COMPANY
Moline, Illinois
All rights reserved
Previous Editions
Copyright© 1981, 1982, 1983, 1984 Deere & Company
A JOHN DEERE ILLUSTRATION

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com